




# ***Service Manual***

## **Ultra Heat GMV6 Mini DC Inverter VRF Units**

Capacity: 36000Btu/h~60000Btu/h

Rated Frequency: 60Hz

Operation Range: Cooling: -5~54°C(23~129°F) Heating: -30~27°C(-22~81°F)



# Contents

|   |           |
|---|-----------|
| <b>Chapter 1 Product .....</b>                              | <b>1</b>  |
| <b>1 Unit List .....</b>                                    | <b>1</b>  |
| 1.1 Basic Modules .....                                     | 1         |
| <b>2 Parameters .....</b>                                   | <b>1</b>  |
| 2.1 Parameters of Basic Modules .....                       | 1         |
| <b>3 The Range of Production Working Temperature .....</b>  | <b>2</b>  |
| <b>Chapter 2 Commissioning .....</b>                        | <b>3</b>  |
| <b>1 Commissioning Process .....</b>                        | <b>3</b>  |
| <b>2 Safety Requirements .....</b>                          | <b>3</b>  |
| <b>3 Unit Commissioning .....</b>                           | <b>4</b>  |
| 3.1 Preparation .....                                       | 4         |
| 3.2 Check Items after Installation and Test Operation ..... | 7         |
| <b>4 Unit Function Settings .....</b>                       | <b>19</b> |
| 4.1 DIP Switch Settings .....                               | 19        |
| 4.2 System Function Operations .....                        | 20        |
| 4.3 Restoration to Default Settings .....                   | 35        |
| 4.4 Fire Alarm Function Setting .....                       | 36        |
| 4.5 Indoor Unit Function Applications .....                 | 36        |
| <b>Chapter 3 Faults .....</b>                               | <b>37</b> |
| <b>1 Error Indication .....</b>                             | <b>37</b> |
| <b>2 Troubleshooting .....</b>                              | <b>40</b> |
| 2.1 "A0" Unit's to-be-commissioned State .....              | 40        |
| 2.2 "A2" Refrigerant Recycle Running State .....            | 41        |
| 2.3 "A3" Defrosting State .....                             | 41        |
| 2.4 "A4" Oil Return State .....                             | 41        |
| 2.5 "A6" Cooling and Heating Function Settings State .....  | 41        |
| 2.6 "A7" Silent Mode Settings State .....                   | 42        |
| 2.7 "A8" Vacuum Pumping Mode .....                          | 42        |
| 2.8 "AH" Heating State .....                                | 42        |
| 2.9 "AC" Cooling State .....                                | 42        |
| 2.10 "AF" Fan State .....                                   | 42        |
| 2.11 "AE" Artificial Refrigerant Charging State .....       | 43        |
| 2.12 "AJ" Filter Clean Prompt .....                         | 43        |
| 2.13 "AP" Unit Commissioning Startup Confirmation .....     | 43        |
| 2.14 "AU" Remote Control for Emergency Stop .....           | 43        |
| 2.15 "Ab" Emergency Stop .....                              | 44        |

|  |    |
|--|----|
| 2.16 "Ad" Restricted Running State .....   | 44 |
| 2.17 "b1" Outdoor Ambient Temperature Sensor Fault .....   | 44 |
| 2.18 "b2" Defrosting Temperature Sensor 1 Fault .....  | 45 |
| 2.19 "b3" Defrosting Temperature Sensor 2 Fault .....  | 46 |
| 2.20 "b4" Subcooler's Liquid Outlet Temperature Sensor Fault .....   | 46 |
| 2.21 "b5" Subcooler's Gas Outlet Temperature Sensor Fault .....  | 47 |
| 2.22 "b6" Suction Temperature Sensor 1 Fault .....   | 48 |
| 2.23 "b7" Suction Temperature Sensor 2 Fault .....   | 49 |
| 2.24 "b8" Outdoor Humidity Sensor Fault .....  | 50 |
| 2.25 "b9" Heat Exchanger's Gas Outlet Temperature Sensor Fault .....   | 51 |
| 2.26 "bA" Oil Return Temperature Sensor Fault .....  | 52 |
| 2.27 "bd" Subcooler Air Inlet Temperature Sensor Error .....   | 53 |
| 2.28 "bJ" High and Low Pressure Sensor is Wrongly Connected .....  | 53 |
| 2.29 "bn" Subcooler Liquid Temperature Sensor Error .....  | 54 |
| 2.30 "C0" Communication Fault Between Indoor and Outdoor Units and Between Indoor Unit and<br>Wired Controller ..... | 54 |
| 2.31 "C2" Communication Fault Between the Primary Controller and Inverter Compressor Driver                          | 56 |
| 2.32 "C3" Communication Fault Between the Primary Controller and Inverter Fan Driver .....                           | 57 |
| 2.33 "C4" Indoor Unit Loss Fault .....   | 58 |
| 2.34 "C5" Indoor Unit Engineering SN Conflict .....  | 58 |
| 2.35 "C6" Alarm on Inconsistent Number of Outdoor Units .....  | 59 |
| 2.36 "C8" Emergency Operation of Compressor .....  | 60 |
| 2.37 "C9" Emergency Operation of Fan .....   | 60 |
| 2.38 "CA" Emergency Operation of Module .....  | 60 |
| 2.39 "CH" Too High Rated Capacity Ratio .....  | 60 |
| 2.40 "CL" Too Low Rated Capacity Ratio .....   | 61 |
| 2.41 "CJ" System Address Code Conflict .....   | 61 |
| 2.42 "CP" Fault of Multiple Main Wired Controllers .....   | 62 |
| 2.43 "Cb" IP Address Assignment Overflow .....   | 62 |
| 2.44 "d1" Poor Indoor Circuit Board .....  | 63 |
| 2.45 "d2" Water Tank Temperature Sensor Error .....  | 63 |
| 2.46 "d3" Ambient Temperature Sensor Fault .....   | 64 |
| 2.47 "d4" Inlet Pipe Temperature Sensor Fault .....  | 65 |
| 2.48 "d5" Middle Part Temperature Sensor Fault (Reserved) .....  | 65 |
| 2.49 "d6" Outlet Pipe Temperature Sensor Fault .....   | 65 |
| 2.50 "d7" Humidity Sensor Fault .....  | 66 |
| 2.51 "d8" Water Temperature Sensor Fault (Reserved) .....  | 67 |
| 2.52 "d9" Jumper Cap Fault .....   | 67 |
| 2.53 "dA" Abnormal Network Address of Indoor Unit .....  | 67 |

|  |     |
|--|-----|
| 2.54 "dH" Abnormal Circuit Board of Wired Controller .....                             | 68  |
| 2.55 "dC" Abnormal Settings of DIP Switch for Capacity .....                           | 68  |
| 2.56 "dL" Air Outlet Temperature Sensor Fault .....                                    | 69  |
| 2.57 "dE" Indoor CO <sub>2</sub> Sensor Fault (Reserved) .....                         | 70  |
| 2.58 "dF" Temperature Sensor Error .....   | 70  |
| 2.59 "dJ" Water Return Temperature Sensor Error .....                                  | 70  |
| 2.60 "dP" Floor Heating Water Inlet Temperature Sensor Error .....                     | 71  |
| 2.61 "dU" Floor Heating Water Outlet Pipe Temperature Sensor Error .....               | 72  |
| 2.62 "db" Engineering Commissioning .....  | 72  |
| 2.63 "dd" Solar Energy Temperature Sensor Error .....                                  | 73  |
| 2.64 "dn" Swing Assy Error .....   | 73  |
| 2.65 "E1" Protection in Case of Too High Pressure .....                                | 74  |
| 2.66 "E2" Protection in Case of Too Low Air Discharge Temperature of Compressor .....  | 76  |
| 2.67 "E3" System Low Pressure Protection .....   | 77  |
| 2.68 "E4" Protection in Case of Too High Air Discharge Temperature of Compressor ..... | 79  |
| 2.69 "Ed" Low Drive Module Temperature Protection .....                                | 80  |
| 2.70 "F0" Poor Main Board of Outdoor Unit .....  | 80  |
| 2.71 "F1" High-pressure Sensor Fault .....   | 82  |
| 2.72 "F3" Low Pressure Sensor Fault .....  | 83  |
| 2.73 "F5" Discharge Temperature Sensor Fault of Compressor 1 .....                     | 84  |
| 2.74 "F6" Discharge Temperature Sensor Fault of Compressor 2 .....                     | 85  |
| 2.75 "F7" Discharge Temperature Sensor Fault of Compressor 3 .....                     | 86  |
| 2.76 "F8" Discharge Temperature Sensor Fault of Compressor 4 .....                     | 87  |
| 2.77 "F9" Discharge Temperature Sensor Fault of Compressor 5 .....                     | 88  |
| 2.78 "FA" Discharge Temperature Sensor Fault of Compressor 6 .....                     | 89  |
| 2.79 "FH" Abnormal Current Sensor of Compressor 1 .....                                | 90  |
| 2.80 "FC" Abnormal Current Sensor of Compressor 2 .....                                | 91  |
| 2.81 "FL" Abnormal Current Sensor of Compressor 3 .....                                | 92  |
| 2.82 "FE" Abnormal Current Sensor of Compressor 4 .....                                | 93  |
| 2.83 "FF" Abnormal Current Sensor of Compressor 5 .....                                | 94  |
| 2.84 "FJ" Abnormal Current Sensor of Compressor 6 .....                                | 95  |
| 2.85 "FU" Shell Roof Temperature Sensor Fault of Compressor 1 .....                    | 96  |
| 2.86 "Fb" Shell Roof Temperature Sensor Fault of Compressor 2 .....                    | 97  |
| 2.87 "H0" Fan Drive Board Fault .....  | 98  |
| 2.88 "H1" Abnormal Fan Drive Board .....   | 98  |
| 2.89 "H2" Power Voltage Protection for the Fan Drive Board .....                       | 99  |
| 2.90 "H3" Reset Protection for the Fan Drive Module .....                              | 100 |
| 2.91 "H5" Inverter Fan Over-current Protection .....                                   | 101 |
| 2.92 "H6" IPM Module Protection for Fan Drive .....                                    | 102 |



|  |     |
|--|-----|
| 2.93 "H7" Temperature Sensor Fault of Fan Drive .....  | 103 |
| 2.94 "H8" IPM Over Temperature Protection for Fan Drive .....  | 104 |
| 2.95 "H9" Loss of Synchronization Protection for Inverter Fan .....  | 105 |
| 2.96 "HC" Current Detection Circuit Fault of Fan Drive .....   | 106 |
| 2.97 "HH" Over Voltage Protection for DC Bus of Fan Drive .....  | 106 |
| 2.98 "HL" Under Voltage Protection for DC Bus of Fan Drive .....   | 107 |
| 2.99 "HJ" Inverter Fan Startup Failure .....   | 108 |
| 2.100 "J0" Protection for Other Modules .....  | 109 |
| 2.101 "J1" Compressor 1 Over-current Protection .....  | 109 |
| 2.102 "J2" Compressor 2 Over-current Protection .....  | 111 |
| 2.103 "J3" Compressor 3 Over-current Protection .....  | 112 |
| 2.104 "J4" Compressor 4 Over-current Protection .....  | 113 |
| 2.105 "J5" Compressor 5 Over-current Protection .....  | 114 |
| 2.106 "J6" Compressor 6 Over-current Protection .....  | 115 |
| 2.107 "J7" Four-way Valve Air Backflow Protection .....  | 116 |
| 2.108 "J8" High Pressure Ratio Protection .....  | 117 |
| 2.109 "J9" Low Pressure Ratio Protection .....   | 118 |
| 2.110 "L0" Indoor Unit Fault (Unified) .....   | 118 |
| 2.111 "L1" Indoor Fan Protection .....   | 120 |
| 2.112 "L2" E-heater Protection (Reserved Code, Not Yet Applied) .....  | 121 |
| 2.113 "L3" Overflow Protection .....   | 121 |
| 2.114 "L4" Supply Power Over-current Protection .....  | 122 |
| 2.115 "L5" Antifreeze Protection .....   | 123 |
| 2.116 "L6" Mode Conflict (Reserved) .....  | 124 |
| 2.117 "L7" No Master Indoor Unit .....   | 124 |
| 2.118 "L9" Inconsistent Number of Indoor Units Under Integrated Control .....  | 125 |
| 2.119 "LA" Inconsistent Series of Indoor Units Under Integrated Control .....  | 125 |
| 2.120 "LH" Poor Air Quality Alarm (Reserved Code, Not Yet Applied) .....   | 126 |
| 2.121 "LC" Unmatched Models of Indoor and Outdoor Units .....  | 126 |
| 2.122 "LL" Water Flow Switch Error .....   | 126 |
| 2.123 "LF" Shunt Valve Setting Error .....   | 127 |
| 2.124 "LU" Inconsistent IDU Branch Connecting to the Wired Controller Which Controls Multiple Indoor Units of Heat Recovery System ..... | 127 |
| 2.125 "Ln" Lifting Panel Return Air Frame Reset Error .....  | 128 |
| 2.126 "n0" System Energy Efficiency Running Settings Status .....  | 128 |
| 2.127 "n2" Settings Status of Maximum Capacity Configuration Rate for Indoor and Outdoor Units .....                                     | 129 |
| 2.128 "n4" Settings Status of Maximum Output Capacity .....  | 129 |
| 2.129 "n6" Unit Fault Query Status .....   | 129 |

|  |     |
|--|-----|
| 2.130 "n7" Unit Parameter Query Status .....                                       | 129 |
| 2.131 "n8" Indoor Unit Engineering SN Query .....                                  | 130 |
| 2.132 "n9" Status of Querying Number of Online Indoor Units .....                  | 130 |
| 2.133 "nA" Heating and Cooling Unit .....  | 130 |
| 2.134 "nH" Heating Only Unit .....   | 130 |
| 2.135 "nC" Cooling Only Unit .....   | 130 |
| 2.136 "nE" Negative Number Code .....  | 131 |
| 2.137 "nF" Fan Type Unit .....   | 131 |
| 2.138 "o3" IDU IPM Module Protection .....   | 131 |
| 2.139 "o7" IDU Non-synchronism Protection .....                                    | 132 |
| 2.140 "o8" IDU Drive Communication Error .....                                     | 133 |
| 2.141 "o9" IDU Main Control Communication Error .....                              | 134 |
| 2.142 "P0" Compressor Drive Board Fault .....                                      | 135 |
| 2.143 "P1" Malfunctioning Compressor Drive Board .....                             | 135 |
| 2.144 "P2" Input Voltage Protection for the Compressor Drive Board .....           | 136 |
| 2.145 "P3" Reset Protection for the Compressor Drive Module .....                  | 136 |
| 2.146 "P5" Inverter Compressor Over-current Protection .....                       | 136 |
| 2.147 "P6" IPM Module Protection for the Compressor Drive .....                    | 138 |
| 2.148 "P7" Abnormal Temperature Sensor of Compressor Drive Board .....             | 139 |
| 2.149 "P8" IPM Over Temperature Protection for Compressor Drive Board .....        | 139 |
| 2.150 "P9" Loss of Synchronization Protection for Inverter Compressor .....        | 140 |
| 2.151 "PC" Current Detection Circuit Fault of Compressor Drive .....               | 142 |
| 2.152 "PH" Over Voltage Protection for DC Bus of Compressor Drive .....            | 142 |
| 2.153 "PL" Under Voltage Protection for DC Bus of Compressor Drive .....           | 143 |
| 2.154 "PJ" Inverter Compressor Startup Failure .....                               | 143 |
| 2.155 "U0" Insufficient Warm-up Time for Compressor .....                          | 145 |
| 2.156 "U2" Incorrect Settings of Outdoor Unit Capacity DIP Switch/Jumper Cap ..... | 145 |
| 2.157 "U3" Power Phase-Sequence Protection .....                                   | 146 |
| 2.158 "U4" Refrigerant Loss Protection .....                                       | 146 |
| 2.159 "U6" Abnormal Valve Prompt .....   | 147 |
| 2.160 "U8" Abnormal Pipes of the Indoor Unit .....                                 | 147 |
| 2.161 "U9" Abnormal Pipes of Outdoor Unit .....                                    | 148 |
| 2.162 "UC" Master Indoor Unit Set Successfully .....                               | 149 |
| 2.163 "UL" DIP Switch Error of Compressor Emergency Operation .....                | 149 |
| 2.164 "UE" Auto Refrigerant Charging Void .....                                    | 149 |
| 2.165 "UF" Mode Exchanger IDU Identification Abnormal .....                        | 149 |
| 2.166 "y7" Fresh Air Inlet Temperature Sensor Error .....                          | 150 |
| 2.167 "yA" IFD Error .....   | 151 |
| 2.168 "y8" Indoor Air Box Sensor General Error .....                               | 152 |

|   |            |
|---|------------|
| 2.169 Ineffective Cooling and Heating .....   | 153        |
| 2.170 No Faults Displayed But Compressor Not Starting in Cooling/Heating Mode .....   | 154        |
| <b>3 Non-fault Type Troubleshooting .....</b>   | <b>155</b> |
| <b>Chapter 4 Maintenance .....</b>  | <b>158</b> |
| <b>1 Minimum Room Area for R32 Unit .....</b>   | <b>158</b> |
| 1.1 Calculation Method of Releasable Charge ( $m_{REL}$ ) .....                       | 158        |
| 1.2 Calculation Method of Releasable Charge ( $m_{REL}$ ) .....                       | 160        |
| <b>2 Vacuum Pumping, Refrigerant Adding .....</b>                                     | <b>161</b> |
| 2.1 Vacuum Pumping .....  | 161        |
| 2.2 Additional Refrigerant Charging .....   | 162        |
| 2.3 Engineering Installation Information Confirmation .....                           | 163        |
| <b>3 Inspection of Key Parts .....</b>  | <b>164</b> |
| 3.1 Power .....   | 164        |
| 3.2 Temperature Sensors .....   | 166        |
| 3.3 Solenoid Valve .....  | 171        |
| 3.4 Electronic Expansion Valve .....  | 173        |
| 3.5 Fans .....  | 175        |
| 3.6 Compressor .....  | 177        |
| 3.7 Board .....   | 183        |
| 3.8 Pressure Sensor .....   | 189        |
| <b>4 Replacement of Key Unit Parts .....</b>  | <b>191</b> |
| 4.1 Key Parts .....   | 191        |
| 4.2 Removal of Key Parts .....  | 193        |
| <b>5 Explosive View and Parts List .....</b>  | <b>202</b> |
| <b>Appendixes .....</b>   | <b>204</b> |
| <b>Appendix 1 Temperature Sensor Resistance and Temperature Relationship Table ..</b> | <b>204</b> |
| <b>Appendix 2 Refrigerant Temperature and Pressure Table .....</b>                    | <b>211</b> |
| <b>Appendix 3 Pressure Sensor Voltage and Pressure Table .....</b>                    | <b>212</b> |
| <b>Appendix 4 Electric Specifications .....</b>                                       | <b>215</b> |
| <b>Appendix 5 Circuit Diagram .....</b>   | <b>217</b> |
| <b>Appendix 6 Schematic Diagram .....</b>   | <b>218</b> |
| <b>Appendix 7 Names and Functions of Components .....</b>                             | <b>219</b> |

# Preface

Thank you for purchasing Ultra Heat GMV6 Mini DC Inverter VRF Units. For correct operation, please read this manual carefully.

This manual applies to Ultra Heat GMV6 Mini DC Inverter VRF Units. It clarifies the safety requirements, basic principles and implementation methods in engineering commissioning, troubleshooting, and after-sales maintenance. Relevant professionals must follow the national (local) safety and technical requirements as well as this manual. Failure to do so may result in improper functioning or damage to the air conditioning system, or even personal injury.

## Safety Instructions

### Warning symbols

Symbols in this document indicate different severities and possibilities.



#### **DANGER!**

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



#### **WARNING!**

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



#### **CAUTION!**

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. Or indicates an unsafe behavior.



#### **NOTES!**

Indicates a situation which could result in equipment or property loss.



#### **INFO**

Indicates helpful tips or additional information.




#### **JUMP**

Indicates a jump connection.

# Chapter 1 Product

## 1 Unit List

### 1.1 Basic Modules

| Ton | Product Code | Model              | Power          | External view   |
|-----|--------------|--------------------|----------------|---|
| 3   | CN851W4570   | GMV-V36WL/NhC-T(U) | 208/230V ~60Hz |  |
| 4   | CN851W4560   | GMV-V48WL/NhC-T(U) | 208/230V ~60Hz |   |
| 5   | CN851W4160   | GMV-V60WL/NhC-T(U) | 208/230V ~60Hz |   |

## 2 Parameters

### 2.1 Parameters of Basic Modules

| Model                           |         |       | GMV-V36WL/NhC-T(U) | GMV-V48WL/NhC-T(U) | GMV-V60WL/NhC-T(U) |
|---------------------------------|---------|-------|--------------------|--------------------|--------------------|
| Capacity                        | Cooling | Btu/h | 36000              | 48000              | 60000              |
|                                 |         | W     | 10600              | 14100              | 17600              |
|                                 | Heating | Btu/h | 45000              | 54000              | 66000              |
|                                 |         | W     | 13200              | 15800              | 19300              |
| Minimum Circuit Ampacity        |         | A     | 51.9               | 53.1               | 54.3               |
| Maximum Overcurrent Protection  |         | A     | 60                 | 60                 | 60                 |
| Power supply                    |         | —     | 208/230V ~60Hz     | 208/230V ~60Hz     | 208/230V ~60Hz     |
| Air volume                      |         | m³/h  | 6000               | 6600               | 6600               |
|                                 |         | CFM   | 3531               | 3885               | 3885               |
| Sound pressure level            |         | dB(A) | 50                 | 52                 | 55                 |
| Compressor type                 |         | —     | Inverter Rotary    | Inverter Rotary    | Inverter Rotary    |
| Compressor quantity             |         | N     | 1                  | 1                  | 1                  |
| Refrigerant oil model           |         | —     | FW68L(FW68DA)      | FW68L(FW68DA)      | FW68L(FW68DA)      |
| Refrigerant type                |         | —     | R32                | R32                | R32                |
| Refrigerant charge              |         | kg    | 3.6                | 3.6                | 3.9                |
|                                 |         | LBS   | 7.9                | 7.9                | 8.6                |
| Max. number of connectable IDUs |         | unit  | 7                  | 8                  | 10                 |
| Gas pipe                        |         | mm    | Φ15.9              | Φ15.9              | Φ15.9              |
|                                 |         | inch  | Φ5/8               | Φ5/8               | Φ5/8               |
| Liquid pipe                     |         | mm    | Φ9.52              | Φ9.52              | Φ9.52              |
|                                 |         | inch  | Φ3/8               | Φ3/8               | Φ3/8               |
| Outline dimensions (W×D×H)      |         | mm    | 900×340×1345       | 900×340×1345       | 900×340×1345       |
|                                 |         | inch  | 35-3/8×13-3/8×53   | 35-3/8×13-3/8×53   | 35-3/8×13-3/8×53   |
| Packing dimensions (W×D×H)      |         | mm    | 993×453×1500       | 993×453×1500       | 993×453×1500       |
|                                 |         | inch  | 39-1/4×18×59-1/16  | 39-1/4×18×59-1/16  | 39-1/4×18×59-1/16  |
| Net weight/Gross weight         |         | kg    | 113/124            | 113/124            | 113/124            |
|                                 |         | LBS   | 250/270            | 250/270            | 250/270            |

**NOTE:**

- ① Sound Pressure Level: Anechoic chamber conversion value, measured in a semi-anechoic room. During actual operation, the value may be higher due to ambient noise and echoes of the installation conditions.
- ② The total capacity of connected indoor units must be in the range of 50%~135% of the outdoor unit capacity. The relevant parameters can be corrected by referring to the unit capacity correction table.
- ③ The above parameters are tested based on the standard connection pipe length. In the actual project, the parameters should be corrected referring to the capacity correction for the long connection pipe of units.
- ④ Specifications may be changed due to product improvement. Please refer to nameplates of the units.

## 3 The Range of Production Working Temperature

| —                   | Cooling               | Heating                |
|---------------------|-----------------------|------------------------|
| Ambient temperature | -5°C~54°CDB(23~129°F) | -30°C~27°CDB(-22~81°F) |
| Indoor temperature  | 14°C~25°CWB(57~77°F)  | 15°C~27°CDB(59~80°F)   |
| Indoor humidity     | ≤80%                  |                        |

When the indoor units are all VRF fresh air processor, the unit operating range is as follows:

|         |  |
|---------|--|
| Cooling | Ambient temperature: 16°C(60.8°F)~45°C(113°F)  |
| Heating | Ambient temperature: -7°C(19.4°F)~16°C(60.8°F) |

**NOTE!**

If exceeding the temperature range for working, the product may be damaged, which is not within the warranty range.

# Chapter 2 Commissioning



## WARNING!


Before performing operations (such as commissioning, maintenance, and repair) on the device, you need to shut down the unit and cut off the power, and use a relevant instrument to ensure that the voltage at the power input terminal is zero, and the power indicator on the main board is off. Otherwise, an electric shock or injury may be caused.



## NOTE!

The unit features a low-power standby function. When the unit is standby, the power indicators on the main control board and the drive board are on.

## 1 Commissioning Process



## 2 Safety Requirements



## WARNING!

Safety measures must be taken for outdoor operations. All involved commissioning personnel and maintenance personnel must master the building construction safety regulations and strictly follow them.

Special workers like refrigeration workers, electricians, and welders must hold special work licenses and cannot work on other posts.

When the device is operated, the power of the entire system must be cut off, and the equipment safety requirements must be strictly followed.









All installation and maintenance operations must comply with the product design requirements and national and local safety requirements.

It is strictly forbidden to directly connect the compressor to the power.

# 3 Unit Commissioning

## 3.1 Preparation

### 3.1.1 Tools

| Name               | Picture  |
|--------------------|--|
| Screwdrivers       |    |
| Spanner            |    |
| Hex key            |    |
| Pincers            |   |
| Vacuum pump        |  |
| Electronic balance |  |
| Pressure gauge     |  |
| Multimeter         |  |



### 3.1.2 Files

To record the installation and commissioning of the unit, all the following documents need to be prepared: minutes of the pre-commissioning scheme determining meeting, commissioning personnel record form, pre-commissioning checklist, commissioning data record form, and commissioning report.

Minutes of the commissioning scheme determining meeting:

| Minutes of the commissioning scheme determining meeting for XXX project: |     |
|--|-----|
| Theme:   | xxx |
| Date:  | xxx |
| Place:   | xxx |
| Participants:  | xxx |
| Details:   | xxx |
| 1  |     |
| 2  |     |
| 3  |     |
|  |     |
|  |     |
|  |     |
|  |     |

Checklist of the commissioning system appearance:

| Checklist of the equipment appearance of xxx air-conditioning project |                                  |        |           |      |
|---|----------------------------------|--------|-----------|------|
| Item  |                                  | Defect | Inspector | Time |
| Refrigerating system  | Outdoor unit appearance          |        |           |      |
|   | Indoor unit appearance           |        |           |      |
|   | Copper pipe insulation           |        |           |      |
| Drainage system   | Condensate water pipe insulation |        |           |      |
| Electrical system   | Power cable diameter             |        |           |      |
|   | Power cable layout               |        |           |      |
|   | Air circuit breaker              |        |           |      |
| Communication system  | Communication cable material     |        |           |      |
|   | Communication cable connection   |        |           |      |

## Commissioning data record form

|   |                               |   |                |   |        |  |  |
|---|-------------------------------|---|----------------|---|--------|--|--|
| Project name:   |                               |   |                | Unit model:                               |        |  |  |
| Debugger:   |                               |   |                | Date:                                     |        |  |  |
| Rated capacity of the outdoor unit (kW):  |                               | Rated capacity of the indoor unit (kW): |                | Total length of the refrigerant pipe (m): |        |  |  |
| Maximum drop between the indoor unit and outdoor unit (m):  |                               |   |                | Supplemented refrigerant (kg):            |        |  |  |
| Commissioning status: <input type="checkbox"/> Cooling <input type="checkbox"/> Heating Qty and capacity of indoor units: |                               |   |                |   |        |  |  |
| Status Parameter  |                               | Unit                                    | Before Startup | 30 min                                    | 60 min |  |  |
| Status parameters of the outdoor unit   | Outdoor ambient temperature   | °C                                      |                |   |        |  |  |
|   | Power voltage                 | V                                       |                |   |        |  |  |
|   | Frequency                     | Hz                                      |                |   |        |  |  |
|   | Compressor current            | A                                       |                |   |        |  |  |
|   | Discharge temperature         | °C                                      |                |   |        |  |  |
|   | High system pressure          | °C                                      |                |   |        |  |  |
|   | Low system pressure           | °C                                      |                |   |        |  |  |
|   | ...                           |   |                |   |        |  |  |
| Parameters of indoor unit 1#  | Rated capacity                | kW                                      |                |   |        |  |  |
|   | Ambient temperature           | °C                                      |                |   |        |  |  |
|   | Air position                  | Position                                |                |   |        |  |  |
|   | Temperature at the air outlet | °C                                      |                |   |        |  |  |
|   | Outlet airflow                | M/S                                     |                |   |        |  |  |
|   | Noise                         | dB                                      |                |   |        |  |  |
|   | Drainage pan                  | —                                       |                |   |        |  |  |
| Parameters of indoor unit 2#  | Rated capacity                | kW                                      |                |   |        |  |  |
|   | Ambient temperature           | °C                                      |                |   |        |  |  |
|   | Air position                  | Position                                |                |   |        |  |  |
|   | Temperature at the air outlet | °C                                      |                |   |        |  |  |
|   | Outlet airflow                | M/S                                     |                |   |        |  |  |
|   | Noise                         | dB                                      |                |   |        |  |  |
|   | Drainage pan                  | —                                       |                |   |        |  |  |
|   |                               |   |                |   |        |  |  |

## 3.2 Check Items after Installation and Test Operation

### 3.2.1 Check Items after Installation

| Check items  | Possible conditions due to improper installation         | Check |
|--|--|-------|
| Each part of the unit is installed securely?   | Unit may drop, shake or emit noise.                      |       |
| Gas leakage test is taken or not?  | Insufficient cooling (heating) capacity.                 |       |
| Unit gets proper thermal insulation or not?  | There may be condensation and dripping.                  |       |
| Drainage is smooth or not?   | There may be condensation and dripping.                  |       |
| Is the voltage in accordance with the rated voltage specified on the nameplate?        | Unit may have malfunction or components may get damaged. |       |
| Is the electric wiring and pipe connection installed correctly?                        | Unit may have malfunction or components may get damaged. |       |
| Unit is securely grounded or not?  | Electrical leakage.                                      |       |
| Power cord meets the required specification?   | Unit may have malfunction or components may get damaged. |       |
| Is the air inlet/outlet blocked?   | Insufficient cooling (heating) capacity.                 |       |
| Length of refrigerant pipe and the charging amount of refrigerant are recorded or not? | The refrigerant charging amount is not accurate.         |       |
| Binding pieces on compressor feet are removed or not?                                  | Compressor may get damaged.                              |       |

### 3.2.2 Test Operation and Debugging

| <b>NOTICE</b>   |
|---|
| (1) After finishing the first installation or replacing the main board of outdoor unit, it is necessary to perform test operation and debugging. Otherwise, unit won't be able to work. |
| (2) Test operation and debugging must be performed by professional technicians or under the guidance of professional technicians.   |

#### 3.2.2.1 Prepare the Test Operation and Debugging

- (1) Do not connect power until all installation work is finished.
- (2) All control circuits and wires are correctly and securely connected.
- (3) Check whether unit's appearance and pipeline system has been damaged during transportation.
- (4) Calculate the quantity of refrigerant that needs to be added according to the pipe length. Pre-charge the refrigerant. In case that the required charging quantity is not reached while refrigerant can't be added, record the quantity of refrigerant that still needs to add and complement the quantity during test operation. For details of adding refrigerant during test operation, see below.
- (5) After refrigerant is added, make sure valves of outdoor unit are completely open.
- (6) For the convenience of troubleshooting during debugging, unit shall be connected to a PC with applicable debugging software. Make sure unit's real-time data can be checked through this computer. The installation and connection of debugging software can be found in the Service Manual.
- (7) Before test operation, make sure unit is power on and compressor has been preheated for more than 8 hours. Touch the unit to check whether it's normally preheated. If yes, start test operation. Otherwise, compressor might be damaged.

### 3.2.2.2 Test Operation and Debugging

Description of test operation procedures and main board display of ODU

| Description of each stage of debugging progress                |                |                    |  |
|--|----------------|--------------------|--|
| —  | Debugging code |                    | Code meaning and operation method  |
| Progress   | LED            |                    |  |
|  | Code           | Display status     |  |
| 01_ Setting of master control unit                             | A0             | ON                 | The unit is in debugging standby status. Press and hold the button SW3 for over 5s, and it will automatically start debugging.   |
|  | 01             | ON                 | The master outdoor unit is automatically set by the system. 2s later, the next step “Address allocation” starts.   |
| 02_ Address allocation   | 02/Ad          | Display circularly | The system is allocating addresses. 10s later, it will display as below.   |
|  | 02/oC          | Display circularly | Address allocation is done. 2s later, the next step starts.  |
| 03_ ODU quantity confirmation                                  | 03/01          | Display circularly | The system is confirming. 2s later, the next step starts.  |
| 04_ Quantity confirmation                                      | 04/n           | Display circularly | “n” displays the quantity of indoor units identified by the system. The displayed quantity may be different from the actual quantity. Please check personally. If the actual quantity is different from the displayed one, power off the indoor and outdoor units, and check if the connection of IDU communication lines is faulted. After checking, connect power and start debugging from step 01. If the displayed quantity is correct, press the button SW3 on the main board in 30s to confirm it; if it is not confirmed within 30s, the system will automatically enter the next step. After confirmation, it will display as below. |
|  | 04/oC          | Display circularly | The quantity of indoor units has been confirmed. 2s later, the next step starts.   |
| 05_ Detection of ODU internal communication and capacity ratio | 05/C2<br>05/C3 | Display circularly | The main control of the outdoor unit cannot communicate normally with the drive. Please check whether the communication line connection between the outdoor unit main board and the drive board is normal, and proceed to the next step after troubleshooting. If the outdoor unit needs to be powered off during the troubleshooting process, restart debugging from step 01 after the unit is powered on.  |
|  | 05/oC          | Display circularly | The main control of the outdoor unit can communicate normally with the drive. Then the system will detect the capacity ratio of indoor and outdoor units. If the ratio is within range, the system will automatically enter the next step after 2s; if the capacity ratio is out of range, it will display as below.   |
|  | 05/CH          | Display circularly | The rated capacity ratio of indoor units is too high. Change the combination of indoor and outdoor units to make the capacity ratio within a reasonable range, and restart debugging from step 01.   |
|  | 05/CL          | Display circularly | The rated capacity ratio of indoor units is too low. Change the combination of indoor and outdoor units to make the capacity ratio within a reasonable range, and restart debugging from step 01.  |

| Description of each stage of debugging progress |                                      |                    |   |
|---|--------------------------------------|--------------------|---|
| —   | Debugging code                       |                    | Code meaning and operation method   |
| Progress  | LED                                  |                    |   |
|   | Code                                 | Display status     |   |
| 06_ Detection of ODU components                 | 06/<br>Corresponding error code      | Display circularly | Outdoor unit components are faulted. The corresponding error code flashes, except "06". After errors are eliminated, it will automatically enter the next step. If the outdoor unit needs to be powered off during the troubleshooting process, restart debugging from step 01 after the unit is powered on.  |
|   | 06/oC                                | Display circularly | The system detects no error on outdoor unit components. 10s later, the next step starts.  |
| 07_ Detection of IDU components                 | 07/XX/<br>Corresponding error code   | Display circularly | The system detects errors on indoor unit components. XX represents the project code of the faulty indoor unit. For example, when indoor unit No.01 has errors d5 and d6 and indoor unit No.03 has errors d6 and d7, the nixie tube circularly displays "07", "01", "d5", "d6", "03", "d6", "d7". After errors are eliminated, it will automatically enter the next step. If the outdoor unit needs to be powered off during the troubleshooting process, restart debugging from step 01 after the unit is powered on.   |
|   | 07/XXXX/<br>Corresponding error code | Display circularly | If errors occur to an indoor unit whose project code has 3 or more digits, the upper two digits of the project code will be displayed first, then the lower two digits and finally the error code. For example: If indoor unit No.101 has the error L1, the nixie tube will circularly display "01", "01", and "L1". If multiple errors occur to multiple indoor units, the display method is the same.   |
|   | 07/oC                                | Display circularly | There is no error on indoor unit components. 5s later, the next step starts.  |
| 08_ Compressor preheating confirmation          | 08/U0                                | Display circularly | The compressor is not sufficiently preheated. The nixie tube will keep displaying as shown on the left until the preheating time of the compressor reaches 8 hours. Pressing SW3 can skip the waiting time, and the system will enter the next step 2s later (Note: If the compressor is started when the preheating time is less than 8 hours, there is a risk of damage to the compressor, please be careful).  |
|   | 08/oC                                | Display circularly | If the outdoor unit has been continuously connected to power for a period of ≥8h, or the last time when the unit was continuously connected to power for a period of ≥8h is within 2 hours from the current time (a clock chip is required), it means compressor preheating is completed. 2s later, the next step starts.   |
| 09_ Refrigerant judgment before startup         | 09/U4                                | Display circularly | Refrigerant in the system is insufficient. In this case, startup is prohibited and buttons are all invalid. Please power off the indoor and outdoor units, and check whether there is leakage in the pipeline. After fixing the leakage problem, recharge the refrigerant as per the required amount. After recharging, re-energize the unit and start debugging again from step 01 (Note: The unit must be powered off before refrigerant charging. This is to prevent the unit from automatically entering the next step to start running during refrigerant charging). |
|   | 09/oC                                | Display circularly | The amount of refrigerant in the system is normal. 2s later, the next step starts.  |

| Description of each stage of debugging progress |                          |                    |  |
|---|--------------------------|--------------------|--|
| —   | Debugging code           |                    | Code meaning and operation method  |
| Progress  | LED                      |                    |  |
|   | Code                     | Display status     |  |
| 10_ Judgment of ODU valves before startup       | 10/on                    | Display circularly | Judgment on the valves of the outdoor unit is in progress. The compressor starts operation for about 2 minutes and then stops. The opening status of the big and small valves of the outdoor unit is judged as below.  |
|   | 10/U6                    | Display circularly | The valves of the outdoor unit are not fully opened. Press the button SW4 on the main board to display "09/oC", and then check whether the big and small valves of the outdoor unit are fully opened. After confirming, press the button SW4 on the main board again. Then the compressor will start operation for about 2 minutes to re-judge the valve status. |
|   | 10/oC                    | Display circularly | Valve status is normal and the display is as shown on the left. 2s later, the next step starts.  |
| 12_ Confirmation of debugging startup           | 12/AP                    | Display circularly | Wait for confirmation to start debugging. Press the button SW3 on the main board within 1 minute to confirm the start of debugging. If the user does not operate within 1 minute, it will be automatically confirmed. After confirmation, the main board indicator will display as below.  |
|   | 12/AE                    | Display circularly | Unit start-up is confirmed. After displaying for 2 seconds, the system starts debugging. If the project requires additional refrigerant charge but refrigerant is not complemented before debugging, then it can be added through the low-pressure service port during this process.   |
| 15_ Debugging                                   | 15/AC or 15/AH           | Display circularly | During the debugging process, if the system has been running for 50 minutes without an error, it is determined that the system is normal. After the whole system is shut down for 5s, it will enter standby mode.  |
|   | Corresponding error code | Display circularly | An error occurs during debugging.  |
| Debugging completed                             | oF                       | ON                 | The whole unit has finished debugging and the system is in standby mode.   |

**NOTE!**

In commissioning status and before the above commissioning processes are completed, when the SW1 up button and SW4 back button are pressed for over 5 seconds, the system enters non-wired-controller commissioning mode, and no longer detects the communication status between the wired controller and indoor units.

Once the debugging for the complete unit is finished, please set relevant functions for the unit according to the actual functional requirements of the project. Refer to relative technical materials for the detailed operation method. If there is no special requirement, skip this step directly.

When delivery it to the user for operation, explain the precautions to the user.

### 3.2.3 Unit Commissioning on Commissioning Software

**Step 1:** Install the commissioning software.

Install the commissioning software on a PC, and connect the monitoring communication cable. (For details, see Gree Debugger.)


**Step 2:** Power on the indoor and outdoor units.

Power on all indoor and outdoor units. In this case, all modules of the outdoor unit indicate that the unit is in "Not commissioning" status.




**Step 3:** Switch the commissioning software to the commissioning control interface.

Click "Debug" to switch to the engineering commissioning interface. The unit will automatically operate the commissioning modules listed in this interface from top to bottom and from left to right. Note: The commissioning function only applies to the single-system network.




**Step 4:** Click "Start" to enter the commissioning function

Click "Start" to enter the commissioning function and the software automatically performs commissioning. "🟡" indicates that commissioning is being performed on the phase and "🟢" indicates that commissioning is passed on the phase.




For the phase with "OK" displayed, a manual confirmation is required for entering the next commissioning step. In processes "3 Confirm number of outdoor basic modules" and "4 Confirm the number of IDUs", if the number of online units is consistent with the actual number, click Confirm or wait for 30 seconds to go to the next process. If the displayed number of online units is inconsistent with the actual number in the project, manual check and commissioning again are required for confirmation. Click "!" to display relevant information detected on this phase, which provides references for selection. Click "Close" to close the information (the number of commissioning units is displayed in "3 Confirm number of outdoor basic modules" and "4 Confirm the number of IDUs", as shown in the red boxes in the figure below.)






In step "8 Compressor preheating confirmation", the current preheat time is directly displayed, as



shown in the red box in the figure below. If the system currently detects that all the basic modules have been continuously powered on for 8 hours or more, or the previous time when the modules were powered on for 8 hours or more is less than 8 hours from the current time, preheat is completed and the system can proceed to the next process. Otherwise, the system prompts UO (insufficient compressor preheat time).




"" indicates that commissioning is not passed on the phase and troubleshooting is required (after troubleshooting, the unit automatically enters the next step if no "OK" exists or click "OK" to enter the next step). Click "" to display relevant information detected on this phase, which provides references for troubleshooting. Click "Close" to close the information.




During commissioning, click "Stop" to stop commissioning and then click "Start" to continue commissioning till commissioning ends. "Back" and "Skip" are provided in "10 ODU valves check before startup". When an exception occurs in step 10, click "Back" to return to step 9 and then click "OK" in step


9 to perform commissioning again for step 10. If a U6 fault (valve exception) occurs in step 10, users can click "Skip" to skip the fault. For other faults, "Skip" is unavailable.



The system automatically enters the stage of confirming the unit start-up and commissioning, with LEDs cyclically displaying "12" and "AP", waiting for confirmation of the unit start-up and commissioning command, and pressing the SW3 confirmation key to confirm the unit start-up and commissioning.



The system automatically enters the unit filling operation stage with "15" and "AE" displayed on the LED cycle. The system automatically selects the commissioning operation mode according to the [average indoor ambient temperature in the system], and the system enters the normal standby state after the engineering commissioning is completed.

**NOTE:**

During commissioning, users must listen to the operating sound of outdoor and indoor fans and compressors to check for exceptions.


### 3.2.4 Unit Commissioning by Using Multi-functional Debugger

**Step 1:** Connect multi-functional debugger. For details, see the user manual of multi-functional debugger.

**Step 2:** Click **Unit Debug** on the home page to enter the commissioning page.



**Step 3:** On the commissioning page, click **Startup** to start commissioning or click **Stoppage** to stop commissioning.



**Step 4:** During commissioning, multi-functional debugger shows the current process (step). In steps 3, 4, 8, and 12, click Confirm to go to the next step. In step 10, click Skip or Back. In steps 3, 4, 5, 6, and 7, you can view the details.

**Step 5:** After the commissioning, the outdoor unit displays "OF" (or a fault, if any, or "on" when the unit is started up).

**Warning:**

After the product is used, the cable connection of the air-conditioner unit must be recovered. Otherwise, the actual use will be affected.

### **3.2.5 After Commissioning**

Organize and save the data. Make complete and detailed records of exceptions and corresponding solutions in the commissioning process for future maintenance and query. Finally, export the commissioning report and hand it over to the user.

After the commissioning, instruct the user of the following precautions:

When the outdoor unit is continuously powered off for more than 24 hours, it must be warmed up for at least 8 hours to avoid damage to the compressor.


### 3.2.6 Reference Values of Unit Normal Operation Parameters (Commissioning Check)

| No. | Debug item        |                | Parameter name                   | Unit   | Reference   |
|-----|-------------------|----------------|----------------------------------|--------|---|
| 1   | System parameters | ODU parameters | Outdoor temperature              | °C(°F) | —   |
| 2   |                   |                | Compressor discharge temperature | °C(°F) | <ul style="list-style-type: none"> <li>When compressor starts, discharge temp in cool mode is within 70~105°C(158~221°F) and at least 10°C(50°F) higher than the high pressure saturation temperature.</li> <li>As for temp in heat mode, it is within 65~90°C(149~194°F) and at least 10°C(50°F) higher than the high pressure saturation temperature.</li> </ul>  |
| 3   |                   |                | Defrosting temperature           | °C(°F) | <ul style="list-style-type: none"> <li>In cool mode, defrosting temperature is 4~10°C(39~50°F) lower than system's high pressure value.</li> <li>In heat mode, defrosting temperature is about 2°C(36°F) different from system's low pressure value.</li> </ul>   |
| 4   |                   |                | System high pressure             | °C(°F) | <ul style="list-style-type: none"> <li>In cool mode, the normal high pressure value is within 20~55°C(68~131°F). According to the change of ambient temperature and system's operating capacity, the high pressure value will be 10~30°C(50~86°F) higher than ambient temperature. The higher ambient temperature is, the smaller temperature difference is. If ambient temp is 25~35°C(77~95°F) in cool mode, system's high pressure value will be within 44~53°C(111~127°F).</li> <li>In heat mode, if ambient temperature is above -5°C(23°F), system's high pressure value is within 40~52°C(104~126°F). If ambient temperature is low and many IDUs are turned on, the high pressure will be lower.</li> </ul> |
| 5   |                   |                | System low pressure              | °C(°F) | <ul style="list-style-type: none"> <li>When ambient temperature in cool mode is 25~35°C(77~95°F), the low pressure value is 0~8°C(32~46°F).</li> <li>When ambient temperature in heat mode is above -5°C(23°F), the low pressure value is -15~8°C(5~46°F).</li> </ul>   |
| 6   |                   |                | Opening degree of thermal EXV    | PLS    | <ul style="list-style-type: none"> <li>In cool mode, the thermal electronic expansion valve remains 480PLS.</li> <li>In heat mode, the adjustable opening degree of EXV is 60~480PLS.</li> </ul>  |
| 7   |                   |                | Compressor's operating frequency | Hz     | Changes in 15Hz~120Hz.  |
| 8   |                   |                | Compressor's operating current   | A      | When compressor works normally, the current is no more than 18A.  |
| 9   |                   |                | Compressor's IPM temperature     | °C(°F) | When ambient temperature is below 35°C(95°F), IPM temp is lower than 80°C(176°F) and the highest temperature won't be above 95°C(203°F).  |

| No. | Debug item               |                | Parameter name                            | Unit   | Reference   |
|-----|--------------------------|----------------|---|--------|---|
| 10  | System parameters        | ODU parameters | Fan motor's operating frequency           | Hz     | Changes in 0~50Hz according to system's pressure.   |
| 11  | System parameters        | IDU parameters | IDU ambient temperature                   | °C(°F) | —   |
| 12  |                          |                | Indoor heat exchanger's inlet temperature | °C(°F) | <ul style="list-style-type: none"><li>● According to ambient temperature, for a same IDU in cool mode, the inlet temp will be 1~7°C(34~45°F) lower than the outlet temperature, and 4~9°C(39~48°F) higher than the low pressure value.</li><li>● For a same IDU in heat mode, the inlet temperature will be 10~20°C(50~68°F) lower than the outlet temperature.</li></ul> |
| 13  |                          |                | Opening degree of indoor EXV              | PLS    | <ul style="list-style-type: none"><li>● In cool mode, the opening degree of indoor EXV varies within 50~480PLS.</li><li>● In heat mode, the opening degree of indoor EXV varies within 35~480PLS.</li></ul>   |
| 14  | Communication parameters |                | Communication data                        | —      | Number of IDUs detected by software is the same with the actual number. No communication error.   |
| 15  | Drainage system          |                | —   | —      | Indoor unit can drain water out completely and smoothly. Condensate pipe has no backward slope of water; Water of outdoor unit can be drained completely through drainage pipe. No water drop from unit base.   |
| 16  | Others                   |                | —   | —      | Compressor and indoor/outdoor fan motor do not have strange noise. Unit can operate normally.   |

## 4 Unit Function Settings

### 4.1 DIP Switch Settings



| Code         | Name                                       | Meaning   | Default Setting        | Remarks  |
|--------------|--|---|------------------------|--|
| SA1_capacity | Capacity DIP switch                        | Defines the rated capacity of the unit.   | Depending on the model | The DIP switch is set by the factory and cannot be changed.  |
| SA2_Addr-CC  | Address DIP switch for centralized control | Defines and distinguishes addresses of different systems for centralized control of multiple systems. | 00000                  | The code is used only for centralized control. Otherwise, keep the default setting. This address can be set only on the master unit. |



#### NOTES!

- ① The function DIP switches must be set when the outdoor unit is powered off. A DIP switch setting takes effect after the unit is re-powered on.
- ② SA1 DIP switch cannot be changed. The default settings of other DIP switches do not need to be changed if there are no special requirements.

#### 4.1.1 Unit Capacity DIP Switch (SA1\_capacity)

This DIP switch is set by the factory before shipment, and cannot be changed. Otherwise, the system will work abnormally and even damage the compressor.

#### 4.1.2 Address DIP Switch for Centralized Control (SA2\_Addr-CC)

This DIP switch indicates the address for centralized control of different refrigerating systems. It is set to 0000× by default.

If centralized control is not required between multiple refrigerating systems, keep the default setting of this DIP switch.

If centralized control is required between multiple refrigerating systems, set as follows:

- (1) Be sure to set the DIP switch on the master unit.
- (2) Setting this DIP switch on non-master units in a refrigerating system is invalid and unnecessary.
- (3) Be sure to set the address DIP switch for centralized control (SA2\_Addr-CC) on the master unit of a refrigerating system to "0000x". Then, this system is the main system.
- (4) Set the address DIP switch for centralized control (SA2\_Addr-CC) on the master units of other refrigerating systems as follows:

| SA2  |      |      |      |      | Address No. |
|------|------|------|------|------|-------------|
| DIP1 | DIP2 | DIP3 | DIP4 | DIP5 |             |
| 1    | 0    | 0    | 0    | ×    | 2           |
| 0    | 1    | 0    | 0    | ×    | 3           |

| SA2  |      |      |      |      | Address No. |
|------|------|------|------|------|-------------|
| DIP1 | DIP2 | DIP3 | DIP4 | DIP5 |             |
| 1    | 1    | 0    | 0    | ×    | 4           |
| 0    | 0    | 1    | 0    | ×    | 5           |
| 1    | 0    | 1    | 0    | ×    | 6           |
| 0    | 1    | 1    | 0    | ×    | 7           |
| 1    | 1    | 1    | 0    | ×    | 8           |
| 0    | 0    | 0    | 1    | ×    | 9           |
| 1    | 0    | 0    | 1    | ×    | 10          |
| 0    | 1    | 0    | 1    | ×    | 11          |
| 1    | 1    | 0    | 1    | ×    | 12          |
| 0    | 0    | 1    | 1    | ×    | 13          |
| 1    | 0    | 1    | 1    | ×    | 14          |
| 0    | 1    | 1    | 1    | ×    | 15          |
| 1    | 1    | 1    | 1    | ×    | 16          |


**NOTE:**

- ① DIP switch at the ON end indicates 0;
- ② DIP switch at the other end indicates 1;
- ③ × indicates invalid.
- (5) This DIP switch of different refrigerating systems cannot be set the same. Otherwise, an address conflict will occur and the unit will not operate.

### 4.1.3 DIP switch position description

DIP switch at the ON end indicates 0; DIP switch at the other end indicates 1.

The white lever is DIP switch position.




## 4.2 System Function Operations

**CAUTIONS!**

- ① System function settings and queries must be performed after the entire system is commissioned.
- ② System function settings and queries can be performed regardless of whether the entire system is running or not.

### 4.2.1 Function Buttons

There are four function buttons on the main board of the outdoor unit, as shown below:





| Names and Functions of the Buttons |         |                                    |
|------------------------------------|---------|------------------------------------|
| Button No.                         | Code    | Function                           |
| SW1                                | Up      | Selects the upper item.            |
| SW2                                | Down    | Selects the lower item.            |
| SW3                                | Confirm | Confirms the selection.            |
| SW4                                | Back    | Returns to the previous operation. |

## 4.2.2 Function Description

| Function Code | Function Name                        | Description   | Default Setting |                             | Remarks                               |
|---------------|--------------------------------------|---|-----------------|-----------------------------|---------------------------------------|
|               |                                      |   | Code            | Meaning                     |                                       |
| A2            | Refrigerant recycle                  | This function is automatically started during maintenance. Based on the system pressure change, this function recycles all or partial refrigerant of the faulty module or the indoor unit pipeline. | —               | —                           | This function can only be set.        |
| A6            | Cooling/heating of the entire system | The unit can be set to cooling and heating, cooling only, heating only, or fan mode for centralized management.   | nA              | Cooling and heating         | This function can be set and queried. |
| A7            | Outdoor silence mode                 | This function sets different silence modes based on the user's needs.   | 00              | No silence                  | This function can be set and queried. |
| A8            | After-sales vacuum pumping mode      | During maintenance, the system automatically turns on all electronic expansion valves and solenoid valves to ensure that all lines can be vacuumed.   | —               | —                           | This function can only be set.        |
| n0            | Auto energy saving                   | This function can automatically reduce power consumption of the unit based on system operating parameters.  | 01              | Capability priority control | This function can be set and queried. |
| n3            | Forced defrosting                    | This function forcibly enables defrosting of the outdoor unit of the system.  | —               | —                           | This function can only be set.        |
| n4            | Forced energy saving                 | This function forcibly reduces the maximum power consumption of the unit.   | 10              | 100% capability output      | This function can be set and queried. |
| n5            | Indoor unit engineering SN offset    | When different refrigerating systems are controlled in a centralized manner, this function avoids the conflict of indoor unit engineering numbers.  | —               | —                           | This function can only be set.        |
| C9            | Fan emergency setting                | —   | 00              | Normal operation of the fan | —                                     |

## 4.2.3 Function Operations

Before setting every function, perform the following steps to select the function you want to set. The following premise steps will not be repeated.

Premise steps for function setting:

**Step 1:** Power on the entire system.

**Step 2:** Press and hold the SW1 up button on the unit for over 5 seconds. The system enters the function setting status. The unit displays as follows by default.

| LED1          |                |
|---------------|----------------|
| Function code | Display status |
| A7            | Blinks         |

Press the SW1 up button and the SW2 down button on the unit to select the corresponding function/parameter:

| LED1          |                | Function Name                        |
|---------------|----------------|--------------------------------------|
| Function code | Display status |                                      |
| A7            | Blinks         | Outdoor unit silence                 |
| A6            | Blinks         | Cooling/heating of the entire system |
| A2            | Blinks         | Refrigerant recycle                  |
| A8            | Blinks         | After-sales vacuum pumping           |
| n0            | Blinks         | Auto energy saving                   |
| n3            | Blinks         | Forced defrosting                    |
| n4            | Blinks         | Forced energy saving                 |
| n5            | Blinks         | Indoor unit engineering SN offset    |
| C9            | Blinks         | Fan emergency setting                |

After selecting the function to be set, press the SW3 confirm button to enter the function setting. The unit displays as follows:

| Display step1 |                | Display step2   |                | Function Name                        |
|---------------|----------------|-----------------|----------------|--------------------------------------|
| LED1          |                | LED1            |                |                                      |
| Function code | Display status | Current process | Display status |                                      |
| A7            | Blinks         | 00              | Blinks         | Outdoor unit silence                 |
| A6            | Blinks         | 00              | Blinks         | Cooling/heating of the entire system |
| A2            | Blinks         | 00              | Blinks         | Refrigerant recycle                  |
| A8            | Blinks         | 00              | On             | After-sales vacuum pumping           |
| n0            | Blinks         | 01              | Blinks         | Auto energy saving                   |
| n3            | Blinks         | 00              | On             | Forced defrosting                    |
| n4            | Blinks         | 00              | Blinks         | Forced energy saving                 |
| n5            | Blinks         | 00              | On             | Indoor unit engineering SN offset    |
| C9            | Blinks         | 00              | Blinks         | Fan emergency setting                |

Then, set the function/parameter accordingly.

After entering the function/parameter setting status, press the SW4 back button to return to the previous process or exit the function setting status. If you do not press any button in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

#### 4.2.3.1 "A2" Refrigerant Recycle

##### Introduction:

This function is mainly used to recycle some refrigerant in the fault module and indoor unit pipeline during unit maintenance. The table below lists the maximum amount of refrigerant that can be recycled:

After entering refrigerant recycle, the outdoor unit automatically starts, and recycles the refrigerant to the pipeline of the outdoor unit or indoor unit.

**Setting steps:**

**Step 1:** Enter A2 refrigerant recycle, and ensure that the outdoor unit displays as follows:

| LED1            |                |
|-----------------|----------------|
| Current process | Display status |
| 01              | Blinks         |

**Step 2:** When the default value 01 is displayed, press the SW1 up button and the SW2 down button to select the corresponding recycle mode. Press SW3 to confirm the selected mode.

Press the SW4 back button on the master module to return to the previous process or exit the function setting status.

If you do not press any button in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

**Indoor unit pipeline refrigerant recycle:**

**Step 3:** Select 01 in step 2 to enter indoor unit pipeline refrigerant recycle. The LED1 of outdoor unit display as follows:

| LED1                     |                |
|--------------------------|----------------|
| Current status           | Display status |
| [Module low pressure Ps] | On             |

LED1 shows the low pressure value of the module. If it is negative, LED1 circularly displays negative value code "nE" and the numerical value every 1 second. For example, for -30, LED3 circularly displays nE for 1 second, and 30.

**Step 4:** When the system prompts for manual operation of refrigerant recycle, press SW3 on the master unit to confirm refrigerant recycle. The entire system will stop immediately, and cannot be restarted in 10 minutes. After 10 minutes, the system will exit refrigerant recycle, and enter standby status.

Then, press the SW4 back button to return to the previous process to resume the standby status of the entire system. (During setting, press SW4 to return to the previous process. If the setting is completed, press SW4 to resume the unit to the current normal working status.)

**NOTE:**

After refrigerant recycle, the system cannot be restarted within 10 minutes.

#### 4.2.3.2 "A6" Cooling/Heating of the Entire System

**Introduction:**

This function sets the cooling/heating mode of the entire system. Available modes include:

| Outdoor Unit Function Mode |                     | Available Indoor Unit Operation Modes  |
|----------------------------|---------------------|--|
| Code                       | Name                |  |
| nA                         | Cooling and heating | Cooling, dry, heating, and fan<br>(Note: Heating mode cannot run with other modes at the same time.) (Default setting) |
| nC                         | Cooling only        | Cooling, dry, and fan  |
| nH                         | Heating only        | Heating and fan<br>(Note: Heating mode cannot run with other modes at the same time.)                                  |
| nF                         | Fan                 | Fan  |

The user or administrator needs to set the mode of the outdoor unit based on the actual usage to avoid conflicts.

**Setting steps:**

**Step 1:** Enter A6 cooling/heating setting of the entire system, and ensure that the outdoor unit displays as follows:

| LED1            |                |
|-----------------|----------------|
| Current process | Display status |
| nC              | Blinks         |

**Step 2:** Press the SW1 up button and the SW2 down button to select the corresponding cooling/heating mode.

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| nC                   | Blinks         |
| nH                   | Blinks         |
| nA                   | Blinks         |
| nF                   | Blinks         |

**Step 3:** After selecting the mode, press the SW3 confirm button. The outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| nC                   | On             |
| nH                   | On             |
| nA                   | On             |
| nF                   | On             |

Press the SW4 back button on the outdoor unit to return to the previous process or exit the function setting status.

The outdoor unit memorizes this setting and does not clear it even upon power failure and power-on again. The default value is nA cooling and heating mode.

#### 4.2.3.3 A7 Outdoor Silence Mode

**Introduction:**

This function is mainly used in scenarios where the user requires low ambient noise. Smart night silence mode and forced silence mode are available.

In smart night silence mode, need to set timer of outdoor units.

to ensure low-noise operation at night. Smart night silence mode has nine options:

| Silence Mode | Code |
|--------------|------|
| Mode 1       | 01   |
| Mode 2       | 02   |
| Mode 3       | 03   |
| Mode 4       | 04   |
| Mode 5       | 05   |
| Mode 6       | 06   |
| Mode 7       | 07   |
| Mode 8       | 08   |
| Mode 9       | 09   |

**NOTE:**

In forced silence mode, the system operates in low-noise mode regardless of day or night. This mode has three options:

| Silence Mode | Code |
|--------------|------|
| Mode 10      | 10   |
| Mode 11      | 11   |
| Mode 12      | 12   |
| Mode 13      | 13   |

**NOTE:**

After a silence mode is set, the system capability will be attenuated. Therefore, the noise and the capability need to be balanced when a silence mode is selected.

No silence is set by default, that is, "00" status.

**Setting steps:**

**Step 1:** Enter A7 outdoor silence mode, and ensure that the master module displays as follows:

| LED1              |                |
|-------------------|----------------|
| Silence mode code | Display status |
| 00                | Blinks         |

**Step 2:** Press the SW1 up button and the SW2 down button to select the corresponding silence mode.

| LED1              |                |
|-------------------|----------------|
| Silence mode code | Display status |
| 00                | Blinks         |
| 01                | Blinks         |
| 02                | Blinks         |
| 03                | Blinks         |
| 04                | Blinks         |
| 05                | Blinks         |
| 06                | Blinks         |
| 07                | Blinks         |
| 08                | Blinks         |
| 09                | Blinks         |
| 10                | Blinks         |
| 11                | Blinks         |
| 12                | Blinks         |
| 13                | Blinks         |

**Step 3:** After selecting the corresponding silence mode, press the SW3 confirm button. The outdoor unit displays as follows:

| LED1              |                |
|-------------------|----------------|
| Silence mode code | Display status |
| 00                | On             |
| 01                | On             |
| 02                | On             |
| 03                | On             |
| 04                | On             |
| 05                | On             |
| 06                | On             |
| 07                | On             |
| 08                | On             |
| 09                | On             |

| LED1              |                |
|-------------------|----------------|
| Silence mode code | Display status |
| 10                | On             |
| 11                | On             |
| 12                | On             |
| 13                | On             |

Press the SW4 back button on the master module to return to the previous process or exit the function setting status.

The default status is 00, that is, no silence.

#### 4.2.3.4 A8 After-Sales Vacuum Pumping Mode

##### Introduction:

This function is used to ensure the vacuum of the entire system during maintenance and to avoid dead pipeline zones. When this function is set, both the expansion valve and the solenoid valve of the unit will open.

##### Setting steps:

**Step 1:** Enter A8 after-sales vacuum pumping mode, and ensure that the master module displays as follows:

| LED1            |                |
|-----------------|----------------|
| Current process | Display status |
| 00              | Blinks         |

The system enters the to-be-confirmed status of vacuum pumping mode.

**Step 2:** Press the SW3 button. The system enters the confirmed status of vacuum pumping mode and all modules display as follows:

| LED1          |                |
|---------------|----------------|
| Function code | Display status |
| A8            | On             |

At this time, the expansion valves of all indoor and outdoor units are open, and the entire system cannot be started.

When you press the SW4 back button on the master unit for over 5 seconds or the vacuum pumping status remains for 24 hours, the entire system exits the status.

#### 4.2.3.5 n0 Auto Energy Saving

##### Introduction:

This function sets the user-required energy saving mode. The default mode is capability priority control.

After energy saving mode is set, the system capability will deteriorate.

| Code | Function Name                                 |
|------|---|
| 01   | Capability priority control (default setting) |
| 02   | Energy saving priority control                |

**Setting steps:**

**Step 1:** Enter n0 system energy saving operation, and ensure that the outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 01                   | Blinks         |

**Step 2:** Press the SW1 up button and the SW2 down button to select the corresponding mode.

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 01                   | Blinks         |
| 02                   | Blinks         |

**Step 3:** After selecting the mode, press the SW3 confirm button. The outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 01                   | On             |
| 02                   | On             |

If you do not press any button on the outdoor unit in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status. (During setting, press SW4 to return to the previous process. If the setting is completed, press SW4 to resume the unit to the current normal working status.)

#### 4.2.3.6 n3 Forced Defrosting

**Introduction:**

This function is used when forced defrosting is required during unit maintenance. After entering forced defrosting, the system automatically exits according to the exit conditions, and then automatically runs according to the system conditions.

**Setting steps:**

**Step 1:** Enter n3 forced defrosting, and ensure that the outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 00                   | Blinks         |

**Step 2:** Press the SW3 confirm button. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function code | Display status |
| n3            | On             |

If the defrosting condition is not met, the outdoor unit the set mode. If the setting is completed, press SW4 to resume the unit to the current normal working status.

When the defrosting exit condition is met, the system automatically exits and resumes normal running control.

#### 4.2.3.7 n4 Forced Energy Saving Mode

##### Introduction:

The maximum output capability limit is used in scenarios where the user needs to forcibly limit the system power consumption. Available functions are as follows:

| Code | Maximum Output Capability |
|------|---------------------------|
| 10   | 100% (default setting)    |
| 09   | 90%                       |
| 08   | 80%                       |

##### NOTE:

After the capability limit is set, the cooling or heating effect is correspondingly reduced.

##### Setting steps:

**Step 1:** Enter n4 maximum output capability limit setting, and ensure that the outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 10 or 09 or 08       | Blinks         |

**Step 2:** Press the SW1 up button and the SW2 down button to select the corresponding value.

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 10                   | Blinks         |
| 09                   | Blinks         |
| 08                   | Blinks         |

**Step 3:** After selecting the value, press the SW3 confirm button. The outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 10                   | On             |
| 09                   | On             |
| 08                   | On             |

If you do not press any button on the outdoor unit in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status. (During setting, press SW4 to return to the previous process. If the setting is completed, press SW4 to resume the unit to the current normal working status.)

#### 4.2.3.8 n5 Indoor Unit Engineering SN Offset

##### Introduction:

When different refrigerating systems are controlled in a centralized manner (by remote monitoring or a centralized controller), this function sets the engineering numbers of indoor units and avoids their conflict among different systems, and therefore must be set.

Set this function only in the master system, whose centralized control address SA2 is "0000×". For details, see the settings in section "Address DIP Switch for Centralized Control (SA2\_Addr-CC)".



**Setting steps:**

**Step 1:** Enter n5 indoor unit engineering SN offset, and ensure that the outdoor unit displays as follows:

| LED1                 |                |
|----------------------|----------------|
| Current process/mode | Display status |
| 00                   | Blinks         |

**Step 2:** Press the SW3 confirm button to send the engineering number offset instruction. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function code | Display status |
| n5            | On             |

After 10s, the system exits the mode and enters normal working.

#### 4.2.3.9 C9 Fan Failure Emergency Operation

This function is after-sales emergency setting when a fan on a dual-fan module works abnormally. It shields the abnormal fan in a short time to ensure the emergency operation of the system.

**Setting steps:**

Enter the function setting on the main board of the faulty outdoor unit. The outdoor unit displays as follows:

| LED1            |                |
|-----------------|----------------|
| Current process | Display status |
| 00              | Blinks         |

Press the SW1 up button and the SW2 down button to select the corresponding fan emergency operation status.

| LED1            |                | Description                         |
|-----------------|----------------|-------------------------------------|
| Current process | Display status |                                     |
| 00              | Blinks         | Fans 1 and 2 run normally.          |
| 01              | Blinks         | The operation of fan 1 is shielded. |
| 02              | Blinks         | The operation of fan 2 is shielded. |

After selecting the corresponding value, press the SW3 confirm button. outdoor unit display as follows:

| LED1 |                |
|------|----------------|
| Mode | Display status |
| 00   | On             |
| 01   | On             |
| 02   | On             |

The outdoor unit memorizes this setting and does not clear it even upon power failure and power-on again. The default value is 00.

Then, press the SW4 back button to return to the previous process. (During setting, press SW4 to return to the previous process. If the setting is completed, press SW4 to resume the unit to the current normal working status)

If you do not press any button in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.



### NOTES!

- ① This function is applicable only to dual-fan models;
- ② A module can set only one fan to emergency mode;
- ③ The default status is 00.
- ④ The system cannot run continuously for more than 120 hours in fan emergency operation status. If it exceeds 120 hours, the entire system is stopped, and the indoor unit displays the limit operation code.

## 4.2.4 Outdoor Unit Status Query

The following functions can be queried:

| Function Code | Function Name                    |
|---------------|----------------------------------|
| n6            | Fault query                      |
| n7            | Parameter query                  |
| n8            | Indoor unit engineering SN query |
| n9            | Online indoor unit qty query     |
| nb            | Outdoor unit barcode query       |

After the unit is powered, you can query the function setting status, historical fault record, indoor unit engineering number and real-time parameter of the unit in any status. The query method is as follows:

On the master unit, press and hold the SW2 down button for over 5 seconds. The master unit displays the current function setting status, and other modules display based on their current status. Press the SW1 up button and the SW2 down button on the master unit to select the corresponding query. The default selection is A6.

In function query status, if there are two levels of menus, you can press the SW4 back button to return to the previous level. Press the SW4 query button again to exit query status.

In function query status, if you do not press any button on the master unit in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

### 4.2.4.1 n6 Fault Query

Press the SW1 up button and the SW2 down button to select fault query. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| n6            | Blinks         |

Press the SW3 confirm button on the outdoor unit to confirm the selection.

#### Introduction:

This function is used to query historical faults in the system. Up to five historical faults can be stored in the order of time.

#### Operations:

In fault query status, press the SW1 up button and the SW2 down button. LED1 circularly displays

the code and address of the faulty module in history in the order of time (at an interval of 1s),. If there is no historical fault, LED1 display "00" by default. Up to five latest historical faults can be queried. Faults that can be stored and queried are as follows:

|    |   |    |   |
|----|---|----|---|
| 1  | High pressure protection  | 20 | Inverter compressor over-current protection   |
| 2  | Low pressure protection   | 21 | Current detection circuit fault of the inverter compressor driver                   |
| 3  | Lack-of-refrigerant protection  | 22 | Loss of synchronization protection for the inverter compressor                      |
| 4  | Air discharge low temperature protection                              | 23 | Communication fault between the primary controller and inverter compressor driver   |
| 5  | Over low pressure ratio protection                                    | 24 | Over temperature protection for the inverter compressor driver module.              |
| 6  | Over high pressure ratio protection                                   | 25 | Temperature sensor fault of the inverter compressor driver module.                  |
| 7  | Four-way valve air backflow protection                                | 26 | Charging loop fault of the inverter compressor driver.                              |
| 8  | High pressure low protection  | 27 | Under voltage protection for DC bus of the inverter outdoor fan driver              |
| 9  | High temperature protection for compressor 1                          | 28 | Over voltage protection for DC bus of the inverter outdoor fan driver               |
| 10 | High temperature protection for compressor 2                          | 29 | IPM module protection for the inverter outdoor fan driver.                          |
| 11 | Compressor 2 over-current protection                                  | 30 | Inverter outdoor fan startup failure.   |
| 12 | Shell roof high temperature protection for compressor 1               | 31 | Inverter outdoor fan phase loss protection.   |
| 13 | Shell roof high temperature protection for compressor 2               | 32 | Inverter outdoor fan driver module reset.   |
| 14 | Under voltage protection for the DC bus of inverter compressor driver | 33 | Inverter outdoor fan over-current protection.                                       |
| 15 | Over voltage protection for DC bus of the inverter compressor driver. | 34 | Current detection circuit fault of the inverter outdoor fan driver.                 |
| 16 | IPM module protection for the inverter compressor driver.             | 35 | Loss of synchronization protection for the inverter outdoor fan.                    |
| 17 | Inverter compressor startup failure                                   | 36 | Communication fault between the primary controller and inverter outdoor fan driver. |
| 18 | Inverter compressor phase loss protection.                            | 37 | Over temperature protection for the inverter outdoor fan driver module.             |
| 19 | Inverter compressor driver module reset.                              | 38 | Temperature sensor fault of the inverter outdoor fan driver module.                 |

The figure below shows the Debug page.

| LED1                            |                |
|---------------------------------|----------------|
| Current status                  | Display status |
| Historical fault/module address | Alternated     |
|                                 | Alternated     |
|                                 | Alternated     |
|                                 | Alternated     |
|                                 | Alternated     |

If historical faults are less than five, after the last fault is displayed, LED1 display 00, indicating no more fault.

In fault query status, press and hold the SW3 confirm button for over 5 seconds to clear all historical faults of the outdoor unit.

#### 4.2.4.2 n7 Parameter Query

Press the SW1 up button and the SW2 down button to select parameter query. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| n7            | Blinks         |

Press the SW3 confirm button on the outdoor unit to confirm the selection.

##### Introduction:

This function is used to query running parameters of each module of the outdoor unit in real time.

##### Operations:

In parameter query status, the outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| n7            | On             |

Press the SW1 up button and the SW2 down button to select the corresponding query module, and press the SW3 confirm button. The unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| module        | On             |

LED1 displays the module parameter code and the specific value. The parameters and display sequence are listed below. "Outdoor ambient temperature (master module)" is displayed by default. Press the SW1 up button and the SW2 down button to select the corresponding query parameter value.

| Parameter Code | Parameter Name                         | Remarks   |
|----------------|--|---|
| 01             | Outdoor ambient temperature            | Outdoor ambient temperature of the outdoor unit is used.            |
| 02             | Operating frequency of compressor 1    | —   |
| 03             | Operating frequency of compressor 2    | —   |
| 04             | Operating frequency of the outdoor fan | Operating frequency of outdoor fan 1 is used.                       |
| 05             | Module high pressure                   | Temperature value corresponding to the pressure                     |
| 06             | Module low pressure                    | Temperature value corresponding to the pressure                     |
| 07             | Discharge temperature of compressor 1  | The air discharge pipe temperature is used.                         |
| 08             | Discharge temperature of compressor 2  | The air discharge pipe temperature is used.                         |
| 09             | Discharge temperature of compressor 3  | —   |
| 10             | Discharge temperature of compressor 4  | —   |
| 11             | Discharge temperature of compressor 5  | —   |
| 12             | Discharge temperature of compressor 6  | —   |
| 13             | Operating frequency of compressor 3    | —   |
| 14             | Current of compressor 1                | The integer value is used, and the wired controller does not query. |
| 15             | Current of compressor 2                | The integer value is used, and the wired controller does not query. |
| 16             | Current of compressor 3                | The integer value is used, and the wired controller does not query. |
| 17             | Current of compressor 4                | The integer value is used, and the wired controller does not query. |
| 18             | Current of compressor 5                | The integer value is used, and the wired controller does not query. |

| Parameter Code | Parameter Name                           | Remarks   |
|----------------|--|---|
| 19             | Current of compressor 6                  | The integer value is used, and the wired controller does not query.         |
| 20             | Reserved                                 | —   |
| 21             | Module temperature of compressor 1       | The wired controller does not query.  |
| 22             | Module temperature of compressor 2       | The wired controller does not query.  |
| 23             | Module temperature of outdoor fan 1      | The wired controller does not query.  |
| 24             | Module temperature of outdoor fan 2      | The wired controller does not query.  |
| 25             | Outdoor unit heating EEV 1               | The displayed value is the integer value of the actual value divided by 10. |
| 26             | Outdoor unit heating EEV 2               | The displayed value is the integer value of the actual value divided by 10. |
| 27             | Subcooler EEV                            | The displayed value is the integer value of the actual value divided by 10. |
| 28             | Defrost temperature                      | Defrost temperature 1 is used.  |
| 29             | Subcooler's liquid outlet temperature    | —   |
| 30             | Outlet temperature of accumulator        | —   |
| 31             | Oil return temperature                   | —   |
| 32             | Inlet pipe temperature of the condenser  | —   |
| 33             | Outlet pipe temperature of the condenser | —   |

**NOTE:**

If a parameter value is negative, LED1 circularly displays negative value code "nE" and the numerical value every 1 second. For example, for -30, LED1 circularly displays nE for 1 second, and 30.

Discharge temperature and ambient temperature values are in four digits. The LED1 circularly displays the left two digits and then the right two digits. For example, 01 and 15 indicate 115 degrees, while nE, 00, and 28 indicate -28 degrees.

If a parameter is invalid on the unit, value "00" is displayed.

If there are two levels of menus on the outdoor unit, you can press the SW4 back button to return to the previous level. Press the SW4 query button again to exit query status.

If you do not press any button on the master unit in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

#### 4.2.4.3 n8 Indoor Unit Engineering SN Query

**Introduction:**

This function makes all indoor units display their SN respectively by performing an operation on the outdoor unit, facilitating indoor unit address query.

**Operations:**

Press the SW1 up button and the SW2 down button to select indoor unit engineering SN query. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| n8            | Blinks         |

Press the SW3 confirm button on the outdoor unit to confirm the selection. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| n8 or 00      | On             |

At this time, regardless of the current display status of all indoor unit wired controllers or display panels, all of them switch to display the engineering number of the internal unit, without affecting the setting and operation status of the indoor units and the outdoor unit.

Press the SW4 back button on the outdoor unit to return to the upper operation level, but the indoor units remains displaying the engineering numbers.

Press and hold the SW4 back button on the master unit for over 5 seconds to make all indoor units exit displaying the engineering numbers and return to the upper operation level.

If you do not press any button on the master unit to exit indoor unit engineering SN query in 30 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

#### 4.2.4.4 n9 Online Indoor Unit Qty Query

##### **Introduction:**

This function directly uses the outdoor unit to query the quantity of online indoor units.

##### **Operations:**

In n9 online indoor unit qty query status, the module displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| n9/ quantity, | On             |

LED1 circularly displays the code and quantity, For example, if the indoor unit quantity is 75, 75 is displayed.

If there are two levels of menus on the outdoor unit, you can press the SW4 back button to return to the previous level. Press the SW4 query button again to exit query status.

If you do not press any button on the outdoor unit in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

##### **NOTE:**

This function can query the quantity of indoor units only on a single-system network.

#### 4.2.4.5 nb Outdoor Unit Barcode Query

##### **Introduction:**

This function queries the barcodes of the outdoor unit and controller.

##### **Operations:**

Press the SW1 up button and the SW2 down button to select outdoor unit barcode query. The outdoor unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| nb            | Blinks         |

Press the SW3 confirm button on the outdoor unit to enter the next level of menu. The unit displays as follows:

| LED1          |                |
|---------------|----------------|
| Function Code | Display status |
| nb            | On             |

Press the SW1 up button and the SW2 down button to select the corresponding query module, and press the SW3 confirm button. The unit displays as follows:

| LED1           |                |
|----------------|----------------|
| Parameter Code | Display status |
| Un/Pc          | Blinks         |

**NOTE:**

Un indicates the unit barcode, while Pc indicates the controller barcode.

After confirming the module, press the SW1 up button and the SW2 down button to select the barcode sequence. The displayed sequence is as follows:

Unit barcode digits 1–13, controller barcode digits 1–13, that is, unit barcode head, unit barcode (digits 1–6), unit barcode (digits 7–12), unit barcode (digit 13), controller barcode head, controller barcode (digits 1–6), controller barcode (digits 7–12), controller barcode (digit 13). The LED display as follows:

| LED1           |                |
|----------------|----------------|
| Parameter code | Display status |
| Barcode        | Blinks         |

If a parameter is invalid on the unit, value "00" is displayed.

If there are two levels of menus on the outdoor unit, you can press the SW4 back button to return to the previous level. Press the SW4 query button again to exit query status.

If you do not press any button on the outdoor unit in 5 minutes, the system will automatically exit the current screen and the unit will resume displaying the current status.

## 4.3 Restoration to Default Settings

### Restoration to default settings 1 (clearing all settings)

On the main board of the master unit, press and hold the SW1 up button and SW4 back button for over 10 seconds to restore the system default settings. The unit display as follows:

| LED1        |                      |
|-------------|----------------------|
| Status code | Display status       |
| 0C          | Blinks for 3 seconds |

At this time, the system clears all settings, including engineering numbers of the indoor and outdoor units, quantities of the indoor and outdoor units, and commissioning completion status.

### Restoration to default settings 2 (clearing all settings except the commissioning status)

On the main board of the master unit, press and hold the SW2 down button and SW4 back button for over 10 seconds to clear all the system settings. The unit display as follows:

| LED1        |                      |
|-------------|----------------------|
| Status code | Display status       |
| 0C          | Blinks for 5 seconds |

At this time, the system clears all settings, including engineering numbers of the indoor and outdoor units, but stores quantities of the indoor and outdoor units, and commissioning completion status.

### **Restoration to default settings 3 (clearing only function settings of the outdoor unit)**

On the main board of the master unit, press and hold the SW3 back button and SW4 back button for over 10 seconds to clear all the system settings. The unit display as follows:

| LED1        |                      |
|-------------|----------------------|
| Status code | Display status       |
| 0C          | Blinks for 7 seconds |

At this time, the system clears all settings, but stores engineering numbers of the indoor and outdoor units, quantities of the indoor and outdoor units, and commissioning completion status.

## **4.4 Fire Alarm Function Setting**

The VRF unit system reserves a fire alarm interface "CN44", which connects with the external fire alarm system. In case of an external fire, the unit urgently shuts down for protection based on the received signal. Then, the unit enters the standby status.

## **4.5 Indoor Unit Function Applications**

For details, see the service manual of the indoor unit.



# Chapter 3 Faults

## 1 Error Indication

Indoor:

| Error Code | Content   | Error Code | Content  |
|------------|---|------------|--|
| L0         | Malfunction of IDU (uniform)  | d1         | Indoor PCB is poor   |
| L1         | Protection of indoor fan  | d2         | Malfunction of lower water temperature sensor of water tank  |
| L2         | Auxiliary heating protection  | d3         | Malfunction of ambient temperature sensor                    |
| L3         | Water-full protection   | d4         | Malfunction of entry-tube temperature sensor                 |
| L4         | Abnormal power supply for wired controller  | d5         | Malfunction of middle temperature sensor                     |
| L5         | Freeze prevention protection  | d6         | Malfunction of exit-tube temperature sensor                  |
| L6         | Mode shock  | d7         | Malfunction of humidity sensor                               |
| L7         | No main IDU   | d8         | Malfunction of water temperature sensor                      |
| L8         | Power supply is insufficient  | d9         | Malfunction of jumper cap                                    |
| L9         | For single control over multiple units, number of IDU is inconsistent                 | dA         | Web address of IDU is abnormal                               |
| LA         | For single control over multiple units, IDU series is inconsistent                    | dH         | PCB of wired controller is abnormal                          |
| LH         | Alarm due to bad air quality  | dC         | Abnormal setting for capacity button                         |
| LC         | IDU is not matching with outdoor unit   | dL         | Malfunction of air outlet temperature sensor                 |
| LL         | Malfunction of water flow switch  | dE         | Malfunction of indoor CO <sub>2</sub> sensor                 |
| LE         | Rotation speed of EC DC water pump is abnormal  | dF         | Malfunction of upper water temperature sensor of water tank  |
| LF         | Malfunction of shunt valve setting  | dJ         | Malfunction of backwater temperature sensor                  |
| LJ         | Setting of functional DIP switch code is wrong  | dP         | Malfunction of inlet tube temperature sensor of generator    |
| LP         | Zero-crossing malfunction of PG motor   | dU         | Malfunction of drainage pipe temperature sensor of generator |
| LU         | Indoor unit's branch is not inconsistent for one-to-more unit of heat recovery system | db         | Debugging status   |
| Lb         | Inconsistent IDU of group-controlled reheat and dehumidification system               | dd         | Malfunction of solar power temperature sensor                |
| y1         | Malfunction of inlet tube temperature sensor 2  | dn         | Malfunction of swing parts                                   |
| y2         | Malfunction of outlet tube temperature sensor 2                                       | dy         | Malfunction of water temperature sensor                      |
| y7         | Malfunction of fresh air intake temperature sensor                                    | y8         | Main error of indoor air box sensor                          |
| yA         | IFD malfunction   | yB         | Refrigerant Leakage Protection                               |
| yd         | Malfunction of Refrigerant Detection Sensor   | En         | Malfunction of System Refrigerant Detection                  |

Outdoor:

| Error Code | Content   | Error Code | Content   |
|------------|---|------------|---|
| F0         | Main board of ODU is poor                                   | E0         | Malfunction of ODU (uniform)                        |
| F1         | Malfunction of high-pressure sensor                         | E1         | High-pressure protection                            |
| F3         | Malfunction of low-pressure sensor                          | E2         | Discharge low-temperature protection                |
| F5         | Malfunction of discharge temperature sensor of compressor 1 | E3         | Low-pressure protection                             |
| F6         | Malfunction of exit-tube temperature sensor                 | E4         | High discharge temperature protection of compressor |
| F7         | Malfunction of humidity sensor                              | Ed         | Drive module low temperature protection             |

| Error Code | Content  | Error Code | Content   |
|------------|--|------------|---|
| F8         | Malfunction of water temperature sensor                              | J0         | Protection for other modules                                      |
| F9         | Malfunction of jumper cap  | J1         | Over-current protection of compressor 1                           |
| FA         | Web address of IDU is abnormal                                       | J2         | Over-current protection of compressor 2                           |
| FC         | Current sensor of compressor 2 is abnormal                           | J3         | Over-current protection of compressor 3                           |
| FL         | Current sensor of compressor 3 is abnormal                           | J4         | Over-current protection of compressor 4                           |
| FE         | Current sensor of compressor 4 is abnormal                           | J5         | Over-current protection of compressor 5                           |
| FF         | Current sensor of compressor 5 is abnormal                           | J6         | Over-current protection for compressor 6                          |
| FJ         | Current sensor of compressor 6 is abnormal                           | J7         | Gas-mixing protection of 4-way valve                              |
| FP         | Malfunction of DC motor  | J8         | High pressure ratio protection of system                          |
| FU         | Malfunction of casing top temperature sensor of compressor 1         | J9         | Low pressure ratio protection of system                           |
| Fb         | Malfunction of casing top temperature sensor of compressor 2         | JA         | Protection because of abnormal pressure                           |
| Fd         | Malfunction of exit tube temperature sensor of mode exchanger        | JC         | Water flow switch protection                                      |
| Fn         | Malfunction of inlet tube temperature sensor of mode exchanger       | JL         | Protection because high pressure is too low                       |
| b1         | Malfunction of outdoor ambient temperature sensor                    | JE         | Oil-return pipe is blocked  |
| b2         | Malfunction of defrosting temperature sensor 1                       | JF         | Oil-return pipe is leaking  |
| b3         | Malfunction of defrosting temperature sensor 2                       | P0         | malfunction of driving board of compressor (uniform)              |
| b4         | Malfunction of liquid temperature sensor of sub-cooler               | P1         | Driving board of compressor operates abnormally (uniform)         |
| b5         | Malfunction of gas temperature sensor of sub-cooler                  | P2         | Voltage protection of driving board power of compressor (uniform) |
| b6         | Malfunction of inlet temp sensor of gas-liquid separator             | P3         | Reset protection of driving module of compressor                  |
| b7         | Malfunction of outlet temp sensor of gas-liquid separator            | P4         | Drive PFC protection of compressor                                |
| b8         | Malfunction of outdoor humidity sensor                               | P5         | Over-current protection of inverter compressor                    |
| b9         | Malfunction of gas temperature sensor of heat exchanger              | P6         | Drive IPM module protection of compressor                         |
| bA         | Malfunction of oil-return temperature sensor 1                       | P7         | Malfunction of drive temperature sensor of compressor             |
| bH         | Clock of system is abnormal  | P8         | Drive IPM high temperature protection of compressor               |
| bE         | Malfunction of inlet tube temperature sensor of condenser            | P9         | Desynchronizing protection of inverter compressor                 |
| bF         | Malfunction of outlet tube temperature sensor of condenser           | PA         | Malfunction of drive storage chip of compressor                   |
| bJ         | High-pressure sensor and low-pressure sensor are connected reversely | PH         | High-voltage protection of compressor's drive DC bus bar          |
| bP         | Malfunction of temperature sensor of oil-return 2                    | PC         | Drive current detection circuit malfunction of compressor         |
| bU         | Malfunction of temperature sensor of oil return 3                    | PL         | Low-voltage protection of compressor's drive DC bus bar           |
| bb         | Malfunction of temperature sensor of oil return 4                    | PE         | Phase-lacking of inverter compressor                              |
| bd         | Malfunction of air inlet temperature sensor of subcooler             | PF         | Drive charging circuit malfunction of compressor                  |
| bn         | Malfunction of liquid inlet temperature sensor of subcooler          | PJ         | Failure startup of inverter compressor                            |
| H0         | Malfunction of driving board of fan (uniform)                        | PP         | AC current protection of inverter compressor                      |
| H1         | Driving board of fan operates abnormally (uniform)                   | PU         | AC input voltage of drive of inverter compressor                  |
| H2         | Voltage protection of driving board power of fan (uniform)           | Py         | DIP switch code or jumper cap of compressor driver is abnormal    |
| H3         | Reset protection of driving module of fan                            | G0         | PV reversed connection protection                                 |
| H4         | Drive PFC protection of fan  | G1         | PV Anti-islanding protection                                      |

| Error Code | Content   | Error Code | Content  |
|------------|---|------------|--|
| H5         | Over-current protection of inverter fan                   | G2         | PV DC overcurrent protection                         |
| H6         | Drive IPM module protection of fan                        | G3         | PV power generation overload                         |
| H7         | Malfunction of drive temperature sensor of fan            | G4         | PV leakage current protection                        |
| H8         | Drive IPM high temperature protection of fan              | G5         | Phase-lacking protection at power grid side          |
| H9         | Desynchronizing protection of inverter fan                | G6         | Phase-lacking protection at power grid side          |
| HA         | Malfunction of drive storage chip of inverter outdoor fan | G7         | PV LVRT  |
| HH         | High-voltage protection of fan's drive DC bus bar         | G8         | Overcurrent protection at power grid side            |
| HC         | Drive current detection circuit malfunction of fan        | G9         | Drive IPM module protection at power grid side       |
| HL         | Low-voltage protection of fan's drive DC bus bar          | GA         | Low/high input voltage protection at power grid side |
| HE         | Phase-lacking of inverter fan                             | GH         | Photovoltaic DC\DC protection                        |
| HF         | Drive charging circuit malfunction of fan                 | GC         | Photovoltaic DC hardware overcurrent protection      |
| HJ         | Failure startup of inverter fan                           | GL         | Grid side hardware overcurrent protection            |
| HP         | AC current protection of inverter fan                     | GE         | High or low photovoltaic voltage protection          |
| HU         | AC input voltage of drive of inverter fan                 | GF         | DC bus neutral-point potential unbalance protection  |
| Gd         | Grid side current sensor protection                       | GJ         | Grid side module high-temperature protection         |
| Gn         | Insulation resistance protection                          | GP         | Grid side temperature sensor protection              |
| Gy         | Unrecoverable error of grid drive (photovoltaic)          | GU         | Charging circuit protection                          |
| Gb         | Grid side relay protection                                | —          | —  |

## Debugging:

| Error Code | Content  | Error Code | Content   |
|------------|--|------------|---|
| U0         | Preheat time of compressor is insufficient                 | Cd         | Communication malfunction between mode exchanger and ODU                      |
| U2         | Wrong setting of ODU's capacity code/jumper cap            | Cn         | Malfunction of network for IDU and ODU of mode exchanger                      |
| U3         | Power supply phase sequence protection                     | Cy         | Communication malfunction of mode exchanger                                   |
| U4         | Refrigerant-lacking protection                             | C0         | Communication malfunction between IDU, ODU and IDU's wired controller         |
| U5         | Wrong address for driving board of compressor              | C1         | Communication malfunction between main control and DC-DC controller           |
| U6         | Alarm because valve is abnormal                            | C2         | Communication malfunction between main control and inverter compressor driver |
| U7         | Power grid DRED0 response protection                       | C3         | Communication malfunction between main control and inverter fan driver        |
| U8         | Short-circuit malfunction of IDU                           | C4         | Malfunction of lack of IDU  |
| U9         | Malfunction of pipe-line for ODU                           | C5         | Alarm because project code of IDU is inconsistent                             |
| UA         | DC bus overvoltage protection at power grid side           | C6         | Alarm because ODU quantity is inconsistent                                    |
| UH         | DC bus undervoltage protection at power grid side          | C7         | Abnormal communication of converter   |
| UC         | Setting of main IDU is successful                          | C8         | Emergency status of compressor  |
| UL         | Emergency operation DIP switch code of compressor is wrong | C9         | Emergency status of fan   |
| UE         | Charging of refrigerant is invalid                         | CA         | Emergency status of module  |
| UF         | Identification malfunction of IDU of mode exchanger        | CH         | Rated capacity is too high  |
| UJ         | FO protection for PV module                                | CC         | Malfunction of lack of main control unit                                      |

| Error Code | Content  | Error Code | Content  |
|------------|--|------------|--|
| Ud         | Grid-connected driver board error                                  | CL         | Rated capacity is too low                                |
| Un         | Communication malfunction between main control and inverter        | CE         | Communication malfunction between mode exchanger and IDU |
| Uy         | Over-temperature protection for PV module                          | CF         | Malfunction of multiple main control units               |
| CU         | Communication malfunction between IDU and the receiving lamp plate | CJ         | Address DIP switch code of system is shocking            |
| Cb         | Overflow distribution of IP address                                | CP         | Malfunction of multiple main wired controllers           |

Status:

| Error Code | Content                                       | Error Code | Content  |
|------------|---|------------|--|
| A0         | Unit waiting for debugging                    | n0         | SE operation setting of system                       |
| A2         | Refrigerant recovery operation of after-sales | n3         | Compulsory defrosting                                |
| A3         | Defrosting                                    | n4         | Limit setting for max. capacity/output capacity      |
| A4         | Oil-return                                    | n5         | Compulsory excursion of engineering code of IDU      |
| A6         | Heat pump function setting                    | n6         | Inquiry of malfunction                               |
| A7         | Quiet mode setting                            | n7         | Inquiry of parameters                                |
| A8         | Vacuum pump mode                              | n8         | Inquiry of project code of IDU                       |
| AH         | Heating                                       | n9         | Check quantity of IDU on line                        |
| AC         | Cooling                                       | nA         | Heat pump unit                                       |
| AL         | Charging refrigerant automatically            | nH         | Heating only unit                                    |
| AE         | Charging refrigerant manually                 | nC         | Cooling only unit                                    |
| AF         | Fan   | nE         | Negative sign code                                   |
| AJ         | Alarm for cleaning filter                     | nF         | Fan model  |
| AP         | Debugging confirmation for startup of unit    | nJ         | High temperature prevention when heating             |
| AU         | Long-distance emergency stop                  | nU         | Eliminate the long-distance shielding command of IDU |
| Ab         | Emergency stop of operation                   | nb         | Bar code inquiry                                     |
| Ad         | Limit operation                               | nn         | Length modification of connection pipe of ODU        |
| An         | Child lock status                             | Ay         | Shielding status                                     |

## 2 Troubleshooting



### WARNING!

When troubleshooting the modular units, make sure that all outdoor units are powered off and powered on at the same time. Avoid doing so to only some of the outdoor units.

### 2.1 "A0" Unit's to-be-commissioned State

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display



#### **Fault diagnosis:**

This is a status code. It is displayed before the completion of system engineering commissioning. At this time, the unit cannot be started.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.2 "A2" Refrigerant Recycle Running State

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

This is a status code. It indicates that the system has entered refrigerant recycle running state and will automatically start.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.3 "A3" Defrosting State

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

This is a status code. It indicates that the system has entered defrosting state. In this case, the indoor fan will stop working for 5 to 10 minutes.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.4 "A4" Oil Return State

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


**Fault diagnosis:**

This is a status code. It indicates that the system has entered oil return state. In case of oil return in heating mode, the indoor fan will stop working for 5 to 10 minutes.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.5 "A6" Cooling and Heating Function Settings State

**Fault display:** main board of outdoor unit displays 

**Fault diagnosis:**

This is a status code. It indicates that the system has entered cooling and heating function settings state. In this case, you can select Cooling and Heating (nA), Cooling Only (nC), Heating Only (nH) or Fan Type (nF).

**Possible causes:** --

**Troubleshooting:** not required.

## 2.6 "A7" Silent Mode Settings State

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the system has entered silent mode settings state.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.7 "A8" Vacuum Pumping Mode

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the system has entered vacuum pumping mode and relevant expansion valves and solenoid valves will open.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.8 "AH" Heating State

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the system has entered heating mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.9 "AC" Cooling State

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the system has entered cooling mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.10 "AF" Fan State

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the system has entered the fan mode. In this case, all the indoor units operate only in fan mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.11 "AE" Artificial Refrigerant Charging State

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the system has employed artificial refrigerant charging mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.12 "AJ" Filter Clean Prompt

**Fault display:** wired controller of indoor unit and receiver of indoor unit display



**Applicable models:** all indoor units

**Fault diagnosis:**

This is a status code. It indicates that the filter of indoor unit needs to be cleaned. The cleaning interval of filter can be set according to actual circumstances.

**Possible causes:** --

**Troubleshooting:** Clean the filter and remove the prompt to have the filter proceeds to the next service cycle.

## 2.13 "AP" Unit Commissioning Startup Confirmation

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

This is a status code. It indicates that the unit has been commissioned and is ready for operation.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.14 "AU" Remote Control for Emergency Stop

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display



**Fault diagnosis:**

This is a status code. It indicates that the unit is in emergency stop status through remote centralized control, and it cannot be started unless such state is disabled.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.15 "Ab" Emergency Stop

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

This is a status code. It indicates that the main board of outdoor unit has received emergency stop signal, and the unit cannot be started unless such state is disabled.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.16 "Ad" Restricted Running State

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

This is a status code. It indicates that an emergency running state has been set for the system, but the unit is not allowed to perform emergency running because the emergency running has reached the time limit.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.17 "b1" Outdoor Ambient Temperature Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


**Fault diagnosis:**

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.



**Troubleshooting:**

## 2.18 "b2" Defrosting Temperature Sensor 1 Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

**Fault diagnosis:**

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

**Troubleshooting:**

## 2.19 "b3" Defrosting Temperature Sensor 2 Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.20 "b4" Subcooler's Liquid Outlet Temperature Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

### Fault diagnosis:


The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;

- Abnormal detection circuit.

#### Troubleshooting:



## 2.21 "b5" Subcooler's Gas Outlet Temperature Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


#### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

#### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

#### Troubleshooting:



## 2.22 "b6" Suction Temperature Sensor 1 Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.23 "b7" Suction Temperature Sensor 2 Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.24 "b8" Outdoor Humidity Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.25 "b9" Heat Exchanger's Gas Outlet Temperature Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.26 "bA" Oil Return Temperature Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the temperature sensor and the main board interface;
- Abnormal temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:





## 2.27 "bd" Subcooler Air Inlet Temperature Sensor Error

**Error display:** ODU main board, IDU wired controller, IDU receive light board will display



**Applicable model:** all ODUs


**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 30 seconds continuously, report the error

**Possible reasons:**

- Poor contact between temperature sensor and terminal in main board interface
- Temperature sensor is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**



## 2.28 "bJ" High and Low Pressure Sensor is Wrongly Connected

**Error display:** ODU main board, IDU wired controller and IDU receive light board will display



**Applicable model:** all ODUs

**Error judgment condition and method:**

Under shutdown status, the high and low pressure sensor has detected that the high pressure test value of module is 30°C higher than the low pressure, the unit will report that the high and low pressure is wrongly connected.

**Possible reasons:**

- The resistance of high pressure sensor is abnormal, the test value is high.
- The resistance of low pressure sensor is abnormal, the test value is low.
- High and low pressure sensor is wrongly connected.

**Troubleshooting:**

Step 1: check if the input voltage of high pressure sensor between "4.9~5.1V" and the output voltage between "0.5~4.5V", if no, replace the high pressure sensor.

Step 2: check if the input voltage of low pressure sensor between "4.9~5.1V" and the output voltage between "0.5~4.5V", if no, replace the high pressure sensor.

Step 3: if the above inspections on input/output voltage of pressure sensor are normal, exchange the corresponding terminal of two pressure sensors.

## 2.29 "bn" Subcooler Liquid Temperature Sensor Error

**Error display:** ODU main board, IDU wired controller and IDU receive light board will display 

**Applicable model:** all ODUs

**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 30 seconds continuously, report the error

**Possible reasons:**

- Poor contact between temperature sensor and terminal in main board interface
- Temperature sensor is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**

Step 1: check the terminal between main board and temperature sensor to see if it is loose or any foreign objects inside? If yes, reconnect it after treatment;

Step 2: check if the temperature sensor is abnormal, if yes, replace the temperature sensor;

Step 3: if the above inspections are normal, the detecting circuit might be abnormal, please replace the main board.

## 2.30 "C0" Communication Fault Between Indoor and Outdoor Units and Between Indoor Unit and Wired Controller

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

There is no communication between the outdoor unit and indoor unit or between the indoor unit and wired controller for 30 seconds, and a fault is generated.


**Possible causes:**

- Communication cables are connected wrongly or get loose;
- Communication cables are broken;
- Poor contact of communication cables;
- Number of wired controllers connected or addresses are set improperly;
- Controller operates improperly.

### Troubleshooting:

If the main control board of outdoor unit does not display C0, check the connection between the indoor unit and the wired controller; if the main control board of outdoor unit, indoor unit's receiver and wired controller display C0, check the connection between the indoor unit and outdoor unit and between the indoor unit and wired controller; if only the wired controller displays C0, check the connection between the indoor unit and wired controller, the number of wired controllers connected and address settings.

Perform the troubleshooting as follows:



## 2.31 "C2" Communication Fault Between the Primary Controller and Inverter Compressor Driver

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the outdoor unit fails to detect inverter compressor driver for 30 consecutive seconds, the fault is generated.

### Possible causes:

- The communication cables between the main board of outdoor unit and inverter compressor driver inside the module are connected improperly;
- The inverter compressor driver operates improperly;
- The main board operates improperly.

### Troubleshooting:



## 2.32 "C3" Communication Fault Between the Primary Controller and Inverter Fan Driver

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the outdoor unit fails to detect inverter fan driver for 30 consecutive seconds, the fault is generated.

### Possible causes:

- The communication cables between the main board of outdoor unit and inverter fan driver inside the module are connected improperly;
- The inverter fan driver operates improperly;
- The main board operates improperly.

### Troubleshooting:



## 2.33 "C4" Indoor Unit Loss Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


**Fault diagnosis:**

When the unit identifies that more than three indoor units are disconnected, it will stop for protection.


**Possible causes:**

- Poor contact of communication cables;
- The indoor units are powered off;
- The main board of indoor unit operates improperly.

**Troubleshooting:**



## 2.34 "C5" Indoor Unit Engineering SN Conflict

**Fault display:** commissioning software and remote monitoring software display the fault ; The wired controller of indoor unit and receiver of indoor unit do not display the fault.

**Fault diagnosis:**

Check the engineering SN of indoor units, as the indoor units having the same numbers generate the same fault. However, the fault is displayed and required to be removed only when the commissioning software, centralized controller and remote monitoring are connected.

In the case of non-centralized control, the conflict in terms of the engineering SNs of some indoor units, if any, do not affect the operation of themselves and of the entire system.

**Possible causes:**

- The same engineering SN is configured for different indoor units;

- The main board of indoor unit is from another unit.

### Troubleshooting:

There are several ways to reset the conflicting engineering SN of an indoor unit:

by commissioning software;

by wired controller;

by commissioning the remote controller;

by pressing the Reset button on the main board of indoor unit so that the system reassigns the numbers.

## 2.35 "C6" Alarm on Inconsistent Number of Outdoor Units

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The unit detects the number of online outdoor modules in real time. When it detects that the number of current modules is inconsistent with the number of modules previously commissioned and memorized, the unit will report the fault and stop working.

### Possible causes:

- Abnormal communication among modules;
- The modules are not powered on.

### Troubleshooting:



## 2.36 "C8" Emergency Operation of Compressor

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

If any compressor is set to emergency operation mode, the main board displays the code during the operation, indicating that the unit's compressor has entered emergency operation.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.37 "C9" Emergency Operation of Fan

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

If any fan is set to emergency operation mode, the main board displays the code during the operation, indicating that the unit's fan has entered emergency operation.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.38 "CA" Emergency Operation of Module

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

If any module is set to emergency operation mode, the main board displays the code during the operation, indicating that the unit's module has entered emergency operation.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.39 "CH" Too High Rated Capacity Ratio

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

The unit detects the rated capacity of the online indoor and outdoor units. When the ratio of the total rated capacity of indoor units to the total rated capacity of outdoor units exceeds 1.35, the unit will stop operation and display the fault.

**Possible causes:**

■ The total rated capacity of the indoor units exceeds 1.35 times of the total rated capacity of the outdoor units.

**Troubleshooting:**

Re-engineer the unit to decrease indoor unit capacity or increase outdoor unit capacity.



## 2.40 "CL" Too Low Rated Capacity Ratio

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

### Fault diagnosis:

The unit detects the rated capacity of the online indoor and outdoor units. When the ratio of the total rated capacity of indoor units to the total rated capacity of outdoor units is below 0.5, the unit will stop operation and display the fault.

### Possible causes:

- The total rated capacity of the indoor units is smaller than 0.5 times of the total rated capacity of the outdoor units.

### Troubleshooting:

Re-engineer the unit to increase indoor unit capacity or decrease outdoor unit capacity.

## 2.41 "CJ" System Address Code Conflict

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

### Fault diagnosis:

When multiple refrigerant systems are connected through the CAN2 network of the unit's main board, only one primary system is allowed in the network.


If two or more master units' DIP switches (SA2) are detected to be master unit's DIP switches in the network (that is, SA2 DIP switch is "00000"), the fault of multiple master units is reported.

### Possible causes:

- If two or more master units' DIP switches (SA2) are detected to be master unit's DIP switches, keep only one master unit's DIP switch (SA2) to be "00000" and other master units' DIP switches (SA2) to be different;

- Abnormal DIP switch or main board.

### Troubleshooting:



## 2.42 "CP" Fault of Multiple Main Wired Controllers

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

Two or more wired controllers in an HBS network are main wired controllers.

**Possible causes:**

■ When two (or more) wired controllers control one or more indoor units at the same time, the two (or more) wired controllers are the main wired controllers.

**Troubleshooting:**

Make sure that at most two wired controllers control one or more indoor units; when two wired controllers control one or more indoor units, enter the wired controller parameter settings (P13) to set the address of one of the wired controllers to be 02 (that is, to be the secondary wired controller).

## 2.43 "Cb" IP Address Assignment Overflow

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


**Fault diagnosis:**

If more than four addresses are assigned to other outdoor units by the outdoor unit, the unit reports an IP address assignment overflow.

If more than 80 (100) addresses are assigned to indoor units by the outdoor unit, the unit reports an IP address assignment overflow.

**Possible causes:**

- More than four outdoor units exist;
- More than 80 (100) indoor units exist.
- After replacing the main boards of the indoor units and the outdoor units, the outdoor units are not powered off.

**Troubleshooting:**

**NOTE:** When the number of indoor units is 100, engineering customization is required.

## 2.44 "d1" Poor Indoor Circuit Board



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Fault diagnosis:**

Check whether the address chip and memory chip of the indoor unit's main board can be read properly. If not, the fault is generated.

**Possible causes:**

- Abnormal address chip;
- Abnormal memory chip.

**Troubleshooting:**

Replace the main control board.

## 2.45 "d2" Water Tank Temperature Sensor Error



**Error display:** wired controller of hydro box displays

**Applicable model:** hydro box

**Error judgment condition and method:**


Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 5 seconds continuously, report the error

**Possible reasons:**

- Poor contact between water tank temperature sensor and terminal in main board interface
- Water tank temperature sensor is abnormal

■ Detecting circuit is abnormal

**Troubleshooting:**



## 2.46 "d3" Ambient Temperature Sensor Fault



**Fault display:** wired controller of indoor unit and receiver of indoor unit display


**Fault diagnosis:**

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 5 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the ambient temperature sensor and the main board interface;
- Abnormal ambient temperature sensor;
- Abnormal detection circuit.

**Troubleshooting:**



## 2.47 "d4" Inlet Pipe Temperature Sensor Fault



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Fault diagnosis:**


The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value.

When the sampled AD value exceeds the limits for 5 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the inlet pipe temperature sensor and the main board interface;
- Abnormal inlet pipe temperature sensor;
- Abnormal detection circuit.

**Troubleshooting:**



## 2.48 "d5" Middle Part Temperature Sensor Fault (Reserved)

## 2.49 "d6" Outlet Pipe Temperature Sensor Fault




**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Fault diagnosis:**

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 5 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the outlet pipe temperature sensor and the main board interface;
- Abnormal outlet pipe temperature sensor;
- Abnormal detection circuit.

**Troubleshooting:**

## 2.50 "d7" Humidity Sensor Fault


**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Fault diagnosis:**

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 5 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the humidity sensor and the main board interface;
- Abnormal humidity sensor;
- Abnormal detection circuit.

**Troubleshooting:**

## 2.51 "d8" Water Temperature Sensor Fault (Reserved)

## 2.52 "d9" Jumper Cap Fault

**Fault display:** wired controller of indoor unit and receiver of indoor unit display




**Fault diagnosis:**

A fault is reported if the jumper cap does not match the main board.

**Possible causes:**

- The jumper cap is not installed;
- The jumper cap is numbered incorrectly;
- Abnormal detection circuit.

**Troubleshooting:**



## 2.53 "dA" Abnormal Network Address of Indoor Unit

**Fault display:** wired controller of indoor unit and receiver of indoor unit display




**Fault diagnosis:**

Check the indoor unit's address chip and IP address. If the address chip cannot be read, the indoor unit's IP address is 0 and IP addresses conflict, the fault is generated.

**Possible causes:**

- Outdoor units' address are assigned incorrectly;
- Indoor unit's processing error;
- Abnormal address chip.

**Troubleshooting:****2.54 "dH" Abnormal Circuit Board of Wired Controller**


**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Fault diagnosis:**

The wired controller's IIC communication is abnormal.

**Possible causes:**

- The communication between the wired controller's touch keypad and display panel IIC is abnormal;
- The wired controller's memory chip IIC cannot be read or written properly (if there are any memory chips).

**Troubleshooting:****2.55 "dC" Abnormal Settings of DIP Switch for Capacity**

**Fault display:** wired controller of indoor unit and receiver of indoor unit display


**Fault diagnosis:**

If DIP switch for capacity is set to the wrong position, the fault is generated.



**Possible causes:**

- DIP switch for capacity is set to a wrong position;
- Abnormal detection circuit.

**Troubleshooting:**

## 2.56 "dL" Air Outlet Temperature Sensor Fault




**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Fault diagnosis:**

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 5 consecutive seconds, the fault is generated.

**Possible causes:**

- Poor contact between the air outlet temperature sensor and the main board interface;
- Abnormal air outlet temperature sensor;
- Abnormal detection circuit.

**Troubleshooting:**

## 2.57 "dE" Indoor CO<sub>2</sub> Sensor Fault (Reserved)

## 2.58 "dF" Temperature Sensor Error

**Error display:** hydro box wired controller will display 

**Applicable mode:** all hydro boxes

**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 30 seconds continuously, report the error

**Possible reasons:**

- Poor contact between temperature sensor and terminal in main board interface
- Temperature sensor is abnormal
- Detecting circuit is abnormal


**Troubleshooting:**

Step 1: check the hydro box main board and temperature sensor interface terminal to see if it is loose or any foreign objects inside? If yes, reconnect it after treatment;

Step 2: check if the temperature sensor is abnormal, if yes, replace the temperature sensor;

Step 3: if the above inspections are normal, the detecting circuit might be abnormal, please replace the main board.

## 2.59 "dJ" Water Return Temperature Sensor Error

**Error display:** wired controller of hydro box will display 


**Applicable model:** hydro box

**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 5 seconds continuously, report the error

**Possible reasons:**

- Poor contact between water return temperature sensor and terminal in main board interface
- Water return temperature sensor is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**

## 2.60 "dP" Floor Heating Water Inlet Temperature Sensor Error

**Error display:** hydro box wired controller



**Applicable model:** all hydro boxes

**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 30 seconds continuously, report the error

**Possible reasons:**

- Poor contact between temperature sensor and terminal in main board interface
- Temperature sensor is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**

Step 1: check the hydro box main board and temperature sensor interface terminal to see if it is loose or any foreign objects inside? If yes, reconnect it after treatment;

Step 2: check if the temperature sensor is abnormal, if yes, replace the temperature sensor;

Step 3: if the above inspections are normal, the detecting circuit might be abnormal, please replace the main board.

## 2.61 "dU" Floor Heating Water Outlet Pipe Temperature Sensor Error

**Error display:** wired controller of hydro box will display



**Applicable model:** hydro box

**Error judgment condition and method:**

1) Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 5 seconds continuously, report the error

2) After the water pump has operating for 30min, report alarm if detecting that water inlet temperature of generator is higher than water outlet temperature in 10 consecutive minutes.

**Possible reasons:**

■ Poor contact between floor heating outlet water pipe temperature sensor and terminal in main board interface

■ Floor heating outlet water pipe temperature sensor falls off or is abnormal

■ The circulating water in generator is not drained completely

■ Detecting circuit is abnormal

**Troubleshooting:**

Step 1: Is the terminal between main board of hydro box and temperature sensor loose or any foreign objects inside? If yes, retighten it after treatment;

Step 2: Is the temperature sensor loose or any foreign objects inside? If yes, retighten it or replace the temperature sensor;

Step 3: If air exist in the circulated waterway of hydro box, if yes, drain it again;

Step 4: If the above tests are normal, then the detecting circuit might be abnormal, please replace the main board.

## 2.62 "db" Engineering Commissioning

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display A black square icon with the white text "db" inside.


**Fault diagnosis:**

This is a status code but not a fault code. It indicates that the unit is being commissioned and the indoor unit is not operational.

**Possible causes:** --

**Troubleshooting:** --

## 2.63 "dd" Solar Energy Temperature Sensor Error

**Error display:** wired controller of hydro box will display 

**Applicable model:** hydro box which the solar energy at function DIP code of the main board is set as "connect"


**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 5 seconds continuously, report the error


**Possible reasons:**

- Poor contact between temperature sensor and terminal in main board interface
- Temperature sensor is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**



## 2.64 "dn" Swing Assy Error

**Error display:** display in the monitor software only 


**Applicable model:** Multi VRF indoor unit with swing assy

**Error judgment condition and method:**

Report alarm through judging the status of limit switch 1 and 2, When the swing structure is faulted, the indoor unit will not stop, the display board does not display error code (the error will only be embodied in CAN communication data)

**Possible reasons:**

- Poor contact between limit switch and terminal in main board interface
- Detecting circuit is abnormal

**Troubleshooting:****2.65 "E1" Protection in Case of Too High Pressure**

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

**Fault diagnosis:**

When the high pressure sensor detects that the temperature at the high pressure is greater than 65°C or the high pressure switch is disconnected, it indicates that the high pressure is too high, and the unit will stop running to ensure safe operation.

**Possible causes:**

- Check valve of the outdoor unit is closed;
- Abnormal high pressure sensor;
- The high pressure switch operates improperly;
- Abnormal outdoor or indoor fans;
- Clogging of indoor filter or air duct (heating mode);
- The ambient temperature where the unit operates is too high;
- Excessive refrigerant in the unit;
- Clogging of unit pipes.

**Troubleshooting:**

## 2.66 "E2" Protection in Case of Too Low Air Discharge Temperature of Compressor

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

### **Fault diagnosis:**

When the difference between the air discharge temperature of compressor and the temperature at the high pressure is below 10°C, the unit stops running to ensure safe operation.

### **Possible causes:**

- The compressor's temperature sensor for air discharge operates improperly;
- The electronic expansion valve of indoor unit operates improperly in cooling mode;
- The electronic expansion valve of outdoor unit operates improperly in heating mode;
- Excessive refrigerant in the unit.

### **Troubleshooting:**

**Step 1:** Check whether the air discharge pipe and shell roof temperature sensor of each compressor are installed firmly, and whether the protection sponge is fastened.

Then, check whether the resistance corresponding to each temperature is normal based on the temperature - resistance table of temperature sensor. If not, replace the temperature sensor.

**Step 2:** If the unit is in cooling mode:

First, inspect the indoor electronic expansion valve:

- ① When the electronic expansion valve of the indoor unit is closed to 0PLS, if the temperature difference between the inlet and outlet pipes of the indoor unit coil and the temperature at the low pressure is less than 10°C, it indicates that the unit operates improperly.

**Solution:** First, make sure that the EXV coil is connected properly, and then power off the unit. Power on to reset the unit and check the resetting action. If unable to reset the unit, replace the coil or the main board. If able to reset the unit normally despite the problem, replace the electronic expansion valve.

- ② Check whether the electronic expansion valve of the indoor unit operates properly: If the electronic expansion valve is open to 200PLS, the temperature of the outlet pipe of indoor unit coil is smaller than that of the inlet pipe by over 1°C, and the difference between the discharge temperature of the compressor or the shell roof temperature of the compressor and the high pressure temperature is less than 10°C.

**Solution:** First, make sure that the EXV coil is connected properly, and then power off the unit. Power on to reset the unit and check the resetting action. If unable to reset the unit, replace the coil or the main board. If able to reset the unit normally despite the problem, replace the electronic expansion valve.

Next, inspect the outdoor subcooler electronic expansion valve:

After confirming that the EXV coil is connected properly, power off the unit. Then power on to reset the unit and check the resetting action.



**Step 3:** If the unit is in heating mode, check the electronic expansion valve of the outdoor unit first.

After confirming that the EXV coil is connected properly, power off the unit. Then power on to reset the unit and check the resetting action. If unable to reset the unit, replace the coil or the main board. If able to reset the unit normally, inspect other parts of the unit.

**Step 4:** Check whether the refrigerant is added in accordance with the design requirements, as excessive refrigerant may trigger system protection.

**Solution:** Add refrigerant in accordance with the design requirements.

## 2.67 "E3" System Low Pressure Protection

Fault display: main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

### Fault diagnosis:

The low pressure sensor detects the compressor's suction pressure. When the saturation temperature corresponding to the low pressure is below  $-41^{\circ}\text{C}$ , the unit stops to ensure safe operation.

### Possible causes:

- Check valve of the outdoor unit is closed;
- Abnormal low pressure sensor;
- Abnormal outdoor or indoor fans;
- Clogging of indoor filter or air duct (cooling mode);
- The ambient temperature where the unit operates is too low;
- Insufficient refrigerant in the unit;
- Clogging of unit pipes.

**Troubleshooting:**

## 2.68 "E4" Protection in Case of Too High Air Discharge Temperature of Compressor

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

### **Fault diagnosis:**

When the compressor's discharge temperature detected by the temperature sensors on the discharge pipes and on the top of the compressor is above 118°C, the unit stops running to ensure safe operation.

### **Possible causes:**

- Check valve of the outdoor unit is closed;
- The electronic expansion valve operates improperly;
- Abnormal outdoor or indoor fans;
- Clogging of indoor filter or air duct (cooling mode);
- The ambient temperature where the unit operates exceeds the limit;
- Insufficient refrigerant in the unit;
- Clogging of unit pipes.

### **Troubleshooting:**

**Step 1:** Inspect and make sure that the check valves of the gas pipe and liquid pipe of the outdoor unit are fully opened.

**Step 2:** Power on the units based on the capacity and number of indoor units enabled previously in the case of protection state. After confirming that the EXV coil is connected properly, power off the unit. Then power on to reset the unit and check the resetting action. If unable to reset the unit, replace the coil or the main board. If able to reset the unit normally, inspect other parts of the unit.

**Step 3:** Power on the units based on the capacity and number of indoor units enabled previously in the case of protection state. Observe whether the indoor and outdoor fans are operating properly according to the rotational speed displayed by the commissioning software. If not, replace the motor or motor drive module (outdoor fan).

**Step 4:** In the case of cooling mode, check whether the filter of the indoor unit is dirty or clogged or whether the air resistance is too high (the air resistance is designed to be larger than the static pressure of the unit as required).

**Step 5:** Check whether the air return temperature of the unit exceeds the limit during operation (requirements in cooling mode: outdoor ambient temperature -5°C to +50°C, indoor ambient temperature 16°C to 32°C; requirements in heating mode: outdoor ambient temperature -20°C to +24°C, indoor ambient temperature 16°C to 30°C).

**Step 6:** Check whether the refrigerant is added in accordance with the design requirements, as insufficient refrigerant may trigger system protection.

**Step 7:** Power on the units based on the capacity and number of indoor units enabled previously in the case of protection state. Check whether the pipeline or expansion valve is blocked according to the parameters of the indoor and outdoor units and the temperature of the pipelines (touch with hands).

## 2.69 "Ed" Low Drive Module Temperature Protection

**Error display:** ODU main board, IDU wired controller and IDU receive light board will display 

**Applicable model:** GMV6 series

**Error judgment condition and method:**

Test module temperature through the internal sensor of IPM module, when the test value is below outdoor ambient temperature, the system will stop for protection.

**Possible reasons:**

- Insufficient system refrigerant
- Electronic expansion valve is abnormal
- Drive board is damaged

**Troubleshooting:**

Step 1: confirm if the refrigerant charge is added according to the design requirement, or any leakage exists, insufficient refrigerant might lead to protection;

Step 2: turn on the unit according to the IDU capacity and quantity in previous protection status, after confirming the coil of IDU and ODU expansion valve is correctly connected, disconnect the power, then re-energize for reset and check the reset action. If it is abnormal, replace the coil or main board; if it is normal, check other items;

Step 3: if no problems are found in other inspection steps, the drive board might be damaged, IPM temperature test is abnormal, please replace the drive board.

## 2.70 "F0" Poor Main Board of Outdoor Unit

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

**Fault diagnosis:**

Check whether the address chip, memory chip and clock chip of the main board of the outdoor unit can be read properly. If not, the fault is generated.

**Possible causes:**

- Abnormal address chip;
- Abnormal memory chip;
- Abnormal clock chip.

**Troubleshooting:**

## 2.71 "F1" High-pressure Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The sensor detection circuit samples the AD value of high pressure sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the high pressure sensor and the main board interface;
- Poor contact between high pressure sensor and part where the pressure is detected;
- Abnormal high pressure sensor;
- Abnormal sensor detection circuit.

### Troubleshooting:



## 2.72 "F3" Low Pressure Sensor Fault

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The sensor detection circuit samples the AD value of low pressure sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the low pressure sensor and the main board interface;
- Poor contact between low pressure sensor and part where the pressure is detected;
- Abnormal low pressure sensor;
- Abnormal low pressure sensor detection circuit.

### Troubleshooting:



## 2.73 "F5" Discharge Temperature Sensor Fault of Compressor 1

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the discharge temperature sensor and the main board interface;
- Abnormal discharge temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:





## 2.74 "F6" Discharge Temperature Sensor Fault of Compressor 2

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the discharge temperature sensor and the main board interface;
- Abnormal discharge temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.75 "F7" Discharge Temperature Sensor Fault of Compressor 3

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the discharge temperature sensor and the main board interface;
- Abnormal discharge temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.76 "F8" Discharge Temperature Sensor Fault of Compressor 4

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the discharge temperature sensor and the main board interface;
- Abnormal discharge temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.77 "F9" Discharge Temperature Sensor Fault of Compressor 5

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the discharge temperature sensor and the main board interface;
- Abnormal discharge temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.78 "FA" Discharge Temperature Sensor Fault of Compressor 6

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the discharge temperature sensor and the main board interface;
- Abnormal discharge temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.79 "FH" Abnormal Current Sensor of Compressor 1

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The circuit detection circuit samples the AD value and determines the range of AD value. When the sampled AD value exceeds the limits for 3 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the circuit sensor and the main board interface;
- Abnormal small board of circuit sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.80 "FC" Abnormal Current Sensor of Compressor 2

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The circuit detection circuit samples the AD value and determines the range of AD value. When the sampled AD value exceeds the limits for 3 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the circuit sensor and the main board interface;
- Abnormal small board of circuit sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.81 "FL" Abnormal Current Sensor of Compressor 3

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The circuit detection circuit samples the AD value and determines the range of AD value. When the sampled AD value exceeds the limits for 3 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the circuit sensor and the main board interface;
- Abnormal small board of circuit sensor;
- Abnormal detection circuit.

### Troubleshooting:





## 2.82 "FE" Abnormal Current Sensor of Compressor 4

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The circuit detection circuit samples the AD value and determines the range of AD value. When the sampled AD value exceeds the limits for 3 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the circuit sensor and the main board interface;
- Abnormal small board of circuit sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.83 "FF" Abnormal Current Sensor of Compressor 5

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The circuit detection circuit samples the AD value and determines the range of AD value. When the sampled AD value exceeds the limits for 3 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the circuit sensor and the main board interface;
- Abnormal small board of circuit sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.84 "FJ" Abnormal Current Sensor of Compressor 6

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The circuit detection circuit samples the AD value and determines the range of AD value. When the sampled AD value exceeds the limits for 3 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the circuit sensor and the main board interface;
- Abnormal small board of circuit sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.85 "FU" Shell Roof Temperature Sensor Fault of Compressor 1

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the shell roof temperature sensor and the main board interface;
- Abnormal shell roof temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.86 "Fb" Shell Roof Temperature Sensor Fault of Compressor 2

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

The temperature sensor detection circuit samples the AD value of temperature sensor and determines the range of AD value. When the sampled AD value exceeds the limits for 30 consecutive seconds, the fault is generated.

### Possible causes:

- Poor contact between the shell roof temperature sensor and the main board interface;
- Abnormal shell roof temperature sensor;
- Abnormal detection circuit.

### Troubleshooting:



## 2.87 "H0" Fan Drive Board Fault

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:**

Check the fault code displayed on the wired controller of the indoor unit. If the wired controller displays HO, check the fault code displayed on the 2-digit digital LED of the main control board of the outdoor unit, based on which you are able to identify the specific fault of the fan drive board. Then, troubleshoot the fault according to the corresponding troubleshooting methods.

**Possible causes:**

- Fan drive module reset protection (2-digit digital LED of the main control board of the outdoor unit displays H3);
- Temperature sensor fault of fan drive (2-digit digital LED of the main control board of the outdoor unit displays H7);
- IPM over temperature protection for the fan drive (2-digit digital LED of the main control board of the outdoor unit displays H8);
- Current detection circuit fault of fan drive (2-digit digital LED of the main control board of the outdoor unit displays HC);
- Charging loop fault of fan drive (2-digit digital LED of the main control board of the outdoor unit displays HF);
- Loss of synchronization protection for the inverter fan (2-digit digital LED of the main control board of the outdoor unit displays H9);
- Inverter fan startup failure (2-digit digital LED of the main control board of the outdoor unit displays HJ).

**Troubleshooting:**

**Step 1:** Check the fault code displayed on the wired controller of the indoor unit.

**Step 2:** Check the fault code displayed on the 2-digit digital LED of the outdoor unit at the same time.

**Step 3:** Troubleshoot according to the fault code displayed on the 2-digit digital LED of the outdoor unit (troubleshooting procedures may vary depending on the fault).

## 2.88 "H1" Abnormal Fan Drive Board

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:**

Check the fault code displayed on the wired controller of the indoor unit. If the wired controller displays H1, check the fault code displayed on the 2-digit digital LED of the main control board of the outdoor unit, based on which you are able to identify the specific fault of the fan drive board. Then, troubleshoot the fault according to the corresponding troubleshooting methods.

**Possible causes:**

- IPM module protection for the fan drive (2-digit digital LED of the main control board of the outdoor

unit displays H6);

- Inverter fan over-current protection (2-digit digital LED of the main control board of the outdoor unit displays H5);

- Communication fault of fan drive (2-digit digital LED of the main control board of the outdoor unit displays C3).

**Troubleshooting:**

**Step 1:** Check the fault code displayed on the wired controller of the indoor unit.

**Step 2:** Check the fault code displayed on the 2-digit digital LED of the outdoor unit at the same time.

**Step 3:** Troubleshoot according to the fault code displayed on the 2-digit digital LED of the outdoor unit (troubleshooting procedures may vary depending on the fault).

## 2.89 "H2" Power Voltage Protection for the Fan Drive Board

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:**

Check the fault code displayed on the wired controller of the indoor unit. If the wired controller displays H2, check the fault code displayed on the 2-digit digital LED of the main control board of the outdoor unit, based on which you are able to identify the specific fault of the fan drive board. Then, troubleshoot the fault according to the corresponding troubleshooting methods.

**Possible causes:**

- Over voltage protection for the DC bus of fan drive (2-digit digital LED of the main control board of the outdoor unit displays HH);

- Under voltage protection for the DC bus of fan drive (2-digit digital LED of the main control board of the outdoor unit displays HL).

**Troubleshooting:**

**Step 1:** Check the fault code displayed on the wired controller of the indoor unit.

**Step 2:** Check the fault code displayed on the 2-digit digital LED of the outdoor unit at the same time.

**Step 3:** Troubleshoot according to the fault code displayed on the 2-digit digital LED of the outdoor unit (troubleshooting procedures may vary depending on the fault).

## 2.90 "H3" Reset Protection for the Fan Drive Module

**Fault display:** wired controller of indoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is H3, it indicates the reset protection for the fan drive board.

**Possible causes:**

- The fan drive board operates improperly

**Troubleshooting:**





## 2.91 "H5" Inverter Fan Over-current Protection



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is H5, it indicates the over-current protection for the inverter fan.

**Possible causes:**

- Poor contact of fan's UVW cables;
- The fan is damaged;
- The blades are stuck (the blades are blocked or the motor shaft gets rusty);
- The fan drive board operates improperly.

**Troubleshooting:**



## 2.92 "H6" IPM Module Protection for Fan Drive



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is H6, it indicates the IPM module protection for the fan drive.

**Possible causes:**

- Poor contact of fan's UVW cables;
- The fan is damaged;
- The blades are stuck (the blades are blocked or the motor shaft gets rusty);
- The fan drive board operates improperly.

**Troubleshooting:**



## 2.93 "H7" Temperature Sensor Fault of Fan Drive

**Fault display:** main board of outdoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is H7, it indicates the temperature sensor fault for the fan drive.

**Possible causes:**

- The fan drive board operates improperly.

**Troubleshooting:**



## 2.94 "H8" IPM Over Temperature Protection for Fan Drive

Fault display: main board of outdoor unit displays




### Fault diagnosis:

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is H8, it indicates the IPM over temperature protection for the fan drive.

### Possible causes:

- The IPM module is not covered, or unevenly covered by thermal grease, or covered by dried thermal grease;
- The IPM module's screws are not tightened;
- The fan drive board operates improperly.

### Troubleshooting:



## 2.95 "H9" Loss of Synchronization Protection for Inverter Fan



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is H9, it indicates the loss of synchronization protection for the inverter fan.

**Possible causes:**

- Poor contact of fan's UVW cables;
- The fan is damaged;
- The blades are stuck (the blades are blocked or the motor shaft gets rusty);
- The fan drive board operates improperly.

**Troubleshooting:**



## 2.96 "HC" Current Detection Circuit Fault of Fan Drive

**Fault display:** main board of outdoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is HC, it indicates the current detection circuit fault of fan drive.

**Possible causes:**

- The fan drive board operates improperly.

**Troubleshooting:**



## 2.97 "HH" Over Voltage Protection for DC Bus of Fan Drive

**Fault display:** main board of outdoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is HH, it indicates the over voltage protection for the DC bus of fan drive.

**Possible causes:**

- The unit's input power cable has a voltage exceeding 460V;
- The fan drive board operates improperly.

**Troubleshooting:**

## 2.98 "HL" Under Voltage Protection for DC Bus of Fan Drive




**Fault display:** main board of outdoor unit displays

**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is HL, it indicates the under voltage protection for the DC bus of fan drive.

**Possible causes:**

- The unit's input power cable has a voltage below 320 V;
- The fan drive board operates improperly.

**Troubleshooting:**

## 2.99 "HJ" Inverter Fan Startup Failure



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is HJ, it indicates the inverter fan startup failure.

**Possible causes:**


- Poor contact of fan's UVW cables;
- The fan is damaged;
- The blades are stuck (the blades are blocked or the motor shaft gets rusty);
- The fan drive board operates improperly.

**Troubleshooting:**





## 2.100 "J0" Protection for Other Modules

**Fault display:** main board of outdoor unit displays  while the indoor unit and receiver of indoor unit do not.

**Applicable models:** GMV6, GMV5, GMV5S, TOPS, GMV water Series

**Fault diagnosis:**

In a multi-module system, the fault of any module will cause any other properly operating modules to display the fault code. It indicates that some other module has a fault, thereby causing the shutdown of the unit to ensure safe operation.


**Possible causes:**

- Other modules have faults, thereby causing the unit to stop operation.

**Troubleshooting:**

Troubleshoot other modules.

## 2.101 "J1" Compressor 1 Over-current Protection


**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit display 

**Fault diagnosis:**

When the operating current of the compressor detected by the current sensor or circuit exceeds the limit, the unit will stop working.


**Possible causes:**

- The unit's parameters are abnormal;
- The drive module is abnormal;
- The compressor is abnormal.

**Troubleshooting:**

## 2.102 "J2" Compressor 2 Over-current Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the operating current of the compressor detected by the current sensor or circuit exceeds the limit, the unit will stop working.

### Possible causes:


- The unit's parameters are abnormal;
- The drive module is abnormal;
- The compressor is abnormal.

### Troubleshooting:



## 2.103 "J3" Compressor 3 Over-current Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the operating current of the compressor detected by the current sensor or circuit exceeds the limit, the unit will stop working.

### Possible causes:


- The unit's parameters are abnormal;
- The drive module is abnormal;
- The compressor is abnormal.

### Troubleshooting:



## 2.104 "J4" Compressor 4 Over-current Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the operating current of the compressor detected by the current sensor or circuit exceeds the limit, the unit will stop working.

### Possible causes:


- The unit's parameters are abnormal;
- The drive module is abnormal;
- The compressor is abnormal.

### Troubleshooting:



## 2.105 "J5" Compressor 5 Over-current Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the operating current of the compressor detected by the current sensor or circuit exceeds the limit, the unit will stop working.

### Possible causes:


- The unit's parameters are abnormal;
- The drive module is abnormal;
- The compressor is abnormal.

### Troubleshooting:



## 2.106 "J6" Compressor 6 Over-current Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the operating current of the compressor detected by the current sensor or circuit exceeds the limit, the unit will stop working.

### Possible causes:


- The unit's parameters are abnormal;
- The drive module is abnormal;
- The compressor is abnormal.

### Troubleshooting:



## 2.107 "J7" Four-way Valve Air Backflow Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit




### Fault diagnosis:

When the difference between the system high pressure and low pressure during operation detected by the pressure sensor is less than 0.1 MPa, the unit will stop running to ensure safe operation.

### Possible causes:

- The coil or connecting wire is abnormal;
- The main board is abnormal;
- The four-way valve is abnormal.


### Troubleshooting:





## 2.108 "J8" High Pressure Ratio Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the ratio between the system high pressure and the low pressure during operation detected by the pressure sensor exceeds 8, the unit will stop running to ensure safe operation.

### Possible causes:

- The pressure sensor is abnormal;
- The ambient temperature where the unit operates exceeds the limit.

### Troubleshooting:



## 2.109 "J9" Low Pressure Ratio Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

When the ratio between the system high pressure and the low pressure during operation detected by the pressure sensor is smaller than 1.8, the unit will stop running to ensure safe operation.

### Possible causes:

- The pressure sensor is abnormal;
- The ambient temperature where the unit operates exceeds the limit.

### Troubleshooting:



## 2.110 "L0" Indoor Unit Fault (Unified)

**Fault display:** wired controller of indoor unit displays



**Applicable models:** all indoor units


### Possible causes:

- The indoor unit is faulty.

### Troubleshooting:

When multiple indoor units are installed in the same place, you can use the function of "indoor unit engineering SN query and fault indoor unit identification" to fast locate the faulty indoor unit or the corresponding indoor unit controlled by a wired controller. The detailed operations are as follows:

"C01" indoor unit engineering SN and fault query:



## NOTES!

- ① If the enquired IDU is normal, no fault code will be displayed in the temperature area; if the unit indoor has multiple faults, fault codes will be displayed in the temperature area at an interval of 3 seconds.
- ② Press the "ON/OFF" button on the interface of IDU project number and fault enquiry to exist the parameter enquiry interface.

## 2.111 "L1" Indoor Fan Protection



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Applicable models:** all indoor units


**Fault diagnosis:**

Check whether the indoor unit rotates slowly or stops or whether there exists external fan protection signal. If yes, it indicates the indoor fan protection.

**Possible causes:**

- The motor stops or is stuck
- The main board of indoor unit operates improperly

**Troubleshooting:**



## 2.112 "L2" E-heater Protection (Reserved Code, Not Yet Applied)

## 2.113 "L3" Overflow Protection



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Applicable models:** all indoor units


**Fault diagnosis:**

When the water level is too high, the float switch of indoor unit will be triggered for overflow protection.

**Possible causes:**

- The indoor unit is installed improperly;
- The drain pump is damaged;
- The float switch operates improperly;
- The main board of indoor unit operates improperly.

**Troubleshooting:**



## 2.114 "L4" Supply Power Over-current Protection



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Applicable models:** all indoor units


**Fault diagnosis:**

When the current supplied to the wired controller by the indoor unit is too large, the fault is generated.

**Possible causes:**

- The wires of the wired controller are short circuited;
- The main board of indoor unit operates improperly;
- The main board of the wired controller is abnormal.

**Troubleshooting:**



## 2.115 "L5" Antifreeze Protection



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Applicable models:** all indoor units


**Fault diagnosis:**

When the pipe temperature of the indoor unit is too low, the unit will trigger antifreeze protection to prevent the evaporator from freezing.

**Possible causes:**

- The indoor filter and evaporator are dirty;
- The indoor motor is stuck;
- Insufficient refrigerant in the unit;
- The ambient temperature where the indoor unit and outdoor unit operate is too low.

**Troubleshooting:**



## 2.116 "L6" Mode Conflict (Reserved)

## 2.117 "L7" No Master Indoor Unit

**Fault display:** wired controller of indoor unit and receiver of indoor unit display



**Applicable models:** all indoor units


**Fault diagnosis:**

The unit triggers the "no master indoor unit" fault when no master indoor unit exists in the system.

**Possible causes:**

- The master indoor unit is disconnected;
- The main board of the master indoor unit is replaced;
- The main board of the master indoor unit is faulty.

**Troubleshooting:**





## 2.118 "L9" Inconsistent Number of Indoor Units Under Integrated Control



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Applicable models:** all indoor units


**Fault diagnosis:**

When more than 16 indoor units are connected to the wired controller or the number of indoor units connected to the wired controller is not the same as what is configured under integrated control, the fault is generated.

**Possible causes:**

- More than 16 indoor units are connected to one wired controller;
- The number of indoor units connected to the wired controller is not the same as what is configured under integrated control.

**Troubleshooting:**



## 2.119 "LA" Inconsistent Series of Indoor Units Under Integrated Control



**Fault display:** wired controller of indoor unit and receiver of indoor unit display

**Applicable models:** all indoor units

**Fault diagnosis:**

When the wired controller detects that the multiple indoor units connected to it belong to different series, the fault is generated.

**Possible causes:**

- The multiple indoor units connected to the wired controller belong to different series.

**Troubleshooting:**

Make sure that the multiple indoor units connected to the wired controller belong to the same series.

## 2.120 "LH" Poor Air Quality Alarm (Reserved Code, Not Yet Applied)

## 2.121 "LC" Unmatched Models of Indoor and Outdoor Units

**Fault display:** wired controller of indoor unit and receiver of indoor unit display



**Applicable models:** some indoor units

**Fault diagnosis:**

The unit triggers the fault of "unmatched indoor and outdoor units" when it fails to recognize some indoor units or equipment.

**Possible causes:**

- The indoor unit is incompatible with the outdoor unit.

**Troubleshooting:**

The unit triggers the fault when it is connected to indoor units or equipment that it cannot recognize, such as floor heating in a modular DC inverter VRF system. In this case, to troubleshoot this fault, you can remove the involved indoor units or change the outdoor unit to make it match the indoor units.

## 2.122 "LL" Water Flow Switch Error

**Error display:** wired controller of hydro box will display



**Applicable model:** hydro box


**Error judgment condition and method:**

Detect if the protection signal of water flow switch is triggered. After turning on the water pump, waterflow switch protection signal is detected in 15 consecutive seconds, then report alarm.

**Possible reasons:**

- Poor contact between limit switch and terminal in main board interface
- Water return of generator is not smooth or lacking water
- Water flow switch is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**



## 2.123 "LF" Shunt Valve Setting Error

**Error display:** wired controller of hydro box will display



**Applicable model:** hydro box

**Error judgment condition and method:**

When setting the corresponding relationship for the floor heating shunt valve and IDU, the generator shall detect and judge the project code of IDU to see if the nonexistent project code is set or shunt valve setting error alarm occurs if the same shunt valve is matching with several IDUs (project code)

**Possible reasons**

- IDU linked with floor heating is offline
- Project code conflict or IP conflict

**Troubleshooting**

Step 1: check if the IDU corresponding to the shunt valve is offline, if yes, the IDU is deemed offline;

Step 2: check if the project code or IP is conflict, if yes, adjust the relationship between shunt valve and IDU again, allow several shunt valves to match with the same IDU (project code), but never allow the same shunt valve to match with several IDUs (project code).

## 2.124 "LU" Inconsistent IDU Branch Connecting to the Wired Controller Which Controls Multiple Indoor Units of Heat Recovery System

**Error display:** wired controller will display



**Applicable model:** wired controller connecting to several IDUs

**Error judgment condition and method:**

When the controller which controls multiple indoor units is connected to several indoor units, different indoor units are connected under different mode exchangers, or connected under different branches of the same mode exchanger.

**Possible reasons:**

- Indoor unit connecting to the wired controller which controls multiple indoor units is not in the same branch of the same mode exchanger
- Communication connection between the IDU and mode exchanger connected to the wired controller which controls multiple indoor units is wrong

**Troubleshooting:**

Step 1: check if the indoor unit connected to the wired controller which controls multiple indoor units in the same branch of the same mode exchanger, if no, please connect the indoor units under different branches to different wired controllers;

Step 2: if the indoor unit connected to the wired controller which controls multiple indoor units is in the same branch of the same mode exchanger, please check if the indoor unit communication cord connected to the communication port of the corresponding branch of mode exchanger, if no, please revise the connection of communication cord;

## 2.125 "Ln" Lifting Panel Return Air Frame Reset Error

**Error display:** IDU lamp panel and IDU wired controller will display



**Applicable model:** multi VRF indoor unit with the lifting panel


**Error judgment condition and method:**

Report alarm by judging the status of limit switch 1 and 2.

**Possible reasons:**

- Poor contact between limit switch and terminal in main board interface
- Limit switch is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**



## 2.126 "n0" System Energy Efficiency Running Settings Status

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display

**Fault diagnosis:**

This is a status code of a function. It indicates that the unit has entered energy efficiency state. "00" indicates comfort as priority; "01" indicates energy efficiency as priority, in which case the unit is up to 15% more efficient.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.127 "n2" Settings Status of Maximum Capacity Configuration Rate for Indoor and Outdoor Units

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**


This is a status code of a function. It indicates that the unit has entered settings status of maximum capacity configuration rate for indoor and outdoor units.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.128 "n4" Settings Status of Maximum Output Capacity

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

This is a status code of a function. It indicates that the unit has entered settings status of maximum output capacity. "10" indicates the maximum output capacity of 100%; "09" indicates the maximum output capacity of 90%; and "08" indicates the maximum output capacity of 80%.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.129 "n6" Unit Fault Query Status

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**


The code is a query status code. It indicates that the unit has entered unit fault query state. In this case, you can query five historical faults of indoor and outdoor units. Keep in mind that you have to query the faults respectively for indoor units and outdoor units.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.130 "n7" Unit Parameter Query Status

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

The code is a query status code. It indicates that the unit has entered unit parameter query state.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.131 "n8" Indoor Unit Engineering SN Query

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:**

The code is a query status code. It indicates that the unit has entered "indoor unit engineering SN query" state. In this case the wired controller displays engineering SN of the indoor unit, the buzzer of which sounds at the same time.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.132 "n9" Status of Querying Number of Online Indoor Units

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

The code is a query status code, in which case you can query the number of online indoor units.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.133 "nA" Heating and Cooling Unit

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

The code indicates that the indoor unit operates in both heating and cooling modes.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.134 "nH" Heating Only Unit

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

The code indicates that the indoor unit only operates in heating mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.135 "nC" Cooling Only Unit

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

The code indicates that the indoor unit only operates in cooling mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.136 "nE" Negative Number Code

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

The code is a negative number code. It indicates that the number following the code is a negative one.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.137 "nF" Fan Type Unit

**Fault display:** main board of outdoor unit displays



**Fault diagnosis:**

The code indicates that the indoor unit only operates in fan mode.

**Possible causes:** --

**Troubleshooting:** not required.

## 2.138 "o3" IDU IPM Module Protection

**Error display:** ODU main board and IDU wired controller will display




**Applicable model:** external drive DC fan

**Error judgment condition and method:**

Check the error code on the display board, if it displays o3, that's the IDU IPM module protection.

**Possible reasons:**

- Contact of the fan UVW wire is poor.
- The fan is damaged;
- The fan blade is blocked (the fan blade is blocked and the motor shaft is rusty)
- The fan drive board is abnormal.

**Troubleshooting:****2.139 "o7" IDU Non-synchronism Protection**

**Error display:** ODU main board and IDU wired controller will display



**Applicable model:** external drive DC fan


**Error judgment condition and method:**

Check the error code on the display board, if it displays o7, that's the IDU non-synchronism protection.

**Possible reasons:**

- Contact of the fan UVW wire is poor;
- The fan is damaged;
- The fan blade is blocked (the fan blade is blocked and the motor shaft is rusty)
- Fan drive board is abnormal.



**Troubleshooting:**

## 2.140 "o8" IDU Drive Communication Error

**Error display:** ODU main board and IDU wired controller will display




**Applicable model:** external drive DC fan


**Error judgment condition and method:**

If the drive does not receive main control data in 30 consecutive seconds, it will report communication error.

**Possible reasons:**

- Poor contact between drive board and main control board communication terminal
- Circuit is abnormal

**Troubleshooting:****2.141 "o9" IDU Main Control Communication Error**

**Error display:** ODU main board and IDU wired controller will display 


**Applicable model:** multi VRF IDU with DC motor

**Error judgment condition and method:**

If the main control does not receive data in 30 consecutive seconds, it will report communication error; if the drive does not receive data in 30 consecutive seconds, it will report communication error.

**Possible reasons:**

- Poor contact between main control board and drive board communication terminal
- Detecting circuit is abnormal

**Troubleshooting:**

## 2.142 "P0" Compressor Drive Board Fault

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:** If the fault code displayed on the wired controller of the indoor unit is PO, check the fault code displayed on the 2-digit digital LED of the main control board of the outdoor unit, based on which you are able to identify the specific fault of the compressor drive board. Then, troubleshoot the fault according to the corresponding troubleshooting methods.

**Possible causes:**

- Compressor drive module reset protection (2-digit digital LED of the main control board of the outdoor unit displays P3);
- Temperature sensor fault of compressor drive (2-digit digital LED of the main control board of the outdoor unit displays P7);
- IPM over temperature protection for the compressor drive (2-digit digital LED of the main control board of the outdoor unit displays P8);
- Current detection circuit fault of compressor drive (2-digit digital LED of the main control board of the outdoor unit displays PC);
- Charging loop fault of compressor drive (2-digit digital LED of the main control board of the outdoor unit displays PF);
- Loss of synchronization protection for the inverter compressor (2-digit digital LED of the main control board of the outdoor unit displays P9);
- Inverter compressor startup failure (2-digit digital LED of the main control board of the outdoor unit displays PJ).

**Troubleshooting:** based on the faults displayed on the main board of the outdoor unit.

## 2.143 "P1" Malfunctioning Compressor Drive Board

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:**

If the fault code displayed on the wired controller of the indoor unit is P1, check the fault code displayed on the 2-digit digital LED of the main control board of the outdoor unit, based on which you are able to identify the specific fault of the compressor drive board. Then, troubleshoot the fault according to the corresponding troubleshooting methods.

**Possible causes:**

- Inverter compressor over-current protection (2-digit digital LED of the main control board of the outdoor unit displays P5);
- IPM module protection for the compressor drive (2-digit digital LED of the main control board of the outdoor unit displays P6);
- Communication fault of compressor drive (2-digit digital LED of the main control board of the outdoor unit displays C2).

**Troubleshooting:** based on the faults displayed on the main board of the outdoor unit.

## 2.144 "P2" Input Voltage Protection for the Compressor Drive Board

**Fault display:** wired controller of indoor unit displays



**Fault diagnosis:**

If fault code displayed on the wired controller of the indoor unit is P2, check the fault code displayed on the 2-digit digital LED of the main control board of the outdoor unit, based on which you are able to identify the specific fault of the compressor drive board. Then, troubleshoot the fault according to the corresponding troubleshooting methods.

**Possible causes:**

- Over voltage protection for the DC bus of compressor drive (2-digit digital LED of the main control board of the outdoor unit displays PH);
- Under voltage protection for the DC bus of compressor drive (2-digit digital LED of the main control board of the outdoor unit displays PL).

**Troubleshooting:** based on the faults displayed on the main board of the outdoor unit.

## 2.145 "P3" Reset Protection for the Compressor Drive Module

**Fault display:** main board of outdoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is P3, it indicates the reset protection for the compressor drive board.

**Possible causes:**

- The compressor drive operates improperly

**Troubleshooting:**



## 2.146 "P5" Inverter Compressor Over-current Protection

**Fault display:** main board of outdoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is P5, it indicates the over-current protection for the inverter compressor.

**Possible causes:**

- Poor contact of compressor's UVW cables;
- The compressor's UVW cables are wrongly connected;
- The compressor is damaged;
- The system is blocked;
- IPM module of the compressor drive board is damaged.

**Troubleshooting:**



## 2.147 "P6" IPM Module Protection for the Compressor Drive



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is P6, it indicates the IPM module protection for the compressor drive.

**Possible causes:**

- Poor contact of compressor's UVW cables;
- The compressor's UVW cables are wrongly connected;
- The compressor is damaged;
- The system is blocked;
- IPM module of the compressor drive board is damaged.

**Troubleshooting:**



## 2.148 "P7" Abnormal Temperature Sensor of Compressor Drive Board



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is P7, it indicates the abnormal temperature sensor of compressor drive board.

**Possible causes:**

- The compressor drive board operates improperly.

**Troubleshooting:**



## 2.149 "P8" IPM Over Temperature Protection for Compressor Drive Board




**Fault display:** main board of outdoor unit displays

**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is P8, it indicates the IPM over temperature protection for the compressor drive.

**Possible causes:**

- The IPM module's screws are not tightened;
- The IPM module is not covered, or unevenly covered by thermal grease, or covered by dried thermal grease;
- The compressor drive board operates improperly.

**Troubleshooting:**

## 2.150 "P9" Loss of Synchronization Protection for Inverter Compressor



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is P9, it indicates the loss of synchronization protection for the inverter compressor.

**Possible causes:**

- The compressor drive board operates improperly.
- The compressor is damaged.



**Troubleshooting:**

## 2.151 "PC" Current Detection Circuit Fault of Compressor Drive



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is PC, it indicates the current detection circuit fault of compressor drive.

**Possible causes:**

- The compressor drive board operates improperly.

**Troubleshooting:**



## 2.152 "PH" Over Voltage Protection for DC Bus of Compressor Drive



**Fault display:** main board of outdoor unit displays


**Fault diagnosis:**

When the input power cable of the main board has a voltage over 460 V, the unit triggers protection against faults.

**Possible causes:**

- The unit's input power cable has a voltage exceeding 460 V;
- The compressor drive board operates improperly.

**Troubleshooting:**



## 2.153 "PL" Under Voltage Protection for DC Bus of Compressor Drive

**Fault display:** main board of outdoor unit displays



Applicable models: GMV6, GMV5, GMV5S series


**Fault diagnosis:**

When the input power cable of the main board has a voltage below 320 V, the unit triggers protection against faults.

**Possible causes:**

- The unit's input power cable has a voltage below 320V;
- The compressor drive board operates improperly.

**Troubleshooting:**



## 2.154 "PJ" Inverter Compressor Startup Failure

**Fault display:** main board of outdoor unit displays




**Fault diagnosis:**

If the fault code displayed on the 2-digit digital LED of the outdoor unit's main control board is PJ, it indicates the inverter compressor startup failure.

**Possible causes:**

- Poor contact of compressor's UVW cables;
- The compressor is damaged;
- The compressor drive board operates improperly.

**Troubleshooting:**

## 2.155 "U0" Insufficient Warm-up Time for Compressor

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

When the oil preheating period of time before compressor starts is less than eight hours, the unit generates a fault.

**Possible causes:** --

**Troubleshooting:** Warm up the whole unit for more than eight hours before startup.

## 2.156 "U2" Incorrect Settings of Outdoor Unit Capacity DIP Switch/Jumper Cap

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Applicable models:** all outdoor units

**Fault diagnosis:**

When the capacity DIP switch detected by the outdoor unit's main board is inconsistent with the unit's actual capacity, or the jumper cap value detected by the outdoor unit's main board is inconsistent with the actual unit, the fault is generated.


**Possible causes:**

- Capacity DIP switch error or jumper cap error (for some models without jumper caps, jumper cap error is not detected)

- DIP switch or jumper cap is broken

- Abnormal detection circuit

**Troubleshooting:**



## 2.157 "U3" Power Phase-Sequence Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


### Fault diagnosis:

Check the three-phase power of the unit. If the power is connected incorrectly, thereby causing phase loss or reverse phase, the unit generates a fault.

### Possible causes:

- The power is connected wrongly or phase loss or reverse phase occurs
- Abnormal detection circuit

### Troubleshooting:



## 2.158 "U4" Refrigerant Loss Protection

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

### Fault diagnosis:

Check the high pressure and the low pressure of the unit by the pressure sensor. If the temperatures corresponding to the high pressure and the low pressure of the unit are below the ambient temperature for over 5, the unit will not start operation for safety purpose.

### Possible causes:

- Insufficient refrigerant in the unit;
- The pipes leak.

**Troubleshooting:****2.159 "U6" Abnormal Valve Prompt**

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

During commissioning process, determine whether the check valve of the outdoor unit is open by detecting the unit's parameters by the pressure sensor. If the parameters are abnormal, the unit prompts you to confirm whether you want to open the check valve again. After confirmation, press SW4 to proceed.

**Possible causes:**

- The check valve of the outdoor unit is not open.

Troubleshooting: Reconfirm and open the check valve of the outdoor unit.

**2.160 "U8" Abnormal Pipes of the Indoor Unit**

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

**Fault diagnosis:**

During commissioning process, check the temperature of the indoor unit's pipes to determine whether the pipes are blocked. Any abnormal parameters found would indicate that the unit has the fault.

**Possible causes:**

- The electronic expansion valve operates improperly;
- The indoor unit's pipes are blocked.

**Troubleshooting:****2.161 "U9" Abnormal Pipes of Outdoor Unit**

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit


display 

**Fault diagnosis:**

During commissioning process, check the pressure of the unit to determine whether the pipes of the outdoor unit are blocked. Any abnormal parameters found would indicate that the unit has the fault.

**Possible causes:**

- The electronic expansion valve operates improperly;
- The outdoor unit's pipes are blocked.

**Troubleshooting:**



## 2.162 "UC" Master Indoor Unit Set Successfully

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

The code indicates the state of the unit rather than the fault. During the commissioning process, the unit prompts that the master indoor unit is already set successfully.

**Possible causes:** --

**Troubleshooting:** --

## 2.163 "UL" DIP Switch Error of Compressor Emergency Operation

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 

**Fault diagnosis:**

The fault is displayed when the DIP switch of compressor emergency operation is not set within the reasonable range.

**Possible causes:** --

**Troubleshooting:** Re-dial the DIP switch according to the DIP switch table.

## 2.164 "UE" Auto Refrigerant Charging Void

**Fault display:** main board of outdoor unit, wired controller of indoor unit and receiver of indoor unit

display 


**Fault diagnosis:**

The code is displayed when the outdoor ambient temperature exceeds the range of auto refrigerant charging (the normal range of charging refrigerant automatically is 0-40°C).

**Possible causes:** --

**Troubleshooting:** Disable the auto refrigerant charging. Instead, charge the refrigerant manually.

## 2.165 "UF" Mode Exchanger IDU Identification Abnormal

**Error display:** mode exchanger main board will display 

**Applicable mode:** mode exchange box

**Error judgment condition and method:**

IDU main board is not compatible with the mode exchange box main board, which might trigger the identification abnormality error of mode exchanger IDU.

**Possible reasons:**

- IDU and mode exchanger is not compatible
- Mode exchanger main board is damaged


**Troubleshooting:**

Step 1: replace mode exchanger main board to see if the error is solved;

Step 2: if UF error still exists after replacing mode exchanger main board, disconnect the communication connection of all IDUs and mode exchangers, connect the IDU communication cord one by one to the communication board of mode exchanger until all the IDUs which have triggered the UF error are tested;

Step 3: update the program for the IDU which triggers UF error or replace the main board.

## 2.166 "y7" Fresh Air Inlet Temperature Sensor Error

**Error display:** ODU main board and IDU wired controller will display 


**Applicable model:** multi VRF indoor unit with fresh air function

**Error judgment condition and method:**

Sample the AD value of temperature sensor through temperature sensor detecting circuit and judge the range of AD value. If the sampling AD value exceeds upper limit and lower limit in 5 seconds continuously, report the error

**Possible reasons:**

- Poor contact between air inlet temperature sensor and main board interface terminal
- Air inlet temperature sensor is abnormal
- Detecting circuit is abnormal

**Troubleshooting:**

## 2.167 "yA" IFD Error

**Error display:** ODU main board and IDU wired controller will display



**Applicable model:** high-end fresh air floor standing unit


**Error judgment condition and method:**

After turning on the IFD for 60s, start the error feedback test, if the IFU feedback tested in 5 consecutive seconds is low level, it's deemed that IFD is faulted.

**Possible reasons:**

- Poor contact between IFD feedback side and main board interface terminal
- IFD abnormality
- Detecting circuit is abnormal

**Troubleshooting:**



## 2.168 "y8" Indoor Air Box Sensor General Error

**Error display:** ODU main board and IDU wired controller will display



**Applicable model:** IDU with air box


**Error judgment condition and method:**

Main board, air box communication abnormality and air box test data (temperature, humidity and CO<sub>2</sub> concentration or PM2.5 concentration) has exceeded the set upper and lower limiting value.

**Possible reasons:**

- Poor contact between main control board and air box communication terminal
- Air box detection is abnormal

**Troubleshooting:**



## 2.169 Ineffective Cooling and Heating

**Applicable models:** all indoor units


**Fault diagnosis:**

- 1) In cooling mode, when the electronic expansion valve is open to 2000PLS, the temperature of outlet pipes of the indoor unit coil is over 5°C greater than the temperature of inlet pipes of the indoor unit coil;
- 2) In heating mode, when the electronic expansion valve is open to 2PLS, the temperature of inlet pipes of the indoor unit coil is over 12°C less than the saturation temperature corresponding to the high pressure;

**Possible causes:**

- The check valve of the outdoor unit is not opened fully as required.
- The unit pipes are clogged.
- The unit operates out of the range of required ambient temperature.
- Airflow organization is set ineffectively.
- The amount of refrigerant is insufficient.

**Troubleshooting:**



## 2.170 No Faults Displayed But Compressor Not Starting in Cooling/Heating Mode

**Error display:** no error displayed but compressor not starting in cooling / heating mode

**Applicable model:** all ODUs

**Error judgment condition and method:**

Under shutdown status, the high pressure sensor has detected that the high pressure of the module is 55°C or higher, or the discharge temperature sensor / shell top temperature sensor has detected that the temperature is 105°C or higher.

**Possible reasons:**

- The ambient temperature is 55°C or higher;
- The temperature of the compressor is 105°C or higher;
- High pressure sensor is abnormal;
- Temperature sensor is abnormal;

**Troubleshooting:**

Step 1: confirm the ambient temperature is below 55°C, otherwise the compressor cannot start;

Step 2: detect the temperature of the compressor, if the temperature is over 104°C, the compressor cannot start;

Step 3: if the above inspections are normal, connect the multi-functional debugger;

Step 4: if the high pressure of the module is 55 or higher, replace the high pressure sensor;

Step 5: if the discharge temperature / shell top temperature of the compressor is 105 or higher, replace the temperature sensor.

### 3 Non-fault Type Troubleshooting

#### WARNING

- (1) If an abnormal situation (such as peculiar smell) occurs, please stop the operation immediately and turn off the main power supply, and then contact Gree authorized maintenance center. If the unit continues to operate under abnormal situation, the air conditioner will be damaged and an electric shock or fire accident may result.
- (2) Do not maintain the air conditioner by yourself, misoperation may cause electric shock or fire hazard. Please contact professional personnel of Gree authorized maintenance center to maintain.

- Before asking for maintenance, please check the following issues first.

| Phenomenon   | Causes   | Troubleshooting   |
|--|--|---|
| Air conditioner can't operate                                  | Fuse is broken or circuit breaker is open                      | Replace fuse or close the circuit breaker                             |
|  | Power failure  | Restart up the unit and then the unit will operate                    |
|  | Power supply is not connected                                  | Connect the power supply  |
|  | The power for batteries of remote controller is insufficient   | Replace the batteries   |
|  | Remote controller is not within the remote control range       | Remote control range is within 8m                                     |
| Air conditioner operates, while it stops operation immediately | Air inlet or air outlet of indoor unit/outdoor unit is blocked | Eliminate the obstacles   |
| Cooling or heating is abnormal                                 | Air inlet or air outlet of indoor unit/outdoor unit is blocked | Eliminate the obstacles   |
|  | Temperature setting is improper                                | Adjust temperature setting by remote controller or wired controller   |
|  | Fan speed is set too low                                       | Adjust fan speed setting by remote controller or wired controller     |
|  | Fan direction is not correct                                   | Adjust fan direction setting by remote controller or wired controller |
|  | Door or window is open   | Close door and window   |
|  | Direct sunshine  | Hang curtains or window shade at the window                           |
|  | Too many persons in the room                                   | —   |
|  | Too many thermal source in the room                            | Reduce the thermal source   |
|  | The filter is dirty and blocked                                | Clean the filter  |

## NOTICE

If problem cannot be solved after checking the above items, please contact Gree service center and describe the cases and models.

- Following circumstances are not malfunctions.

| Phenomenon               |  | Causes  |
|--------------------------|--|---|
| Unit doesn't run         | When unit is started immediately after it is just turned off   | Overload protection switch makes it run after 3 minutes delay   |
|                          | When power is turned on  | Standby operating for about 1 minute  |
| Mist comes from the unit | Under cooling  | Indoor high humidity air is cooled rapidly  |
| Noise is emitted         | When the power supply is connected, there is small "dada" sound.   | It is the sound of startup action of electronic expansion valve.  |
|                          | When the system is conducting cooling or defrosting, there is continuous "sa——" sound.   | This is the sound of refrigerant flowing inside the unit.   |
|                          | When the system is switching cooling and heating modes; during heating operation, the unit enters or quits defrosting operation or oil return operation, there is "chi——" sound.             | This is the sound for direction reversal of 4-way valve.  |
| Noise is emitted         | When the system is started or stopped for a short time, you can hear the sound of "sa——"; you can also hear this sound for a short time after the start or stop of the defrosting operation. | This is the sound produced when the refrigerant stops or changes the flow.  |
|                          | When the system is in cooling operation or after it stops running, a continuous "sa ——" sound can be heard   | This is the operation sound of drain system.  |
|                          | When the system is running or after it stops running, a "creaking" sound can be heard.   | This is the sound produced when plastic parts such as panel expansion and contraction due to temperature changes.   |
|                          | When the system is in heating operation, after the indoor unit stops running, the sound like running water can be heard.   | The unit is melting the frost on the outdoor unit, please wait about 10 minutes (due to different unit models, the waiting time will vary).   |
|                          | When the indoor unit stops running, a faint "sa——" sound or "gurgling" sound can be heard.   | This sound can be heard when other indoor units are running. This is to prevent oil and refrigerant from staying in the indoor unit, and to keep a small amount of refrigerant flowing. |
|                          | When the unit is running, the operating sound of the compressor changes.   | This is caused by changes in compressor operating frequency.  |
|                          | During the operation of the unit or after the operation is started or stopped, a continuous "sa ——" sound can be heard.  | This is the sound produced when the refrigerant bypass valve operates.  |
|                          | When the operating mode of the unit changes, the indoor unit and outdoor unit will produce "sa ——" and "gurgling" sounds.  | This is the sound produced when the refrigerant stops or changes flow.  |
|                          | The sound from the outdoor unit can be heard indoors   | This is because the outdoor unit is installed close to the window or wall, and the sound insulation is poor, and the external noise is transmitted in.                                  |



| Phenomenon   |  | Causes  |
|--|--|---|
| There is dust blowing out from the unit              | Start operation after it is not used for a long time | Dust in indoor unit is blew out   |
| The unit emits odor                                  | Operating  | The odor of the air conditioner is sucked into the room and then blown out  |
| The indoor unit is still running after shutting down | The indoor unit is still running after shutting down | The fan of indoor unit will continue to work for 20 to 70 seconds to fully use the residual cooling or heat of the heat exchanger, and to prepare for the next use.   |
| Mode conflict  | Cooling or heating mode cannot start up              | When the selected operation mode of the indoor unit conflicts with the operation mode of the outdoor unit, after five seconds, the indoor unit error indicator flashes or the remote controller displays the operation conflict, and the indoor unit shuts down. At this time, the indoor unit can be converted to run with the outdoor unit. The mode can be restored to normal without conflict. The cooling mode and dry mode do not conflict, and the air supply does not conflict with any mode. |
| Wired controller displays A3 code                    | Unit enters frost mode operation                     | During cold weather heating operation, when frost or ice may form on the outdoor unit heat exchanger, the unit will automatically enter the defrost mode for a few minutes.   |
| Wired controller displays A4 code                    | Unit enters oil-return mode operation                | When the outdoor unit runs for a certain time, it will automatically enter the oil return mode to run for a few minutes to ensure that the internal compression of the external machine is effectively lubricated.  |

# Chapter 4 Maintenance



## WARNING!

During the maintenance of a modular unit, all the outside units must be powered on and off concurrently. Avoid doing so to only some of the outdoor units.

## 1 Minimum Room Area for R32 Unit

### 1.1 Calculation Method of Releasable Charge ( $m_{REL}$ )

Area of the room where the indoor unit is installed must meet the minimum room area in the following table:

| Releasable Charge (kg) | Minimum Room Area (m <sup>2</sup> / ft <sup>2</sup> ) |              |              |              |
|------------------------|---|--------------|--------------|--------------|
|                        | $H_{inst} < 2.2m$                                     |              |              |              |
|                        | H=1.6m  | H=1.8m       | H=2.0m       | H=2.2m       |
| 2                      | 8.2 / 88.0  | 7.3 / 78.2   | 6.6 / 70.4   | 6.0 / 64.0   |
| 2.2                    | 9.0 / 96.8  | 8.0 / 86.0   | 7.2 / 77.4   | 6.6 / 70.4   |
| 2.4                    | 9.9 / 105.6   | 8.8 / 93.9   | 7.9 / 84.5   | 7.2 / 76.8   |
| 2.6                    | 10.7 / 114.4  | 9.5 / 101.7  | 8.5 / 91.5   | 7.8 / 83.2   |
| 2.8                    | 11.5 / 123.2  | 10.2 / 109.5 | 9.2 / 98.5   | 8.4 / 89.6   |
| 3                      | 12.3 / 132.0  | 10.9 / 117.3 | 9.9 / 105.6  | 9.0 / 96.0   |
| 3.2                    | 13.1 / 140.8  | 11.7 / 125.1 | 10.5 / 112.6 | 9.6 / 102.4  |
| 3.4                    | 13.9 / 149.5  | 12.4 / 132.9 | 11.2 / 119.6 | 10.2 / 108.8 |
| 3.6                    | 14.8 / 158.3  | 13.1 / 140.8 | 11.8 / 126.7 | 10.7 / 115.2 |
| 3.8                    | 15.6 / 167.1  | 13.8 / 148.6 | 12.5 / 133.7 | 11.3 / 121.6 |
| 4                      | 16.4 / 175.9  | 14.6 / 156.4 | 13.1 / 140.8 | 11.9 / 128.0 |
| 4.2                    | 17.2 / 184.7  | 15.3 / 164.2 | 13.8 / 147.8 | 12.5 / 134.4 |
| 4.4                    | 18.0 / 193.5  | 16.0 / 172.0 | 14.4 / 154.8 | 13.1 / 140.8 |
| 4.6                    | 18.8 / 202.3  | 16.8 / 179.8 | 15.1 / 161.9 | 13.7 / 147.2 |
| 4.8                    | 19.7 / 211.1  | 17.5 / 187.7 | 15.7 / 168.9 | 14.3 / 153.5 |
| 5                      | 20.5 / 219.9  | 18.2 / 195.5 | 16.4 / 175.9 | 14.9 / 159.9 |
| 5.2                    | 21.3 / 228.7  | 18.9 / 203.3 | 17.0 / 183.0 | 15.5 / 166.3 |
| 5.4                    | 22.1 / 237.5  | 19.7 / 211.1 | 17.7 / 190.0 | 16.1 / 172.7 |
| 5.6                    | 22.9 / 246.3  | 20.4 / 218.9 | 18.4 / 197.0 | 16.7 / 179.1 |
| 5.8                    | 23.7 / 255.1  | 21.1 / 226.7 | 19.0 / 204.1 | 17.3 / 185.5 |
| 6                      | 24.6 / 263.9  | 21.8 / 234.6 | 19.7 / 211.1 | 17.9 / 191.9 |
| 6.2                    | 25.4 / 272.7  | 22.6 / 242.4 | 20.3 / 218.1 | 18.5 / 198.3 |
| 6.4                    | 26.2 / 281.5  | 23.3 / 250.2 | 21.0 / 225.2 | 19.1 / 204.7 |
| 6.6                    | 27.0 / 290.3  | 24.0 / 258.0 | 21.6 / 232.2 | 19.7 / 211.1 |
| 6.8                    | 27.8 / 299.0  | 24.7 / 265.8 | 22.3 / 239.2 | 20.3 / 217.5 |
| 7                      | 28.6 / 307.8  | 25.5 / 273.6 | 22.9 / 246.3 | 20.8 / 223.9 |
| 7.2                    | 29.5 / 316.6  | 26.2 / 281.5 | 23.6 / 253.3 | 21.4 / 230.3 |
| 7.4                    | 30.3 / 325.4  | 26.9 / 289.3 | 24.2 / 260.4 | 22.0 / 236.7 |
| 7.6                    | 31.1 / 334.2  | 27.6 / 297.1 | 24.9 / 267.4 | 22.6 / 243.1 |

| Releasable Charge<br>(kg) | Minimum Room Area(m <sup>2</sup> / ft <sup>2</sup> ) |              |              |              |              |             |
|---------------------------|--|--------------|--------------|--------------|--------------|-------------|
|                           | H <sub>inst</sub> ≥2.2m                              |              |              |              |              |             |
|                           | H=2.2m   | H=2.5m       | H=3m         | H=3.5m       | H=4m         | H=5m        |
| 2                         | 6.0 / 64.0   | 5.3 / 56.3   | 4.4 / 47     | 3.8 / 40.3   | 3.3 / 35.2   | 2.7 / 28.2  |
| 2.2                       | 6.6 / 70.4   | 5.8 / 62.0   | 4.8 / 51.6   | 4.2 / 44.3   | 3.6 / 38.7   | 2.9 / 31    |
| 2.4                       | 7.2 / 76.8   | 6.3 / 67.6   | 5.3 / 56.3   | 4.5 / 48.3   | 4 / 42.3     | 3.2 / 33.8  |
| 2.6                       | 7.8 / 83.2   | 6.8 / 73.2   | 5.7 / 61     | 4.9 / 52.3   | 4.3 / 45.8   | 3.4 / 36.6  |
| 2.8                       | 8.4 / 89.6   | 7.4 / 78.8   | 6.2 / 65.7   | 5.3 / 56.3   | 4.6 / 49.3   | 3.7 / 39.4  |
| 3                         | 9.0 / 96.0   | 7.9 / 84.5   | 6.6 / 70.4   | 5.7 / 60.4   | 5 / 52.8     | 4 / 42.3    |
| 3.2                       | 9.6 / 102.4  | 8.4 / 90.1   | 7 / 75.1     | 6 / 64.4     | 5.3 / 56.3   | 4.2 / 45.1  |
| 3.4                       | 10.2 / 108.8   | 8.9 / 95.7   | 7.5 / 79.8   | 6.4 / 68.4   | 5.6 / 59.8   | 4.5 / 47.9  |
| 3.6                       | 10.7 / 115.2   | 9.5 / 101.4  | 7.9 / 84.5   | 6.8 / 72.4   | 5.9 / 63.4   | 4.8 / 50.7  |
| 3.8                       | 11.3 / 121.6   | 10.0 / 107.0 | 8.3 / 89.2   | 7.1 / 76.4   | 6.3 / 66.9   | 5 / 53.5    |
| 4                         | 11.9 / 128.0   | 10.5 / 112.6 | 8.8 / 93.9   | 7.5 / 80.5   | 6.6 / 70.4   | 5.3 / 56.3  |
| 4.2                       | 12.5 / 134.4   | 11.0 / 118.2 | 9.2 / 98.5   | 7.9 / 84.5   | 6.9 / 73.9   | 5.5 / 59.1  |
| 4.4                       | 13.1 / 140.8   | 11.6 / 123.9 | 9.6 / 103.2  | 8.3 / 88.5   | 7.2 / 77.4   | 5.8 / 62    |
| 4.6                       | 13.7 / 147.2   | 12.1 / 129.5 | 10.1 / 107.9 | 8.6 / 92.5   | 7.6 / 81     | 6.1 / 64.8  |
| 4.8                       | 14.3 / 153.5   | 12.6 / 135.1 | 10.5 / 112.6 | 9 / 96.5     | 7.9 / 84.5   | 6.3 / 67.6  |
| 5                         | 14.9 / 159.9   | 13.1 / 140.8 | 10.9 / 117.3 | 9.4 / 100.6  | 8.2 / 88     | 6.6 / 70.4  |
| 5.2                       | 15.5 / 166.3   | 13.6 / 146.4 | 11.4 / 122   | 9.8 / 104.6  | 8.5 / 91.5   | 6.8 / 73.2  |
| 5.4                       | 16.1 / 172.7   | 14.2 / 152.0 | 11.8 / 126.7 | 10.1 / 108.6 | 8.9 / 95     | 7.1 / 76    |
| 5.6                       | 16.7 / 179.1   | 14.7 / 157.6 | 12.3 / 131.4 | 10.5 / 112.6 | 9.2 / 98.5   | 7.4 / 78.8  |
| 5.8                       | 17.3 / 185.5   | 15.2 / 163.3 | 12.7 / 136.1 | 10.9 / 116.6 | 9.5 / 102.1  | 7.6 / 81.7  |
| 6                         | 17.9 / 191.9   | 15.7 / 168.9 | 13.1 / 140.8 | 11.3 / 120.7 | 9.9 / 105.6  | 7.9 / 84.5  |
| 6.2                       | 18.5 / 198.3   | 16.3 / 174.5 | 13.6 / 145.4 | 11.6 / 124.7 | 10.2 / 109.1 | 8.2 / 87.3  |
| 6.4                       | 19.1 / 204.7   | 16.8 / 180.2 | 14 / 150.1   | 12 / 128.7   | 10.5 / 112.6 | 8.4 / 90.1  |
| 6.6                       | 19.7 / 211.1   | 17.3 / 185.8 | 14.4 / 154.8 | 12.4 / 132.7 | 10.8 / 116.1 | 8.7 / 92.9  |
| 6.8                       | 20.3 / 217.5   | 17.8 / 191.4 | 14.9 / 159.5 | 12.7 / 136.7 | 11.2 / 119.6 | 8.9 / 95.7  |
| 7                         | 20.8 / 223.9   | 18.4 / 197.0 | 15.3 / 164.2 | 13.1 / 140.8 | 11.5 / 123.2 | 9.2 / 98.5  |
| 7.2                       | 21.4 / 230.3   | 18.9 / 202.7 | 15.7 / 168.9 | 13.5 / 144.8 | 11.8 / 126.7 | 9.5 / 101.4 |
| 7.4                       | 22.0 / 236.7   | 19.4 / 208.3 | 16.2 / 173.6 | 13.9 / 148.8 | 12.1 / 130.2 | 9.7 / 104.2 |
| 7.6                       | 22.6 / 243.1   | 19.9 / 213.9 | 16.6 / 178.3 | 14.2 / 152.8 | 12.5 / 133.7 | 10 / 107    |

## NOTICE

- (1) H<sub>inst</sub> is the installation height of the indoor unit.
- (2) H is the floor-to-ceiling height of the room. If the H<sub>inst</sub> is <2.2m, H cannot exceed 2.2m, even if the actual height of the room is >2.2m.
- (3) If the actual releasable charge is not exactly equal to the value in the table, the larger releasable charge in the table need to be taken.
- (4) If the actual H is not exactly equal to the value in the table, the smaller H in the table need to be taken.
- (5) This manual is only applicable to a single room.
- (6) Correct the minimum room area of the space A<sub>min</sub> by multiplying by an altitude adjustment factor (AF) based on for building site ground level altitude (H<sub>alt</sub>) in meters.

| Halt | 0    | 200  | 400  | 600  | 800  | 1000 | 1200 | 1400 | 1600 |
|------|------|------|------|------|------|------|------|------|------|
| AF   | 1.00 | 1.00 | 1.00 | 1.00 | 1.02 | 1.05 | 1.07 | 1.10 | 1.12 |
| Halt | 1600 | 1800 | 2000 | 2200 | 2400 | 2600 | 2800 | 3000 | 3200 |

|    |      |      |      |      |      |      |      |      |      |
|----|------|------|------|------|------|------|------|------|------|
| AF | 1.12 | 1.15 | 1.18 | 1.21 | 1.25 | 1.28 | 1.32 | 1.36 | 1.40 |
|----|------|------|------|------|------|------|------|------|------|

(7) The minimum airflow is 240m<sup>3</sup>/h.

## 1.2 Calculation Method of Releasable Charge ( $m_{REL}$ )

The outdoor unit is equipped with automatic refrigerant cut-off valves. When the indoor unit detects refrigerant leakage, the cut-off valves will cut off the refrigerant of the outdoor unit. The releasable charge ( $m_{REL}$ ) refers to the total amount of refrigerant remaining in all indoor units and pipeline that may leak into the room.

$$m_{REL} = m_1 \text{ of all indoor units in the system} + m_2 \text{ of all pipeline in the system} + 0.204\text{kg}$$

If the calculated  $m_{REL}$  is larger than the system refrigerant amount (including the default refrigerant of indoor unit and the additional refrigerant charge), the system refrigerant amount should be used as  $m_{REL}$ .

$m_1$  of different indoor unit must refer to corresponding Owner's Manual of indoor unit.


All pipelines in the system are divided into three types A/B/C according to pipe dimension. Count the total pipe length of each type and find out  $m_2$  of corresponding type in the table below. Add up all  $m_2$  of each type to obtain the  $m_2$  of the system.

$m_2$  of pipeline:

Unit: kg

| Pipe Type                     |                | A          | B          | C          |
|-------------------------------|----------------|------------|------------|------------|
| Gas Pipe<br>mm (inch)         |                | 15.9 (5/8) | 12.7 (1/2) | 9.52 (3/8) |
| Liquid Pipe<br>mm (inch)      |                | 9.52 (3/8) | 6.35 (1/4) | 6.35 (1/4) |
| Total Pipe Length<br>m (feet) | 5 (16-3/8)     | 0.27       | 0.11       | 0.10       |
|                               | 10 (32-13/16)  | 0.54       | 0.22       | 0.20       |
|                               | 15 (49-3/16)   | 0.80       | 0.33       | 0.29       |
|                               | 20 (65-5/8)    | 1.07       | 0.43       | 0.39       |
|                               | 25 (82)        | 1.33       | 0.54       | 0.49       |
|                               | 30 (98-7/16)   | 1.60       | 0.65       | 0.58       |
|                               | 35 (114-13/16) | 1.87       | 0.75       | 0.68       |
|                               | 40 (131-1/4)   | 2.13       | 0.86       | 0.78       |
|                               | 45 (147-5/8)   | 2.40       | 0.97       | 0.87       |
|                               | 50 (164-1/16)  | 2.66       | 1.07       | 0.97       |
|                               | 55 (180-7/16)  | 2.93       | 1.18       | 1.07       |
|                               | 60 (196-7/8)   | 3.20       | 1.29       | 1.16       |
|                               | 65 (213-1/4)   | 3.46       | 1.39       | 1.26       |
|                               | 70 (229-11/16) | 3.73       | 1.50       | 1.36       |
|                               | 75 (246-1/16)  | 3.99       | 1.61       | 1.45       |
|                               | 80 (262-7/16)  | 4.26       | 1.71       | 1.55       |
|                               | 85 (278-7/8)   | 4.53       | 1.82       | 1.65       |
|                               | 90 (295-1/4)   | 4.79       | 1.93       | 1.74       |
|                               | 95 (311-11/16) | 5.06       | 2.03       | 1.84       |
|                               | 100 (328-1/16) | 5.32       | 2.14       | 1.93       |

For example:



There are four indoor units in the system:

GMV-ND24PHS/NhD-T(U)\*1 and GMV-ND12PHS/NhD-T(U)\*3.

The total length of type A pipeline L1+a is 20m. m2 of type A is 1.07kg.

The total length of type B pipeline L2+L3+b is 30m. m2 of type B is 0.65kg.

The total length of type C pipeline c+d is 10m. m2 of type C is 0.20kg.

The system refrigerant amount is 7kg.

The releasable charge ( $m_{REL}$ ) should be calculated as below:

$$m1=0.49+0.49*3=1.96\text{kg}$$

$$m2=1.07+0.65+0.20=1.92\text{kg}$$

$$m_{REL}=1.96\text{kg}+1.92\text{kg}+0.204\text{kg}=4.084\text{kg}$$

For 3 meters high room, the room area must not less than  $9.2\text{m}^2$  ( $98.5\text{ft}^2$ ). If the room area is less than  $9.2\text{m}^2$  ( $98.5\text{ft}^2$ ), measures need to be taken to make the room area meet the requirements, such as changing the piping design of the system to reduce the  $m_{REL}$ .


## 2 Vacuum Pumping, Refrigerant Adding

### ⚠ CAUTION

Do not purge the air with refrigerants but use a vacuum pump to vacuum the installation! There is no extra refrigerant in the outdoor unit for air purging!

### 2.1 Vacuum Pumping

- (1) Outdoor unit has been charged with refrigerant before delivery. Field-installed connection pipe needs to be charged with additional refrigerant.
- (2) Confirm whether outdoor liquid and gas valves are closed.
- (3) Use vacuum pump to withdraw the air inside indoor unit and connection pipe from the outdoor valve, as shown below.



## 2.2 Additional Refrigerant Charging

### NOTICE

- (1) The amount of refrigerant charged into the system before leaving the factory does not include the amount of refrigerant added to the pipelines and the outdoor unit.
- (2) The additional amount of refrigerant added to the pipelines is determined according to the size of the liquid pipe and its length on site.
- (3) Record the amount of refrigerant added to facilitate after-sales maintenance.

(1) Additional refrigerant charge  $R = \text{pipeline additional refrigerant charge } A + \text{outdoor unit additional refrigerant charge } B$

(2) Calculation of pipeline additional refrigerant charge  $A$

Pipeline additional refrigerant charge  $A = \text{liquid pipe length } (\Sigma) \times \text{additional refrigerant charge per meter of the liquid pipe.}$

X1: The length of liquid pipe  $\Phi 6.35\text{mm}(\Phi 1/4 \text{ inch})$ ;

X2: The length of liquid pipe  $\Phi 9.52\text{mm}(\Phi 3/8 \text{ inch})$ ;

| The Length of X1+X2                         | The Length of X2                            | Quantity Additional Refrigerant Charge Per Meter of the Liquid Pipe A  |
|---|---|--|
| $\leq 20\text{m}(65\text{-}5/8\text{feet})$ | $\leq 20\text{m}(65\text{-}5/8\text{feet})$ | 0  |
| $> 20\text{m}(65\text{-}5/8\text{feet})$    | $\geq 20\text{m}(65\text{-}5/8\text{feet})$ | $(X2-20\text{m}) \times 0.051\text{kg/m} + X1 \times 0.018\text{kg/m}$<br>$\{X2-(65\text{-}5/8\text{ft})\} \times 0.034\text{LBS/ft} + X1 \times 0.012\text{LBS/ft}$ |
|   | $< 20\text{m}(65\text{-}5/8\text{feet})$    | $(X1+X2-20\text{m}) \times 0.018 \text{ kg/m}$<br>$\{X1+X2-(65\text{-}5/8\text{ft})\} \times 0.012\text{LBS/ft}$   |

(3) Calculation of outdoor unit additional refrigerant charge  $B(\text{kg(LBS)})$

| Indoor Unit Quantity | Outdoor Unit Capacity(kBtu/h) |           |           |
|----------------------|-------------------------------|-----------|-----------|
|                      | 36                            | 48        | 60        |
| $\leq 4$             | 0                             | 0         | 0         |
| $\geq 5$             | 0.9(1.98)                     | 0.9(1.98) | 1.4(3.09) |

### NOTE:

The maximum refrigerant charging volume for the system can't exceed 16.5LBS (including the refrigerant charged in the factory).

Record the amount of refrigerant added to facilitate after-sales maintenance. After ensuring that the system does not leak and the compressor is not working, first charge the specified amount of R32 into the unit from the injection port of the outdoor unit liquid pipe valve until the required amount is reached. If the amount of refrigerant that needs to be added cannot be filled quickly due to pressure rise in the pipe, then power on the unit in cooling mode and charge the refrigerant through the gas valve of

the outdoor unit.

**For example:**

The ODU is composed of the module: 60 kBtu/h.

The IDUs are made up of 4 sets of 15 kBtu/h.

X1=30m(98feet), X2=15m(49feet)

The pipeline additional refrigerant charge A  $= (30+15-20) \times 0.018 = 0.45\text{kg}$

$(98+49-65-5/8) \times 0.012 = 0.97\text{LBS}$

outdoor unit additional refrigerant charge B=0kg(0LBS)

Total Additional refrigerant charge R  $= 0.45+0=0.45\text{kg}$   $(0.97+0=0.97\text{LBS})$ .




## 2.3 Engineering Installation Information Confirmation

Calculate the additional refrigerant quantity according to the method in section 2.2, and record the additional refrigerant quantity and related engineering pipe length information in the engineering installation information confirmation table.

| INFORMATION CONFIRMATION TABLE FOR ENGINEERING INSTALLATION  |   |   |
|--|---|---|
| Length and height of connection pipe   | The length from the outdoor unit to the first branch  | ft.   |
|  | The length from the first branch to the farthest indoor unit  | ft.   |
|  | Location of outdoor unit  | <input type="checkbox"/> upper side/ <input type="checkbox"/> middle/ <input type="checkbox"/> lower side |
|  | The maximum height from the indoor unit to the outdoor unit (outdoor unit is above indoor unit/outdoor unit is under the indoor unit) | / ft.   |
| Refrigerant additional information   | The length of pipe $\Phi 1/4$ inch/The length of pipe $\Phi 3/8$ inch   | ft.   |
|  | Additional refrigerant volume A for the pipe/Additional refrigerant charge volume B for the outdoor unit                              | / LBS.  |
|  | Total additional refrigerant volume A+B   | / LBS.  |
| Installation completion date/Commissioning completion date   |   | /   |
| 1.Length and height of connection pipes can't exceed the range indicated in the instruction manual.<br>2.The maximum refrigerant charging volume for the system can't exceed 16.5LBS (including the refrigerant charged in the factory).<br>3.When this table is filled, please stick it at the inner surface of side plate of the unit for checking during maintenance. |   |   |

# 3 Inspection of Key Parts


## 3.1 Power

| Specifications  |  | Description  |  |
|---|--|--|--|
| <p>The power supplies of the compressor and fan comprise the following three parts:</p> <p>① The specifications of the input power are 208/230V ~ 60Hz and earth line.</p> <p>② The main control board can convert AC power to DC power,also can convert DC power to three phase AC power.</p> <p>③ Emergency power is used to supply electricity to the shut-off valve in case of refrigerant leakage.</p> |  | <p>Use of power to the main control board:</p> <p>① Providing AC power for the solenoid valve coil and 4-way valve coil.</p> <p>② Generating the low-voltage DC power.</p> |  |
| Circuit diagram   |  | Layout of electrical appliance box   | Physical position  |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U)  |  |  |  |
|   |  |    |  |



### 3.1.1 Mechanical Inspection

- (1) Confirm that the unit power is disconnected.
- (2) Remove the electrical appliance cover.
- (3) Check whether the power cable is fixed on the wiring board.
- (4) Check whether the fuses on the main board and filter board are damaged.
- (5) Check whether the varistors on the main board and filter board are damaged.



### 3.1.2 Electrical Inspection


Check the power cable from the main switch board to the ODU:

- (1) Use an ohmmeter of at least 500V DC to check whether the insulation resistance between each phase and the ground reaches at least 1 megohm. Small insulation resistance indicates a potential electric leakage.

**Warning:** Electric shock

- (2) After the checking, connect the power and verify that the voltage of the power terminals is correct:

Voltage between N and AC-L: 208/230 VAC.



3.2 Temperature Sensors

| Specifications   | Description   |                   |
|--|---|-------------------|
| Three types of temperature sensors of different specifications are used, including 50K, 20K and 15K. | The sensors are used to measure the temperature of the unit at different positions. |                   |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、 GMV- V60WL/NhC-T(U)                                  |   |                   |
| Circuit diagram  | Layout of electrical appliance box  | Physical position |
|  |   |                   |

### 3.2.1 Mechanical Inspection

- (1) Confirm that the unit Power is disconnected.
- (2) Find the place corresponding to each sensor on the unit and check if the sensors are firmly fixed on the unit.

### 3.2.2 Electrical Inspection

Measure the actual temperature and resistance of the temperature sensors, and compare it with the characteristic curve of the temperature sensors to determine whether the thermocouple is normal.


- (1) Power off the unit. Remove the electrical appliance cover after the ODU stops.

**Warning:** Electric shock

- (2) Remove the electrical appliance cover and check whether the connecting terminal of the temperature sensors is firm.
- (3) Use a thermometer to measure the temperature of the spot sensed by the temperature sensors.
- (4) Disconnect the connecting terminal of the corresponding temperature sensor from the main board. Use a multimeter to measure the resistance of the temperature sensors and compare it with the confirmed temperature range.
- (5) If the measured resistance and temperature do not match with the resistance and temperature in the characteristic curve of the temperature sensor, the temperature sensor needs to be replaced.
- (6) If the measured resistance and temperature match with the resistance and temperature in the characteristic curve of the temperature sensor, but the temperature of the spot is abnormal according to the monitoring of the unit, the main board needs to be replaced.


## 15K temperature sensor resistance - temperature curve

| 15K               |                  |
|-------------------|------------------|
| Temperature<br>°C | Resistance<br>KΩ |
| -20               | 144              |
| -15               | 108.7            |
| -10               | 82.75            |
| -5                | 63.46            |
| 0                 | 49.02            |
| 5                 | 38.15            |
| 10                | 29.9             |
| 15                | 23.6             |
| 20                | 18.75            |
| 25                | 15               |
| 30                | 12.07            |
| 35                | 9.779            |
| 40                | 7.967            |
| 45                | 6.529            |
| 50                | 5.379            |
| 55                | 4.456            |
| 60                | 3.711            |
| 65                | 3.105            |
| 70                | 2.611            |
| 75                | 2.205            |
| 80                | 1.871            |
| 85                | 1.594            |
| 90                | 1.363            |
| 95                | 1.171            |
| 100               | 1.009            |
| 105               | 0.873            |
| 110               | 0.7577           |
| 115               | 0.6599           |
| 120               | 0.5765           |
| 125               | 0.5052           |
| 130               | 0.4441           |
| 135               | 0.3914           |
| 140               | 0.346            |
| 145               | 0.3066           |
| 150               | 0.2725           |
| 155               | 0.2427           |
| 160               | 0.2166           |



## 20K temperature sensor resistance - temperature curve


| 20K            |               |
|----------------|---------------|
| Temperature °C | Resistance KΩ |
| -30            | 361.8         |
| -25            | 265.5         |
| -20            | 196.9         |
| -15            | 145           |
| -10            | 110.3         |
| -5             | 84.61         |
| 0              | 65.37         |
| 5              | 50.87         |
| 10             | 39.87         |
| 15             | 31.47         |
| 20             | 25.01         |
| 25             | 20            |
| 30             | 16.1          |
| 35             | 13.04         |
| 40             | 10.62         |
| 45             | 8.705         |
| 50             | 7.173         |
| 55             | 5.942         |
| 60             | 4.948         |
| 65             | 4.14          |
| 70             | 3.481         |
| 75             | 2.94          |
| 80             | 2.495         |
| 85             | 2.125         |
| 90             | 1.818         |
| 95             | 1.561         |
| 100            | 1.346         |
| 105            | 1.164         |
| 110            | 1.01          |
| 115            | 0.8799        |
| 120            | 0.7687        |
| 125            | 0.6736        |
| 130            | 0.5921        |
| 135            | 0.5219        |
| 140            | 0.4613        |
| 145            | 0.4088        |
| 150            | 0.3633        |
| 155            | 0.3237        |
| 160            | 0.2891        |





## 50K temperature sensor resistance - temperature curve

| 50K               |                  |
|-------------------|------------------|
| Temperature<br>°C | Resistance<br>KΩ |
| -30               | 911.56           |
| -25               | 660.93           |
| -20               | 486.55           |
| -15               | 362.99           |
| -10               | 274.02           |
| -5                | 209.05           |
| 0                 | 161.02           |
| 5                 | 126.17           |
| 10                | 98.006           |
| 15                | 77.349           |
| 20                | 61.478           |
| 25                | 49.191           |
| 30                | 39.61            |
| 35                | 32.088           |
| 40                | 26.147           |
| 45                | 21.425           |
| 50                | 17.651           |
| 55                | 14.618           |
| 60                | 12.168           |
| 65                | 10.178           |
| 70                | 8.5551           |
| 75                | 7.2245           |
| 80                | 6.1288           |
| 85                | 5.2223           |
| 90                | 4.4693           |
| 95                | 3.841            |
| 100               | 3.3147           |
| 105               | 2.8721           |
| 110               | 2.4983           |
| 115               | 2.1816           |
| 120               | 1.9123           |
| 125               | 1.6821           |
| 130               | 1.485            |
| 135               | 1.3155           |
| 140               | 1.1694           |
| 145               | 1.0429           |
| 150               | 0.9331           |



3.3 Solenoid Valve

| Specifications   | Description   |                   |
|--|---|-------------------|
| <p>Coils of different types are used on:</p> <p>① 4-way valve</p> <p>② Solenoid valve.</p> | <p>① The 4-way valve is used to switch between cooling mode and heating mode. If the 4-way valve is active, the unit works in heating mode, if the 4-way valve is inactive, the unit works in cooling mode.</p> <p>② The solenoid valve is used to control the on-and-off of the pipeline. The valve of the unit is solid closed. That is, the valve is closed when it is inactive, open when it is active.</p> |                   |
| Circuit diagram  | Layout of electrical appliance box  | Physical position |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U)                         |   |                   |
|  |   |                   |

### 3.3.1 Mechanical Inspection

- (1) Confirm that the unit Power is disconnected.
- (2) Find the 4-way valve or solenoid valve, check whether the fixing screw is loose and whether the valve and coil have any apparent exceptions.

### 3.3.2 Electrical Inspection

Compare the measured coil resistance with the normal coil resistance to check whether the coil is damaged.

- (1) Power off the unit. Remove the electrical appliance cover after the ODU stops.

**Warning:** Electric shock

- (2) Remove the electrical appliance cover and check whether the connecting terminal of the 4-way valve or solenoid valve is firm.
- (3) Disconnect the corresponding valve's coil terminal from the main board and use a multimeter to measure the coil resistance.
- (4) If the measured resistance does not match with that in the following table, the coil needs to be replaced.

| Coil                          | Bolt on the main board | Resistance ( $\Omega$ ) | Normal range of deviation |
|-------------------------------|------------------------|-------------------------|---------------------------|
| 4-way valve                   | CN412                  | 1880                    | $\pm 10\%$                |
| Subcooler solenoid valve      | CN5                    | 1830                    | $\pm 10\%$                |
| Sub oil return solenoid valve | CN413                  | 1830                    | $\pm 10\%$                |



3.4 Electronic Expansion Valve

| Specifications  |                                    | Description   |
|---|------------------------------------|---|
| The heating and subcooler electronic expansion valve with the largest openness of 480 pls and 5-core coil.    |                                    | The electronic expansion valve is used to control the flow. When the electronic expansion valve is closed (the openness is 0 pls), the flow is stopped. |
| The gas and liquid shut-off electronic expansion valve with the largest openness of 4000 pls and 6-core coil. |                                    |   |
| Circuit diagram   | Layout of electrical appliance box | Physical position   |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U)  |                                    |   |
|   |                                    |   |

### 3.4.1 Mechanical Inspection





**Step 1:** Switch off the power of the ODU.

**Step 2:** Check whether the coil of the electronic expansion valve is firmly fixed on the electronic expansion valve.




### 3.4.2 Electrical Inspection

**Step 1:** Power off the ODU and power on it. When the ODU is powered on again, the electronic expansion valve should be reset. When the electronic expansion valve is reset, touch the valve with a hand to check if the valve core rotates. In the second half of the resetting process, the valve core will click and vibrate obviously; otherwise, the electronic expansion valve, coil or the main board needs to be replaced.

**Step 2:** Switch off the power of the ODU, disconnect the coil terminal of the electronic expansion valve from the main board and use a multimeter to measure the resistance of each contact point of the terminal. The normal range of the resistance is shown in the following table. If any value is beyond the normal range, the coil is damaged and needs to be replaced.

| Coil                                       | Interface No. | Color  | Port specifications | Max. number of steps | Terminal layout   | Diagram of internal coils  | Coil resistance range |
|--|---------------|--------|---------------------|----------------------|---|--|-----------------------|
| Heating electronic expansion valve         | CN407         | White  | 5 cores             | 480                  |  |   | 46Ω±3.7Ω              |
| Subcooler electronic expansion valve       | CN406         | Red    | 5 cores             | 480                  |   |  |                       |
| Gas shut-off electronic expansion valve    | CN4           | Yellow | 6 cores             | 4000                 |  |  |                       |
| Liquid shut-off electronic expansion valve | CN5           | Green  | 6 cores             | 4000                 |   |  |                       |

3.5 Fans

| Specifications  |  | Description  |  |
|---|--|--|--|
| The unit is equipped with two fans. The fans are connected to the main control board. |  | The fans are powered by a DC inverter motor and can adjust the speed automatically according to the environmental temperature and load, thus adapting to the demand of the unit operation. |  |
| Circuit diagram   |  | Layout of electrical appliance box   | Physical position  |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U)                    |  |  |  |
|     |  |    |  |

### 3.5.1 Mechanical Inspection



**Step 1:** Switch off the power of the ODU.

**Step 2:** Check whether the connector between the fan motor and fan drive board is firmly connected.

**Step 3:** Rotate the blades with a hand to check whether they can rotate smoothly and whether the blades rub the baffle ring during rotation. If the blades are blocked during rotation, the motor needs to be replaced; if the blades rub the baffle ring during rotation, check whether the blades and baffle ring deform and needs to be replaced.

### 3.5.2 Electrical Inspection

Switch off the power of the ODU. Disconnect the connector between the fan motor and fan drive board. Use a multimeter to measure the resistance of each contact point of the motor terminal. The normal range of the resistance is shown in the following table. If any value is beyond the normal range, the motor is damaged and needs to be replaced.

| Terminal layout   | Diagram of internal coils  | Range of coil resistance between any two phases |
|---|--|---|
|  <p>1、W WHITE</p> <p>3、U YELLOW</p> <p>5、V RED</p> |  <p>W (WHITE)</p> <p>U (YELLOW)</p> <p>V (RED)</p> | $37.4\Omega \pm 8\%$                            |

3.6 Compressor

| Specifications   | Description                                     |
|--|---|
| Models: QXAT-F400zN450   | Compression refrigerant, recycling refrigerant. |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U) |   |
| Circuit diagram  | Physical position                               |
|  |   |


### 3.6.1 Diagnosis of Compressor Failures

#### 3.6.1.1 When the unit can be started

##### Step 1:

If the unit can be started, check the faulty compressor's line current. Use a pressure gauge to measure the gas and liquid valve pressure and monitor the measured data on a PC. Compare the data to the following table of recommended current. The current may deviates by about 10% depending on the inverter compressor's speed and working condition.

When the compressor frequency is 30 Hz, the current curve under different evaporation temperature and condensation temperature is shown as follows:



##### NOTE!

When the compressor is working at another frequency, the current curve can be obtained through interpolation calculation of the above frequency.



##### NOTE!

When the compressor is working at another frequency, the current curve can be obtained through interpolation calculation of the above frequency.

##### Step 2:

Check whether the running sound of the compressor is normal and whether any high-pitched sound or obvious scratch can be heard. If there is a nearby unit running properly, compare the sound of the compressor under inspection with that of the normally running unit.


##### Step 3:

Check whether the electronic expansion valve of the ODU and 4-way valve work properly, and whether the oil-return pipeline and oil-return valve are normal. Touch the oil-return capillary tube with a hand to check whether oil flows in the tube and check the pipeline temperature.

##### Diagnosis method:

- 1) Electronic expansion valve: When the unit is powered on and off each time, the electronic expansion valve needs to reset. Touch the valve with a hand to check if the valve core rotates. In the second half of the resetting process, the valve core will click and vibrate obviously.







Note on touching the electronic expansion valve:



**NOTES:**


- ① Check whether the coil is firmly fixed.
- ② Touch the upper part of the electronic expansion valve and check whether the resetting of the unit can be clearly felt.
- 2) 4-way valve: When it is normal, the temperature different between it and the four copper tubes connecting to the valve is obvious. When the 4-way valve works, obvious sound and vibration can be heard and felt.



Marks are made on the 4-way valve: D indicates connection to the exhaust side, E indicates connection to the IDU evaporator, S indicates connection to the air inlet of gas-liquid separator, C indicates connection to the condenser; when the system runs in the cooling mode, C indicates that the pipeline is in the high-pressure and high-temperature status, while E and S indicate that the pipeline is in the low-pressure and low-temperature status; when the system runs in the heating mode, E indicates that the pipeline is in the high-pressure and high-temperature status, while C and S indicate that the pipeline is in the low-pressure and low-temperature status; the pipe marked by D is connected to the air outlet and remains in the high-pressure and high-temperature status. When the unit is being started, defrosting and conducting oil return, the 4-way valve produces obvious valve pushing sound. Do not touch the pipeline with hands. Otherwise, you may get scalded.



- 3) Oil-return solenoid valve: It can be diagnosed based on the oil-return valve status displayed on the monitor program and the actual operation. When the balance valve is open, the coil heats up and the lubricant flow before and after the valve is obvious.




#### Step 4:

Test the main board (IPM module).

1: Disconnect the power and wait five minutes, and unplug the compressor cable.

2: As shown in the figure, switch the multimeter to the diode gear. Point the black probe to the P bonding pad and the red probe to the N wiring terminal. In the normal condition, the multimeter will not beep. If it does, the main board is damaged and needs to be replaced.



3: Point the black probe to the P needle file and the red probe to the V wiring terminal. In the normal condition, the multimeter will not beep. If it does, the drive board is damaged and needs to be replaced.

4: Point the black probe to the P needle file and the red probe to the W wiring terminal. In the normal condition, the multimeter will not beep. If it does, the drive board is damaged and needs to be replaced.

5: Point the black probe to the U wiring terminal and the red probe to the N needle file. In the normal

condition, the multimeter will not beep. If it does, the drive board is damaged and needs to be replaced.

6: Point the black probe to the V wiring terminal and the red probe to N needle file. In the normal condition, the multimeter will not beep. If it does, the drive board is damaged and needs to be replaced.

7: Point the black probe to the W needle file and the red probe to the N needle file. In the normal condition, the multimeter will not beep. If it does, the drive board is damaged and needs to be replaced.

### 3.6.1.2 When the unit cannot be started properly.

#### **Step 1:**

Disconnect the unit from power. Remove the terminal box cover and check whether the compressor is wired correctly.

#### **Step 2:**

Measure the resistance between any two of the wiring terminals of the compressor (U, V and W). The resistance between two wiring terminals is  $0.56 \pm 5\% \Omega$ .



Measure the grounding resistance of each wiring terminal, which should be greater than  $10 \text{ M}\Omega$ ; otherwise, the compressor has an internal fault.

#### **Step 3:**

When the unit cannot be started properly, the solenoid valves of the system, including the electronic expansion valve and oil-return valve, need to be checked using the same method described above.


#### **Step 4:**

Check the IPM module using the same method described above.

3.7 Board


3.7.1 Main Board

The main board is used to control the load of the ODU.



**Step 1:** Disconnect the power and wait five minutes.




**Step 2:** As shown in the figure, switch the multimeter to the diode gear. Point the black and red probes to the following positions to check if the main board is normal.





| Black probe | Red probe | Symptom   |
|-------------|-----------|---|
| CN407 (1)   | CN8 (2)   | The main board is normal if the multimeter does not beep. |
| CN426 (3)   | CN426 (4) | The main board is normal if the multimeter does not beep. |
| CN421(5)    | CN426 (4) | The main board is normal if the multimeter does not beep. |
| CN407 (1)   | CN426 (3) | The main board is normal if the multimeter does not beep. |
| CN421(5)    | CN426 (3) | The main board is normal if the multimeter does not beep. |
| CN407 (1)   | CN421 (5) | The main board is normal if the multimeter does not beep. |
| CN1 (6)     | CN1 (7)   | The main board is normal if the multimeter does not beep. |



3.7.2 Compressor Drive

| Specifications   |   | Description  |
|--|---|--|
| —  |   | This part is used to control the operation of the compressor.                        |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U)                 |   |  |
| Circuit diagram  | Layout of electrical appliance box  | Physical position  |
|  |  |  |

- (1) Before the inspection: Find a correct digital multimeter and switch it to the diode gear. Power off the unit and wait two minutes. Disconnect the U, V and W cables of the compressor and N and AC-L power cables from the main board. Do not operate without waiting two minutes after the unit is powered off.
- (2) Testing method:
  - 1) Point the black probe of the multimeter to the P needle file shown in the following figure and the red probe to U, V and W wiring terminals respectively and check the readings of the multimeter;
  - 2) Point the red probe of the multimeter to the N needle file shown in the following figure and the black probe to U, V and W wiring terminal respectively and check the readings of the multimeter.
- (3) Result analysis: If all the readings of the multimeter are between 0.3 V and 0.7 V in the above 12 conditions, the module is normal; if any of the readings is 0, the module is damaged.



3.7.3 Fan Drive


| Specifications   |                                    | Description  |
|--|------------------------------------|--|
| —  |                                    | This part is used to control the operation of the fan. |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U) |                                    |  |
| Circuit diagram  | Layout of electrical appliance box | Physical position                                      |
| <div></div>  | <div></div>                        | <div></div>  |



## 1. Upper Fan Inspection




- (1) Before the inspection: Find a correct digital multimeter and switch it to the diode gear. Power off the unit and wait two minutes. Disconnect the U1, V1 and W1 cables of the fans from the drive board. Do not operate without waiting two minutes after the unit is powered off.
- (2) Testing method: Point the black probe of the multimeter to the P needle file shown in the following figure and the red probe to U1, V1 and W1 wiring terminals respectively and check the readings of the multimeter; point the red probe of the multimeter to the N needle file shown in the following figure and the black probe to U1, V1 and W1 wiring terminal respectively and check the readings of the multimeter.
- (3) Result analysis: If all the readings of the multimeter are between 0.3 V and 0.7 V in the above six conditions, the module is normal; if any of the readings is 0, the module is damaged.

## 2. Under Fan Inspection in a similar way





### 3.8 Pressure Sensor





| Specifications   | Description  |
|--|--|
| —  | <p>Inspection of high-pressure temperature of the high-pressure sensor:</p> <ol style="list-style-type: none"> <li>1. Control of compressor output capacity</li> <li>2. Conversion and calculation of saturated condensing temperature</li> <li>3. Protection high pressure</li> <li>4. Inspection of high-pressure value and calculation of exhaust superheat degree</li> <li>5. Inspection of the minimum and maximum compression ratio</li> </ol> <p>Inspection of low-pressure temperature of the low-pressure sensor:</p> <ol style="list-style-type: none"> <li>1. Control of compressor output capacity</li> <li>2. Conversion and calculation of saturated evaporating temperature</li> <li>3. Inspection of suction superheat degree</li> <li>4. Low-pressure protection functions</li> <li>5. Inspection of the minimum and maximum compression ratio</li> </ol> |
| Models: GMV-V36WL/NhC-T(U)、GMV- V48WL/NhC-T(U)、GMV- V60WL/NhC-T(U)                 |  |
| Circuit diagram  | Layout of electrical appliance box   |
|  |   |
| Physical position  | Physical position  |
|  |   |




**Inspection procedure**

1. Preparations
  - (1) Use the wired controller or remote controller to shut down the unit.
  - (2) Remove the front cover and open the electrical appliance box.
2. Inspection of low-pressure sensor
  - (1) Connect the pressure gauge to the gas valve and check if the gas and liquid valves are open.
  - (2) Switch the unit to the cooling mode. After the system stabilizes, check the reading of the pressure gauge.
  - (3) Check the unit's suction pressure via the wired controller and compare it with the reading of the pressure gauge on the gas valve. If the value shown on the wired controller is within the range of  $\pm 10\%$  of the reading of the pressure gauge, the pressure sensor is normal. Otherwise, it is abnormal.
3. Inspection of high-pressure sensor
  - (1) Connect the pressure gauge to the gas valve and check if the gas and liquid valves are open.
  - (2) Switch the unit to the heating mode. After the system stabilizes, check the reading of the pressure gauge.
4. Check the unit's exhaust pressure via the wired controller and compare it with the reading of the pressure gauge on the gas valve. If the value shown on the wired controller is within the range of  $\pm 10\%$  of the reading of the pressure gauge, the pressure sensor is normal. Otherwise, it is abnormal.





## 4 Replacement of Key Unit Parts





### 4.1 Key Parts


| Photo   | Name                       | Function  |
|---|----------------------------|---|
|    | compressor                 | Core part of air conditioning system. It sucks low temperature and low pressure gas, compress it to high temperature and high pressure gas, and then discharge it.  |
|   | Electronic expansion valve | Throttling device. It transforms high pressure refrigerant liquid into low pressure steam.  |
|  | 4-way valve                | It changes the flow direction of refrigerant for switching between cooling and heating.   |
|  | Oil separator              | It stays between discharge outlet of compressor and inlet of condenser. It used for separating the lubricant oil of compressor when the high temperature and high pressure refrigerant gas is discharged from the compressor. |




| Photo   | Name                    | Function   |
|---|-------------------------|--|
|    | Vapour liquid separator | It stays between outlet of evaporator and suction outlet of compressor. It used for separating low temperature and low pressure refrigerant. |
|   | Solenoid valve          | —  |
|  | Cut-off valve           | It used for connecting indoor unit and outdoor unit, and used for maintenance and installation.  |





## 4.2 Removal of Key Parts

| Removal operation for panel  |   |   |
|--|---|---|
| Remark: Before removing the panel, please make sure that the unit is disconnected with the power |   |   |
| Process  | Photo   | Operation Instruction   |
| 1.Remove top cover   |    | <ul style="list-style-type: none"> <li>● Loose the screws fixing the top cover with screwdriver</li> <li>● Hold the top cover upwards and then put it on the floor flatly</li> </ul>              |
| 2.Remove front side plate sub-assy   |   | <ul style="list-style-type: none"> <li>● Loose the screw fixing the front side plate with screwdriver</li> <li>● Hold the front side plate upwards and then put it on the floor flatly</li> </ul> |
| 3.Remove front panel and grille  |  | <ul style="list-style-type: none"> <li>● Loose the screws fixing the front panel and grille with screwdriver</li> <li>● Put the front panel and grille on the floor flatly</li> </ul>             |
| 4.Remove left side plate and rear side plate   |  | <ul style="list-style-type: none"> <li>● Loose screws fixing left side plate and rear side plate with screwdriver</li> <li>● remove the rear side plate</li> </ul>                                |


| Removal operation for blade   |   |   |
|---|---|---|
| Remark: Before removing the motor, please make sure that the unit is disconnected with the power. |   |   |
| Process   | Photo   | Operation Instruction   |
| 1.Remove grille   |    | <ul style="list-style-type: none"> <li>• Loose screws fixing the panel with screwdriver</li> <li>• Then remove the grille</li> </ul>  |
| 2.Remove blade  |   | <ul style="list-style-type: none"> <li>• Loosen nuts fixing the blade with wrench</li> <li>• Then remove the blade and put it on the floor flatly</li> </ul>                            |
| 3.Remove motor  |  | <ul style="list-style-type: none"> <li>• Loose screws fixing the motor with screwdriver</li> <li>• then remove the power cord of motor</li> <li>• Take out the damaged motor</li> </ul> |
| 4.Install motor   |  | <ul style="list-style-type: none"> <li>• Replace the motor, tighten screws with screwdriver and then connect the power cord of motor</li> </ul>   |




| Removal operation for blade   |   |  |
|---|---|--|
| Remark: Before removing the motor, please make sure that the unit is disconnected with the power. |   |  |
| Process   | Photo   | Operation Instruction  |
| 5.Assemble unit   |  | <ul style="list-style-type: none"> <li>● Assemble the unit in the the converse sequence</li> </ul> |


| Removal operation of compressor   |   |   |
|---|---|---|
| Remark: Before removing the compressor, please make sure that there's no refrigerant inside the pipeline and the power is disconnected. |   |   |
| Process   | Photo   | Operation Instruction   |
| 1.Remove wiring cover of compressor   |   | <ul style="list-style-type: none"> <li>● Loose screws fixing the compressor with screwdriver</li> <li>● Then pull out the power cord</li> </ul> <p><b>NOTE:</b> When removing the power cord, make marks for different color power cords and corresponding wiring terminals for wrong terminal.</p> |
| 2.Disconnect compressor 、 vapor injection tube and connected pipeline   |  | <ul style="list-style-type: none"> <li>● Weld suction pipe、 vapor injection tube and discharge pipe of compressor</li> <li>● then pull out the connection pipe from the compressor</li> </ul> <p><b>NOTE:</b> During welding process, do not let the flame burn out other parts.</p>                |
| 3.Loose nuts fixing the foot of compressor  |  | <ul style="list-style-type: none"> <li>● Twist off the nuts for compressor with wrench</li> </ul>   |



| Removal operation of compressor   |  |  |
|---|--|--|
| Remark: Before removing the compressor, please make sure that there's no refrigerant inside the pipeline and the power is disconnected. |  |  |
| Process   | Photo  | Operation Instruction  |
| 4.Remove the chassis from compressor  |   | <ul style="list-style-type: none"> <li>Take out the compressor and replace it</li> </ul> <p><b>NOTE:</b> When replacing the compressor, do not damage nearby pipelines and other parts</p>   |
| 5.Fix the new compressor at the chassis   |    | <ul style="list-style-type: none"> <li>After replacing the compressor, fix the nuts at the bottom of compressor</li> </ul>   |
| 6.Connect suction pipe、vapor injection tube and discharge pipe of compressor and pipeline of system again                               |  <p>Connect suction pipe、vapor injection tube and discharge pipe of copressor and pipeline of system again</p>        | <ul style="list-style-type: none"> <li>Weld the connection pipe of compressor, connect the pipeline and compressor</li> </ul> <p><b>NOTE:</b> During welding process, do not let flame burn out other parts</p>  |
| 7.Connect the power cord of compressor well   |  <p>When connecting the power cord, make marks for different color power cords and corresponding wiring terminals</p> | <ul style="list-style-type: none"> <li>Loose screws fixing the power cord with screwdriver</li> <li>connect the power cord well again</li> </ul> <p><b>NOTE:</b> When connecting the power cord, make marks for different color power cords and corresponding wiring terminals</p> |






| Removal operation of compressor   |   |   |
|---|---|---|
| Remark: Before removing the compressor, please make sure that there's no refrigerant inside the pipeline and the power is disconnected. |   |   |
| Process   | Photo   | Operation Instruction   |
| 8.Check and open the upper cover plate  |  | <ul style="list-style-type: none"> <li>●Check whether the pipeline is connected well</li> <li>●Check whether all parts and connection wires are connected well</li> <li>●If there's no problem after checking, install front and rear cover plates</li> </ul> |



| Removal operation for 4-way valve   |   |   |
|---|---|---|
| Remark: Before removing the 4-way valve, please make sure that there's no refrigerant inside the pipeline of system and then power is disconnected. |   |   |
| Process   | Photo   | Operation Instruction   |
| 1.Disconnect the coil of 4-way valve from the 4-way valve   |   | <ul style="list-style-type: none"> <li>●Remove the coil of 4-way valve at first</li> </ul>  |
| 2.Disconnect the 4-way valve and connection pipeline  |  | <ul style="list-style-type: none"> <li>● Weld those 4 connection spots on 4-way valve, and then pull out the connection pipe</li> </ul> <p><b>NOTE:</b> During welding process, do not let the flame burn out other parts</p> |
| 3.Replace 4-way valve   |  | <ul style="list-style-type: none"> <li>● Replace 4-way valve</li> </ul> <p><b>NOTE:</b> During welding process, do not let the flame burn out other parts</p>   |


| Removal operation for 4-way valve   |   |   |
|---|---|---|
| Remark: Before removing the 4-way valve, please make sure that there's no refrigerant inside the pipeline of system and then power is disconnected. |   |   |
| Process   | Photo   | Operation Instruction   |
| 4. Replace 4-way valve  |  <p>Weld those 4 connection spots on 4-way valve</p> | <ul style="list-style-type: none"> <li>Weld the connection position between 4-way valve and pipeline</li> </ul> <p><b>NOTE:</b> During welding process, do not let flame burn out other parts</p> |




| Removal operation for electronic expansion valve   |   |   |
|--|---|---|
| Remark: Before removing the electronic expansion valve, please make sure that there's no refrigerant in the pipeline of system and the power is disconnected |   |   |
| Process  | Photo   | Operation Instruction   |
| 1. Disconnect the electronic expansion valve from the pipeline   |  <p>Weld the connection pipe for expansion valve</p>            | <ul style="list-style-type: none"> <li>Remove the coil of electronic expansion valve at first</li> <li>Weld the connection pipe for expansion valve, and then pull out the connection pipe</li> </ul> <p><b>NOTE:</b> During welding process, do not let flame burn out other parts</p> |
| 2. Take out the electronic expansion valve and replace it  |  <p>Take out the electronic expansion valve and replace it</p> | <ul style="list-style-type: none"> <li>Take out the electronic expansion valve and replace it</li> </ul>  |

| Removal operation for electronic expansion valve   |   |  |
|--|---|--|
| Remark: Before removing the electronic expansion valve, please make sure that there's no refrigerant in the pipeline of system and the power is disconnected |   |  |
| Process  | Photo   | Operation Instruction  |
| 3. Replace electronic expansion valve  |  <p>Weld the connection pipe for expansion valve</p> | <ul style="list-style-type: none"> <li>• Weld the connection pipe of electronic expansion valve</li> <li>• Install the coil of electronic expansion valve</li> </ul> <p><b>NOTE:</b> During welding process, do not let the flame burn out other parts</p> |

| Removal operation of gas liquid separator   |   |   |
|---|---|---|
| Remark: Before removing the gas liquid separator, please make sure that there's no refrigerant inside the pipeline of system and disconnect the power |   |   |
| Process   | Photo   | Operation Instruction   |
| 1. Disconnect inlet pipe and exit pipe of gas liquid separator  |  <p>Weld those two connection spots on the gas liquid separator</p> | <ul style="list-style-type: none"> <li>• Weld those two connection spots on the gas liquid separator and then pull out the connection pipe</li> </ul> <p><b>NOTE:</b> During welding process, do not let flame burn out other parts</p> |
| 2. Replace gas liquid separator   |  <p>Loose three screws</p>   | <ul style="list-style-type: none"> <li>• Loose three screws with screwdriver</li> <li>• Replace gas liquid separator</li> </ul>   |


| Removal operation of gas liquid separator   |  |   |
|---|--|---|
| Remark: Before removing the gas liquid separator, please make sure that there's no refrigerant inside the pipeline of system and disconnect the power |  |   |
| Process   | Photo  | Operation Instruction   |
| 3.Replace gas liquid separator  |   | <ul style="list-style-type: none"> <li>Weld the pipe connected with gas liquid separator</li> <li><b>NOTE:</b> During welding process, do not let flame burn out other parts</li> </ul>             |
| 4.Replace gas liquid separator  |  <p>Weld those two connection points</p> <p>Tighten the screws</p> | <ul style="list-style-type: none"> <li>Fix the screws at the base of gas liquid separator well again</li> <li><b>NOTE:</b> During welding process, do not let flame burn out other parts</li> </ul> |

| Removal operation for plate heat exchanger  |   |  |
|---|---|--|
| Remark: Before removing the plate heat exchanger, please make sure that there's no refrigerant inside the pipeline of system and disconnect the power |   |  |
| Process   | Photo   | Operation Instruction  |
| 1.Twist off two nuts fixing the plate heat exchanger with wrench  |  <p>Twist off two nuts fixing the plate heat exchanger with wrench</p> | <ul style="list-style-type: none"> <li>Twist off two nuts fixing the plate heat exchanger with wrench</li> </ul> |

| Removal operation for plate heat exchanger  |  |   |
|---|--|---|
| Remark: Before removing the plate heat exchanger, please make sure that there's no refrigerant inside the pipeline of system and disconnect the power |  |   |
| Process   | Photo  | Operation Instruction   |
| 2.Disconnect inlet pipe and outlet pipe of plate heat exchanger   |  <p>Weld those 4 connection spots on the plate heat exchanger</p> | <ul style="list-style-type: none"> <li>Weld those 4 connection spots on the plate heat exchanger, and then pull out the connection pipe.</li> </ul> <p><b>NOTE:</b> During welding process, do not let flame burn out other parts</p> |
| 3.Replace plate heat exchanger  |  <p>Replace plate heat exchanger</p>                             | <ul style="list-style-type: none"> <li>Replace plate heat exchanger</li> </ul>  |
| 4..Replace plate heat exchanger   |  <p>Weld the pipe connected with plate heat exchanger</p>       | <ul style="list-style-type: none"> <li>Weld the pipe connected with plate heat exchanger</li> </ul> <p><b>NOTE:</b> During welding process, do not let flame burn out other parts</p>   |

## 5 Explosive View and Parts List

GMV-V36WL/NhC-T(U), GMV- V48WL/NhC-T(U) and GMV- V60WL/NhC-T(U)



Parts list of GMV-V36WL/NhC-T(U), GMV- V48WL/NhC-T(U) and GMV- V60WL/NhC-T(U)

| No. | Name                       | Material code  | Qty |
|-----|----------------------------|----------------|-----|
| 1   | Front Grill                | 016004060002   | 2   |
| 2   | Axial Flow Fan             | 1043410000301  | 2   |
| 3   | Brushless DC Motor         | 150104060074   | 1   |
| 4   | Brushless DC Motor         | 15010406007401 | 1   |
| 5   | Pressure Protect Switch    | 46020006       | 1   |
| 6   | Oil Separator              | 035028000003   | 1   |
| 7   | Electronic Expansion Valve | 072009060008   | 1   |
| 8   | Discharge Charge Valve     | 071015000002   | 1   |
| 9   | Compressor and Fittings    | 009001060980   | 1   |
| 10  | Electromagnetic Valve      | 43044100144    | 1   |
| 11  | Strainer                   | 07213046       | 1   |
| 12  | Cut off Valve              | 07330000002    | 1   |
| 13  | Plate-type Heat Exchanger  | 010007060010   | 1   |
| 14  | Electromagnetic Valve      | 072008060021   | 1   |
| 15  | Electronic Expansion Valve | 072009060011   | 1   |

| No. | Name                                | Material code  | Qty |
|-----|-------------------------------------|----------------|-----|
| 16  | Cut off Valve                       | 070001000009   | 1   |
| 17  | Gas-liquid Separator                | 03502706002001 | 1   |
| 18  | 4-Way Valve                         | 43000338       | 1   |
| 19  | Pressure Sensor                     | 430044060023   | 1   |
| 20  | Pressure Sensor                     | 430044060022   | 1   |
| 21  | Rear Grill                          | 01574100004    | 1   |
| 22  | Condenser Assy                      | 011002062189   | 1   |
| 23  | Electric Box Assy                   | 100002083190   | 1   |
| 24  | Terminal Board                      | 42200006005403 | 1   |
| 25  | Connection Board                    | 300023060112   | 1   |
| 26  | Terminal Board                      | 42200006001202 | 1   |
| 27  | Terminal Board                      | 42000100000102 | 1   |
| 28  | Filter Board                        | 300020060153   | 1   |
| 29  | Main Board                          | 300027064156   | 1   |
| 30  | Electrical Heater                   | 7651000428     | 1   |
| 31  | Electrical Heater                   | 7651521242     | 1   |
| 32  | Sensor Sub-assy                     | 390002060696   | 1   |
| 33  | 4 Way Valve Coil                    | 07201006000604 | 1   |
| 34  | Magnet Coil (electromagnetic valve) | 07200106001532 | 1   |
| 35  | Magnet Coil (electromagnetic valve) | 07200106001533 | 1   |
| 36  | Electric Expand Valve Fitting       | 4304413251     | 1   |
| 37  | Electric Expand Valve Fitting       | 07200206002002 | 1   |



# Appendixes

## Appendix 1 Temperature Sensor Resistance and Temperature Relationship Table

Environmental temperature sensor 15kΩ resistance ~ voltage correspondence table (including outdoor and indoor environment temperature sensors)

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| -20              | 144             | 0.311       | 71               | 2.523           | 2.825       |
| -19              | 138.1           | 0.323       | 72               | 2.439           | 2.838       |
| -18              | 128.6           | 0.345       | 73               | 2.358           | 2.852       |
| -17              | 121.6           | 0.362       | 74               | 2.28            | 2.865       |
| -16              | 115             | 0.381       | 75               | 2.205           | 2.877       |
| -15              | 108.7           | 0.4         | 76               | 2.133           | 2.889       |
| -14              | 102.9           | 0.42        | 77               | 2.064           | 2.901       |
| -13              | 97.4            | 0.44        | 78               | 1.997           | 2.912       |
| -12              | 92.22           | 0.462       | 79               | 1.933           | 2.923       |
| -11              | 87.35           | 0.484       | 80               | 1.871           | 2.934       |
| -10              | 82.75           | 0.506       | 81               | 1.811           | 2.945       |
| -9               | 78.43           | 0.53        | 82               | 1.754           | 2.955       |
| -8               | 74.35           | 0.554       | 83               | 1.699           | 2.964       |
| -7               | 70.5            | 0.579       | 84               | 1.645           | 2.974       |
| -6               | 66.88           | 0.605       | 85               | 1.594           | 2.983       |
| -5               | 63.46           | 0.631       | 86               | 1.544           | 2.992       |
| -4               | 60.23           | 0.658       | 87               | 1.497           | 3.001       |
| -3               | 57.18           | 0.686       | 88               | 1.451           | 3.009       |
| -2               | 54.31           | 0.714       | 89               | 1.408           | 3.017       |
| -1               | 51.59           | 0.743       | 90               | 1.363           | 3.025       |
| 0                | 49.02           | 0.773       | 91               | 1.322           | 3.033       |
| 1                | 46.8            | 0.801       | 92               | 1.282           | 3.04        |
| 2                | 44.31           | 0.835       | 93               | 1.244           | 3.047       |
| 3                | 42.14           | 0.866       | 94               | 1.207           | 3.054       |
| 4                | 40.09           | 0.899       | 95               | 1.171           | 3.061       |
| 5                | 38.15           | 0.931       | 96               | 1.136           | 3.068       |
| 6                | 36.32           | 0.965       | 97               | 1.103           | 3.074       |
| 7                | 34.58           | 0.998       | 98               | 1.071           | 3.08        |
| 8                | 32.94           | 1.033       | 99               | 1.039           | 3.086       |
| 9                | 31.38           | 1.067       | 100              | 1.009           | 3.092       |
| 10               | 29.9            | 1.102       | 101              | 0.98            | 3.098       |
| 11               | 28.51           | 1.138       | 102              | 0.952           | 3.103       |
| 12               | 27.18           | 1.174       | 103              | 0.925           | 3.108       |
| 13               | 25.92           | 1.21        | 104              | 0.898           | 3.114       |
| 14               | 24.73           | 1.246       | 105              | 0.873           | 3.119       |



| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| 15               | 23.6            | 1.282       | 106              | 0.848           | 3.123       |
| 16               | 22.53           | 1.319       | 107              | 0.825           | 3.128       |
| 17               | 21.51           | 1.356       | 108              | 0.802           | 3.133       |
| 18               | 20.54           | 1.393       | 109              | 0.779           | 3.137       |
| 19               | 19.63           | 1.429       | 110              | 0.758           | 3.141       |
| 20               | 18.75           | 1.467       | 111              | 0.737           | 3.145       |
| 21               | 17.93           | 1.503       | 112              | 0.717           | 3.15        |
| 22               | 17.14           | 1.54        | 113              | 0.697           | 3.153       |
| 23               | 16.39           | 1.577       | 114              | 0.678           | 3.157       |
| 24               | 15.68           | 1.613       | 115              | 0.66            | 3.161       |
| 25               | 15              | 1.65        | 116              | 0.642           | 3.165       |
| 26               | 14.36           | 1.686       | 117              | 0.625           | 3.168       |
| 27               | 13.74           | 1.722       | 118              | 0.608           | 3.171       |
| 28               | 13.16           | 1.758       | 119              | 0.592           | 3.175       |
| 29               | 12.6            | 1.793       | 120              | 0.577           | 3.178       |
| 30               | 12.07           | 1.829       | 121              | 0.561           | 3.181       |
| 31               | 11.57           | 1.863       | 122              | 0.547           | 3.184       |
| 32               | 11.09           | 1.897       | 123              | 0.532           | 3.187       |
| 33               | 10.63           | 1.931       | 124              | 0.519           | 3.19        |
| 34               | 10.2            | 1.964       | 125              | 0.505           | 3.192       |
| 35               | 9.779           | 1.998       | 126              | 0.492           | 3.195       |
| 36               | 9.382           | 2.03        | 127              | 0.48            | 3.198       |
| 37               | 9.003           | 2.062       | 128              | 0.467           | 3.2         |
| 38               | 8.642           | 2.094       | 129              | 0.456           | 3.203       |
| 39               | 5.997           | 2.125       | 130              | 0.444           | 3.205       |
| 41               | 7.653           | 2.185       | 131              | 0.433           | 3.207       |
| 42               | 7.352           | 2.215       | 132              | 0.422           | 3.21        |
| 43               | 7.065           | 2.243       | 133              | 0.412           | 3.212       |
| 44               | 6.791           | 2.272       | 134              | 0.401           | 3.214       |
| 45               | 6.529           | 2.299       | 135              | 0.391           | 3.216       |
| 46               | 6.278           | 2.326       | 136              | 0.382           | 3.218       |
| 47               | 6.038           | 2.353       | 137              | 0.372           | 3.22        |
| 48               | 5.809           | 2.379       | 138              | 0.363           | 3.222       |
| 49               | 5.589           | 2.404       | 139              | 0.355           | 3.224       |
| 50               | 5.379           | 2.429       | 140              | 0.346           | 3.226       |
| 51               | 5.179           | 2.453       | 141              | 0.338           | 3.227       |
| 52               | 4.986           | 2.477       | 142              | 0.33            | 3.229       |
| 53               | 4.802           | 2.5         | 143              | 0.322           | 3.231       |
| 54               | 4.625           | 2.522       | 144              | 0.314           | 3.232       |
| 55               | 4.456           | 2.544       | 145              | 0.307           | 3.234       |
| 56               | 4.294           | 2.566       | 146              | 0.299           | 3.235       |
| 57               | 4.139           | 2.586       | 147              | 0.292           | 3.237       |
| 58               | 3.99            | 2.607       | 148              | 0.286           | 3.238       |
| 59               | 3.848           | 2.626       | 149              | 0.279           | 3.24        |
| 60               | 3.711           | 2.646       | 150              | 0.273           | 3.241       |

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| 61               | 3.579           | 2.664       | 151              | 0.266           | 3.242       |
| 62               | 3.454           | 2.682       | 152              | 0.261           | 3.244       |
| 63               | 3.333           | 2.7         | 153              | 0.254           | 3.245       |
| 64               | 3.217           | 2.717       | 154              | 0.248           | 3.246       |
| 65               | 3.105           | 2.734       | 155              | 0.243           | 3.247       |
| 66               | 2.998           | 2.75        | 156              | 0.237           | 3.249       |
| 67               | 2.898           | 2.766       | 157              | 0.232           | 3.25        |
| 68               | 2.797           | 2.781       | 158              | 0.227           | 3.251       |
| 69               | 2.702           | 2.796       | 159              | 0.222           | 3.252       |
| 70               | 2.611           | 2.811       | 160              | 0.217           | 3.253       |

Pipeline temperature sensor 20kΩ resistance ~ voltage correspondence table (including defrosting temperature sensor, subcooler temperature sensor, gas-liquid separator temperature sensor, IDU inlet and outlet tube temperature sensor)

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| -30              | 361.8           | 0.173       | 66               | 3.998           | 2.75        |
| -29              | 339.8           | 0.183       | 67               | 3.861           | 2.766       |
| -28              | 319.2           | 0.195       | 68               | 3.729           | 2.781       |
| -27              | 300             | 0.206       | 69               | 3.603           | 2.796       |
| -26              | 282.2           | 0.218       | 70               | 3.481           | 2.811       |
| -25              | 265.5           | 0.231       | 71               | 3.364           | 2.825       |
| -24              | 249.9           | 0.245       | 72               | 3.252           | 2.838       |
| -23              | 235.3           | 0.259       | 73               | 3.144           | 2.852       |
| -22              | 221.6           | 0.273       | 74               | 3.04            | 2.865       |
| -21              | 208.9           | 0.288       | 75               | 2.94            | 2.877       |
| -20              | 196.9           | 0.304       | 76               | 2.844           | 2.889       |
| -19              | 181.4           | 0.328       | 77               | 2.752           | 2.901       |
| -18              | 171.4           | 0.345       | 78               | 2.663           | 2.912       |
| -17              | 162.1           | 0.362       | 79               | 2.577           | 2.923       |
| -16              | 153.3           | 0.381       | 80               | 2.495           | 2.934       |
| -15              | 145             | 0.4         | 81               | 2.415           | 2.944       |
| -14              | 137.2           | 0.42        | 82               | 2.339           | 2.954       |
| -13              | 129.9           | 0.44        | 83               | 2.265           | 2.964       |
| -12              | 123             | 0.462       | 84               | 2.194           | 2.974       |
| -11              | 116.5           | 0.484       | 85               | 2.125           | 2.983       |
| -10              | 110.3           | 0.507       | 86               | 2.059           | 2.992       |
| -9               | 104.6           | 0.53        | 87               | 1.996           | 3.001       |
| -8               | 99.13           | 0.554       | 88               | 1.934           | 3.009       |
| -7               | 94              | 0.579       | 89               | 1.875           | 3.017       |
| -6               | 89.17           | 0.605       | 90               | 1.818           | 3.025       |
| -5               | 84.61           | 0.631       | 91               | 1.763           | 3.033       |
| -4               | 80.31           | 0.658       | 92               | 1.71            | 3.04        |
| -3               | 76.24           | 0.686       | 93               | 1.658           | 3.047       |
| -2               | 72.41           | 0.714       | 94               | 1.609           | 3.054       |

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| -1               | 68.79           | 0.743       | 95               | 1.561           | 3.061       |
| 0                | 65.37           | 0.773       | 96               | 1.515           | 3.068       |
| 1                | 62.13           | 0.804       | 97               | 1.47            | 3.074       |
| 2                | 59.08           | 0.835       | 98               | 1.427           | 3.08        |
| 3                | 56.19           | 0.866       | 99               | 1.386           | 3.086       |
| 4                | 53.46           | 0.898       | 100              | 1.346           | 3.092       |
| 5                | 50.87           | 0.931       | 101              | 1.307           | 3.098       |
| 6                | 48.42           | 0.965       | 102              | 1.269           | 3.103       |
| 7                | 46.11           | 0.998       | 103              | 1.233           | 3.108       |
| 8                | 43.92           | 1.033       | 104              | 1.198           | 3.114       |
| 9                | 41.84           | 1.067       | 105              | 1.164           | 3.119       |
| 10               | 39.87           | 1.102       | 106              | 1.131           | 3.123       |
| 11               | 38.01           | 1.138       | 107              | 1.099           | 3.128       |
| 12               | 36.24           | 1.174       | 108              | 1.069           | 3.133       |
| 13               | 34.57           | 1.209       | 109              | 1.039           | 3.137       |
| 14               | 32.98           | 1.246       | 110              | 1.01            | 3.141       |
| 15               | 31.47           | 1.282       | 111              | 0.9825          | 3.145       |
| 16               | 30.04           | 1.319       | 112              | 0.9556          | 3.15        |
| 17               | 28.68           | 1.356       | 113              | 0.9295          | 3.153       |
| 18               | 27.39           | 1.393       | 114              | 0.9043          | 3.157       |
| 19               | 26.17           | 1.429       | 115              | 0.8799          | 3.161       |
| 20               | 25.01           | 1.466       | 116              | 0.8562          | 3.165       |
| 21               | 23.9            | 1.503       | 117              | 0.8333          | 3.168       |
| 22               | 22.85           | 1.54        | 118              | 0.8111          | 3.171       |
| 23               | 21.85           | 1.577       | 119              | 0.7895          | 3.175       |
| 24               | 20.9            | 1.614       | 120              | 0.7687          | 3.178       |
| 25               | 20              | 1.65        | 121              | 0.7485          | 3.181       |
| 26               | 19.14           | 1.686       | 122              | 0.7289          | 3.184       |
| 27               | 18.32           | 1.722       | 123              | 0.7099          | 3.187       |
| 28               | 17.55           | 1.758       | 124              | 0.6915          | 3.19        |
| 29               | 16.8            | 1.793       | 125              | 0.6736          | 3.192       |
| 30               | 16.1            | 1.828       | 126              | 0.6563          | 3.195       |
| 31               | 15.43           | 1.863       | 127              | 0.6395          | 3.198       |
| 32               | 14.79           | 1.897       | 128              | 0.6232          | 3.2         |
| 33               | 14.18           | 1.931       | 129              | 0.6074          | 3.203       |
| 34               | 13.59           | 1.965       | 130              | 0.5921          | 3.205       |
| 35               | 13.04           | 1.998       | 131              | 0.5772          | 3.207       |
| 36               | 12.51           | 2.03        | 132              | 0.5627          | 3.21        |
| 37               | 12              | 2.063       | 133              | 0.5487          | 3.212       |
| 38               | 11.52           | 2.094       | 134              | 0.5351          | 3.214       |
| 39               | 11.06           | 2.125       | 135              | 0.5219          | 3.216       |
| 40               | 10.62           | 2.155       | 136              | 0.509           | 3.218       |
| 41               | 10.2            | 2.185       | 137              | 0.4966          | 3.22        |
| 42               | 9.803           | 2.215       | 138              | 0.4845          | 3.222       |
| 43               | 9.42            | 2.243       | 139              | 0.4727          | 3.224       |

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| 44               | 9.054           | 2.272       | 140              | 0.4613          | 3.226       |
| 45               | 8.705           | 2.299       | 141              | 0.4502          | 3.227       |
| 46               | 8.37            | 2.326       | 142              | 0.4394          | 3.229       |
| 47               | 8.051           | 2.353       | 143              | 0.4289          | 3.231       |
| 48               | 7.745           | 2.379       | 144              | 0.4187          | 3.232       |
| 49               | 7.453           | 2.404       | 145              | 0.4088          | 3.234       |
| 50               | 7.173           | 2.429       | 146              | 0.3992          | 3.235       |
| 51               | 6.905           | 2.453       | 147              | 0.3899          | 3.237       |
| 52               | 6.648           | 2.477       | 148              | 0.3808          | 3.238       |
| 53               | 6.403           | 2.5         | 149              | 0.3719          | 3.24        |
| 54               | 6.167           | 2.522       | 150              | 0.3633          | 3.241       |
| 55               | 5.942           | 2.544       | 151              | 0.3549          | 3.242       |
| 56               | 5.726           | 2.565       | 152              | 0.3468          | 3.244       |
| 57               | 5.519           | 2.586       | 153              | 0.3389          | 3.245       |
| 58               | 5.32            | 2.607       | 154              | 0.3312          | 3.246       |
| 59               | 5.13            | 2.626       | 155              | 0.3237          | 3.247       |
| 60               | 4.948           | 2.646       | 156              | 0.3164          | 3.249       |
| 61               | 4.773           | 2.664       | 157              | 0.3093          | 3.25        |
| 62               | 4.605           | 2.682       | 158              | 0.3024          | 3.251       |
| 63               | 4.443           | 2.7         | 159              | 0.2956          | 3.252       |
| 64               | 4.289           | 2.717       | 160              | 0.2891          | 3.253       |
| 65               | 4.14            | 2.734       | —                | —               | —           |

Exhaust temperature sensor 50kΩ resistance ~ voltage correspondence table (including compressor top shell temperature sensor and air exhaust pipe temperature sensor)

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| -30              | 911.56          | 0.036       | 61               | 11.736          | 1.518       |
| -29              | 853.66          | 0.038       | 62               | 11.322          | 1.548       |
| -28              | 799.98          | 0.041       | 63               | 10.925          | 1.577       |
| -27              | 750.18          | 0.043       | 64               | 10.544          | 1.606       |
| -26              | 703.92          | 0.046       | 65               | 10.178          | 1.635       |
| -25              | 660.93          | 0.049       | 66               | 9.8269          | 1.664       |
| -24              | 620.94          | 0.052       | 67               | 9.4896          | 1.693       |
| -23              | 583.72          | 0.056       | 68               | 9.1655          | 1.722       |
| -22              | 549.04          | 0.059       | 69               | 8.9542          | 1.741       |
| -21              | 516.71          | 0.063       | 70               | 8.5551          | 1.778       |
| -20              | 486.55          | 0.066       | 71               | 5.9676          | 1.806       |
| -19              | 458.4           | 0.07        | 72               | 7.9913          | 1.834       |
| -18              | 432.1           | 0.075       | 73               | 7.7257          | 1.862       |
| -17              | 407.51          | 0.079       | 74               | 7.4702          | 1.889       |
| -16              | 384.51          | 0.084       | 75               | 7.2245          | 1.916       |
| -15              | 362.99          | 0.088       | 76               | 6.9882          | 1.943       |
| -14              | 342.83          | 0.094       | 77               | 6.7608          | 1.969       |
| -13              | 323.94          | 0.099       | 78               | 6.542           | 1.995       |

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| -12              | 306.23          | 0.104       | 79               | 6.3315          | 2.021       |
| -11              | 289.61          | 0.11        | 80               | 6.1288          | 2.046       |
| -10              | 274.02          | 0.116       | 81               | 5.9336          | 2.071       |
| -9               | 259.37          | 0.123       | 82               | 5.7457          | 2.096       |
| -8               | 245.61          | 0.129       | 83               | 5.5647          | 2.12        |
| -7               | 232.67          | 0.136       | 84               | 5.3903          | 2.144       |
| -6               | 220.5           | 0.143       | 85               | 5.2223          | 2.168       |
| -5               | 209.05          | 0.151       | 86               | 5.0605          | 2.191       |
| -4               | 195.97          | 0.158       | 87               | 4.9044          | 2.214       |
| -3               | 188.12          | 0.167       | 88               | 4.7541          | 2.237       |
| -2               | 178.65          | 0.175       | 89               | 4.6091          | 2.259       |
| -1               | 169.68          | 0.184       | 90               | 4.4693          | 2.281       |
| 0                | 161.02          | 0.193       | 91               | 4.3345          | 2.302       |
| 1                | 153             | 0.202       | 92               | 4.2044          | 2.323       |
| 2                | 145.42          | 0.212       | 93               | 4.0789          | 2.344       |
| 3                | 135.96          | 0.223       | 94               | 3.9579          | 2.364       |
| 4                | 131.5           | 0.233       | 95               | 3.841           | 2.384       |
| 5                | 126.17          | 0.242       | 96               | 3.7283          | 2.404       |
| 6                | 119.08          | 0.256       | 97               | 3.6194          | 2.423       |
| 7                | 113.37          | 0.267       | 98               | 3.5143          | 2.442       |
| 8                | 107.96          | 0.28        | 99               | 3.4128          | 2.46        |
| 9                | 102.85          | 0.292       | 100              | 3.3147          | 2.478       |
| 10               | 98.006          | 0.306       | 101              | 3.22            | 2.496       |
| 11               | 93.42           | 0.319       | 102              | 3.1285          | 2.514       |
| 12               | 89.075          | 0.333       | 103              | 3.0401          | 2.531       |
| 13               | 84.956          | 0.348       | 104              | 2.9547          | 2.547       |
| 14               | 81.052          | 0.362       | 105              | 2.8721          | 2.564       |
| 15               | 77.349          | 0.378       | 106              | 2.7922          | 2.58        |
| 16               | 73.896          | 0.393       | 107              | 2.715           | 2.595       |
| 17               | 70.503          | 0.41        | 108              | 2.6404          | 2.611       |
| 18               | 67.338          | 0.427       | 109              | 2.5682          | 2.626       |
| 19               | 64.333          | 0.444       | 110              | 2.4983          | 2.64        |
| 20               | 61.478          | 0.462       | 111              | 2.4308          | 2.655       |
| 21               | 58.766          | 0.48        | 112              | 2.3654          | 2.669       |
| 22               | 56.189          | 0.499       | 113              | 2.3021          | 2.682       |
| 23               | 53.738          | 0.518       | 114              | 2.2409          | 2.696       |
| 24               | 51.408          | 0.537       | 115              | 2.1816          | 2.709       |
| 25               | 49.191          | 0.558       | 116              | 2.1242          | 2.722       |
| 26               | 47.082          | 0.578       | 117              | 2.0686          | 2.734       |
| 27               | 45.074          | 0.599       | 118              | 2.0148          | 2.747       |
| 28               | 43.163          | 0.621       | 119              | 1.9626          | 2.759       |
| 29               | 41.313          | 0.643       | 120              | 1.9123          | 2.77        |
| 30               | 39.61           | 0.665       | 121              | 1.8652          | 2.781       |
| 31               | 37.958          | 0.688       | 122              | 1.8158          | 2.793       |
| 32               | 36.384          | 0.711       | 123              | 1.7698          | 2.804       |

| Temperature (°C) | Resistance (kΩ) | Voltage (V) | Temperature (°C) | Resistance (kΩ) | Voltage (V) |
|------------------|-----------------|-------------|------------------|-----------------|-------------|
| 33               | 34.883          | 0.735       | 124              | 1.7253          | 2.814       |
| 34               | 33.453          | 0.759       | 125              | 1.6821          | 2.825       |
| 35               | 32.088          | 0.784       | 126              | 1.6402          | 2.835       |
| 36               | 30.787          | 0.809       | 127              | 1.5996          | 2.845       |
| 37               | 29.544          | 0.835       | 128              | 1.5602          | 2.855       |
| 38               | 28.359          | 0.86        | 129              | 1.522           | 2.864       |
| 39               | 27.227          | 0.886       | 130              | 1.485           | 2.873       |
| 40               | 26.147          | 0.913       | 131              | 1.449           | 2.882       |
| 41               | 25.114          | 0.94        | 132              | 1.4141          | 2.891       |
| 42               | 24.128          | 0.967       | 133              | 1.3803          | 2.9         |
| 43               | 23.186          | 0.994       | 134              | 1.3474          | 2.908       |
| 44               | 22.286          | 1.022       | 135              | 1.3155          | 2.916       |
| 45               | 21.425          | 1.05        | 136              | 1.2846          | 2.924       |
| 46               | 20.601          | 1.078       | 137              | 1.2545          | 2.932       |
| 47               | 19.814          | 1.107       | 138              | 1.2233          | 2.94        |
| 48               | 19.061          | 1.136       | 139              | 1.1969          | 2.947       |
| 49               | 18.34           | 1.164       | 140              | 1.1694          | 2.955       |
| 50               | 17.651          | 1.193       | 141              | 1.1476          | 2.96        |
| 51               | 16.99           | 1.223       | 142              | 1.1166          | 2.969       |
| 52               | 16.358          | 1.252       | 143              | 1.0913          | 2.975       |
| 53               | 15.753          | 1.281       | 144              | 1.0667          | 2.982       |
| 54               | 15.173          | 1.311       | 145              | 1.0429          | 2.988       |
| 55               | 14.618          | 1.34        | 146              | 1.0197          | 2.995       |
| 56               | 14.085          | 1.37        | 147              | 0.9971          | 3.001       |
| 57               | 13.575          | 1.4         | 148              | 0.9752          | 3.007       |
| 58               | 13.086          | 1.429       | 149              | 0.9538          | 3.013       |
| 59               | 12.617          | 1.459       | 150              | 0.9331          | 3.018       |
| 60               | 12.368          | 1.475       | —                | —               | —           |

# Appendix 2 Refrigerant Temperature and Pressure Table

Refrigerant: R32

| Temperature (°C) | Corresponding saturation pressure (BAR) | Temperature (°C) | Corresponding saturation pressure (BAR) | Temperature (°C) | Corresponding saturation pressure (BAR) |
|------------------|---|------------------|---|------------------|---|
| -43              | 1.54                                    | -9               | 6.03                                    | 25               | 16.89                                   |
| -42              | 1.62                                    | -8               | 6.24                                    | 26               | 17.35                                   |
| -41              | 1.69                                    | -7               | 6.46                                    | 27               | 17.82                                   |
| -40              | 1.77                                    | -6               | 6.68                                    | 28               | 18.29                                   |
| -39              | 1.86                                    | -5               | 6.91                                    | 29               | 18.78                                   |
| -38              | 1.94                                    | -4               | 7.14                                    | 30               | 19.27                                   |
| -37              | 2.03                                    | -3               | 7.38                                    | 31               | 19.78                                   |
| -36              | 2.12                                    | -2               | 7.62                                    | 32               | 20.29                                   |
| -35              | 2.21                                    | -1               | 7.87                                    | 33               | 20.82                                   |
| -34              | 2.31                                    | 0                | 8.13                                    | 34               | 21.35                                   |
| -33              | 2.41                                    | 1                | 8.39                                    | 35               | 21.9                                    |
| -32              | 2.52                                    | 2                | 8.66                                    | 36               | 22.45                                   |
| -31              | 2.62                                    | 3                | 8.94                                    | 37               | 23.02                                   |
| -30              | 2.73                                    | 4                | 9.22                                    | 38               | 23.59                                   |
| -29              | 2.84                                    | 5                | 9.51                                    | 39               | 24.18                                   |
| -28              | 2.97                                    | 6                | 9.81                                    | 40               | 24.78                                   |
| -27              | 3.09                                    | 7                | 10.11                                   | 41               | 25.39                                   |
| -26              | 3.21                                    | 8                | 10.42                                   | 42               | 26.01                                   |
| -25              | 3.34                                    | 9                | 10.74                                   | 43               | 26.64                                   |
| -24              | 3.48                                    | 10               | 11.07                                   | 44               | 27.29                                   |
| -23              | 3.62                                    | 11               | 11.4                                    | 45               | 27.94                                   |
| -22              | 3.76                                    | 12               | 11.74                                   | 46               | 28.61                                   |
| -21              | 3.91                                    | 13               | 12.09                                   | 47               | 29.29                                   |
| -20              | 4.06                                    | 14               | 12.44                                   | 48               | 29.99                                   |
| -19              | 4.21                                    | 15               | 12.81                                   | 49               | 30.69                                   |
| -18              | 4.37                                    | 16               | 13.18                                   | 50               | 31.41                                   |
| -17              | 4.54                                    | 17               | 13.56                                   | 52               | 32.88                                   |
| -16              | 4.71                                    | 18               | 13.94                                   | 54               | 34.41                                   |
| -15              | 4.88                                    | 19               | 14.34                                   | 56               | 35.99                                   |
| -14              | 5.06                                    | 20               | 14.74                                   | 58               | 37.63                                   |
| -13              | 5.24                                    | 21               | 15.16                                   | 60               | 39.33                                   |
| -12              | 5.43                                    | 22               | 15.58                                   | 62               | 41.09                                   |
| -11              | 5.63                                    | 23               | 16.01                                   | 65               | 43.84                                   |
| -10              | 5.83                                    | 24               | 16.45                                   | 67               | 45.76                                   |

# Appendix 3 Pressure Sensor Voltage and Pressure Table

High-pressure sensor features (R32)

| Temperature (°C) | Absolute pressure (kPA) | Voltage (V) | Temperature (°C) | Absolute pressure (kPA) | Voltage (V) |
|------------------|-------------------------|-------------|------------------|-------------------------|-------------|
| -40              | 176                     | 0.102       | 16               | 1300                    | 1.3         |
| -39              | 184                     | 0.111       | 17               | 1337                    | 1.34        |
| -38              | 193                     | 0.12        | 18               | 1375                    | 1.38        |
| -37              | 202                     | 0.13        | 19               | 1413                    | 1.421       |
| -36              | 211                     | 0.139       | 20               | 1453                    | 1.463       |
| -35              | 220                     | 0.149       | 21               | 1493                    | 1.506       |
| -34              | 230                     | 0.16        | 22               | 1535                    | 1.551       |
| -33              | 240                     | 0.17        | 23               | 1577                    | 1.596       |
| -32              | 250                     | 0.181       | 24               | 1620                    | 1.641       |
| -31              | 261                     | 0.193       | 25               | 1664                    | 1.688       |
| -30              | 273                     | 0.206       | 26               | 1708                    | 1.735       |
| -29              | 283                     | 0.216       | 27               | 1754                    | 1.784       |
| -28              | 295                     | 0.229       | 28               | 1801                    | 1.834       |
| -27              | 307                     | 0.242       | 29               | 1848                    | 1.884       |
| -26              | 319                     | 0.255       | 30               | 1897                    | 1.937       |
| -25              | 332                     | 0.268       | 31               | 1946                    | 1.989       |
| -24              | 345                     | 0.282       | 32               | 1996                    | 2.042       |
| -23              | 359                     | 0.297       | 33               | 2048                    | 2.098       |
| -22              | 373                     | 0.312       | 34               | 2100                    | 2.153       |
| -21              | 388                     | 0.328       | 35               | 2153                    | 2.21        |
| -20              | 403                     | 0.344       | 36               | 2208                    | 2.268       |
| -19              | 418                     | 0.36        | 37               | 2263                    | 2.327       |
| -18              | 434                     | 0.377       | 38               | 2320                    | 2.388       |
| -17              | 450                     | 0.394       | 39               | 2377                    | 2.448       |
| -16              | 467                     | 0.412       | 40               | 2436                    | 2.511       |
| -15              | 484                     | 0.43        | 41               | 2495                    | 2.574       |
| -14              | 502                     | 0.45        | 42               | 2556                    | 2.639       |
| -13              | 520                     | 0.469       | 43               | 2618                    | 2.705       |
| -12              | 538                     | 0.488       | 44               | 2681                    | 2.772       |
| -11              | 558                     | 0.509       | 45               | 2745                    | 2.841       |
| -10              | 577                     | 0.53        | 46               | 2810                    | 2.91        |
| -9               | 597                     | 0.551       | 47               | 2876                    | 2.98        |
| -8               | 618                     | 0.573       | 48               | 2944                    | 3.053       |
| -7               | 639                     | 0.596       | 49               | 3013                    | 3.126       |
| -6               | 661                     | 0.619       | 50               | 3083                    | 3.201       |
| -5               | 684                     | 0.644       | 51               | 3154                    | 3.277       |
| -4               | 707                     | 0.668       | 52               | 3226                    | 3.353       |
| -3               | 730                     | 0.693       | 53               | 3300                    | 3.432       |
| -2               | 754                     | 0.718       | 54               | 3374                    | 3.511       |



| Temperature (°C) | Absolute pressure (kPA) | Voltage (V) | Temperature (°C) | Absolute pressure (kPA) | Voltage (V) |
|------------------|-------------------------|-------------|------------------|-------------------------|-------------|
| -1               | 779                     | 0.745       | 55               | 3450                    | 3.592       |
| 0                | 804                     | 0.772       | 56               | 3528                    | 3.675       |
| 1                | 830                     | 0.799       | 57               | 3606                    | 3.759       |
| 2                | 857                     | 0.828       | 58               | 3686                    | 3.844       |
| 3                | 884                     | 0.857       | 59               | 3767                    | 3.93        |
| 4                | 912                     | 0.887       | 60               | 3849                    | 4.018       |
| 5                | 940                     | 0.917       | 61               | 3932                    | 4.106       |
| 6                | 969                     | 0.947       | 62               | 4017                    | 4.197       |
| 7                | 999                     | 0.979       | 63               | 4103                    | 4.288       |
| 8                | 1030                    | 1.012       | 64               | 4190                    | 4.381       |
| 9                | 1061                    | 1.046       | 65               | 4278                    | 4.475       |
| 10               | 1093                    | 1.08        | 66               | 4367                    | 4.57        |
| 11               | 1125                    | 1.114       | 67               | 4457                    | 4.666       |
| 12               | 1159                    | 1.15        | 68               | 4548                    | 4.763       |
| 13               | 1193                    | 1.186       | 69               | 4639                    | 4.86        |
| 14               | 1228                    | 1.224       | 70               | 4731                    | 4.958       |
| 15               | 1263                    | 1.261       | 71               | 4893                    | 5.13        |

## Low-pressure sensor features (R32)


| Temperature (°C) | Absolute pressure (kPA) | Voltage (V) | Temperature (°C) | Absolute pressure (kPA) | Voltage (V) |
|------------------|-------------------------|-------------|------------------|-------------------------|-------------|
| -70              | 36                      | 0.369       | -14              | 502                     | 1.301       |
| -69              | 38                      | 0.373       | -13              | 520                     | 1.337       |
| -68              | 40                      | 0.377       | -12              | 538                     | 1.373       |
| -67              | 43                      | 0.383       | -11              | 558                     | 1.413       |
| -66              | 46                      | 0.389       | -10              | 577                     | 1.451       |
| -65              | 48                      | 0.393       | -9               | 597                     | 1.491       |
| -64              | 51                      | 0.399       | -8               | 618                     | 1.533       |
| -63              | 54                      | 0.405       | -7               | 639                     | 1.575       |
| -62              | 57                      | 0.411       | -6               | 661                     | 1.619       |
| -61              | 61                      | 0.419       | -5               | 684                     | 1.665       |
| -60              | 64                      | 0.425       | -4               | 707                     | 1.711       |
| -59              | 68                      | 0.433       | -3               | 730                     | 1.757       |
| -58              | 72                      | 0.441       | -2               | 754                     | 1.805       |
| -57              | 76                      | 0.449       | -1               | 799                     | 1.895       |
| -56              | 80                      | 0.457       | 0                | 804                     | 1.905       |
| -55              | 84                      | 0.465       | 1                | 830                     | 1.957       |
| -54              | 89                      | 0.475       | 2                | 857                     | 2.011       |
| -53              | 94                      | 0.485       | 3                | 884                     | 2.065       |
| -52              | 99                      | 0.495       | 4                | 912                     | 2.121       |
| -51              | 104                     | 0.505       | 5                | 940                     | 2.177       |
| -50              | 109                     | 0.515       | 6                | 969                     | 2.235       |
| -49              | 115                     | 0.527       | 7                | 999                     | 2.295       |
| -48              | 121                     | 0.539       | 8                | 1030                    | 2.357       |
| -47              | 127                     | 0.551       | 9                | 1061                    | 2.419       |
| -46              | 133                     | 0.563       | 10               | 1096                    | 2.489       |

| Temperature (°C) | Absolute pressure (kPA) | Voltage (V) | Temperature (°C) | Absolute pressure (kPA) | Voltage (V) |
|------------------|-------------------------|-------------|------------------|-------------------------|-------------|
| -45              | 140                     | 0.577       | 11               | 1125                    | 2.547       |
| -44              | 146                     | 0.589       | 12               | 1159                    | 2.615       |
| -43              | 154                     | 0.605       | 13               | 1193                    | 2.683       |
| -42              | 161                     | 0.619       | 14               | 1228                    | 2.753       |
| -41              | 168                     | 0.633       | 15               | 1263                    | 2.823       |
| -40              | 176                     | 0.649       | 16               | 1300                    | 2.897       |
| -39              | 184                     | 0.665       | 17               | 1337                    | 2.971       |
| -38              | 193                     | 0.683       | 18               | 1375                    | 3.047       |
| -37              | 202                     | 0.701       | 19               | 1413                    | 3.123       |
| -36              | 211                     | 0.719       | 20               | 1453                    | 3.203       |
| -35              | 220                     | 0.737       | 21               | 1493                    | 3.283       |
| -34              | 230                     | 0.757       | 22               | 1535                    | 3.367       |
| -33              | 240                     | 0.777       | 23               | 1577                    | 3.451       |
| -32              | 250                     | 0.797       | 24               | 1620                    | 3.537       |
| -31              | 261                     | 0.819       | 25               | 1664                    | 3.625       |
| -30              | 272                     | 0.841       | 26               | 1708                    | 3.713       |
| -29              | 283                     | 0.863       | 27               | 1754                    | 3.805       |
| -28              | 295                     | 0.887       | 28               | 1801                    | 3.899       |
| -27              | 307                     | 0.911       | 29               | 1848                    | 3.993       |
| -26              | 319                     | 0.935       | 30               | 1897                    | 4.091       |
| -25              | 332                     | 0.961       | 31               | 1946                    | 4.189       |
| -24              | 345                     | 0.987       | 32               | 1996                    | 4.289       |
| -23              | 359                     | 1.015       | 33               | 2048                    | 4.393       |
| -22              | 373                     | 1.043       | 34               | 2100                    | 4.497       |
| -21              | 388                     | 1.073       | 35               | 2153                    | 4.603       |
| -20              | 403                     | 1.103       | 36               | 2208                    | 4.713       |
| -19              | 418                     | 1.133       | 37               | 2263                    | 4.823       |
| -18              | 434                     | 1.165       | 38               | 2320                    | 4.937       |
| -17              | 450                     | 1.197       | 39               | 2377                    | 5.051       |
| -16              | 467                     | 1.231       | 40               | 2439                    | 5.175       |
| -15              | 484                     | 1.265       | —                | —                       | —           |

## Appendix 4 Electric Specifications

### ⚠ WARNING

- (1) All electrical installation must be performed by qualified technicians in accordance with local laws, regulations and this user manual.
- (2) Use air conditioner specialized power supply and make sure that it is consistent with system's rated voltage.
- (3) Do not pull the power cord with force.
- (4) Caliber of the power cord must be large enough. A damaged power cord or connection wire must be replaced by specialized electrical cords.
- (5) Connect the unit to specialized grounding device and make sure it is securely grounded. It's a must to install air switch and current circuit breaker that can cut off the power of the entire system. The air switch should include magnetic trip function and thermal trip function so that system can be protected from short circuit and overload.
- (6) Air conditioner belongs to class I electrical appliance, so it must be securely grounded.
- (7) The yellow-green wire inside the unit is a ground wire. Do not cut it off or secure it with tapping screws, otherwise it will lead to electric shock.
- (8) Power supply must include secure grounding terminal. Do not connect the ground wire to the following: ① Water pipe; ② Gas pipe; ③ Drain pipe; ④ Other places that are deemed as not secure by professional technicians.
- (9) Be sure the power supply has been cut off and the capacitor on the main board has been discharged prior to electric wiring and service.
- (10) Do not change any part; and do not shield, shortcut or remove any part.



NOTE: For single-phase units, connect wires according to drawing ①; for three-phase units, connect wires according to drawing ②.

**NOTE:** Connect the power cord to the corresponding terminal and grounding screws. Please refer to the circuit diagram for wiring.

### ⚠ WARNING

- (1) Before starting work, check that power is not being supplied to the indoor unit and outdoor unit.
- (2) Wrong wire connection may burn the electrical components.
- (3) Connect the connection cords firmly to the terminal block. Imperfect installation may cause a fire.
- (4) Always connect the ground wire.

## Electrical Parameters:

(1) For Unit Power, selection of air switch are as below:


| Model              | Power Supply   | Fuse Capacity (A) | Maximum Over-Current Protection (A) | Minimum Circuit Ampacity (A) |
|--------------------|----------------|-------------------|-------------------------------------|------------------------------|
| GMV-V36WL/NhC-T(U) | 208/230V~ 60Hz | 60                | 60                                  | 51.9                         |
| GMV-V48WL/NhC-T(U) | 208/230V~ 60Hz | 60                | 60                                  | 53.1                         |
| GMV-V60WL/NhC-T(U) | 208/230V~ 60Hz | 60                | 60                                  | 54.3                         |

(2) For Emergency Power, selection of air switch are as below:

| Model              | Power Supply   | Fuse Capacity (A) | Maximum Over-Current Protection (A) | Minimum Circuit Ampacity (A) |
|--------------------|----------------|-------------------|-------------------------------------|------------------------------|
| GMV-V36WL/NhC-T(U) | 208/230V~ 60Hz | 15                | 15                                  | 1                            |
| GMV-V48WL/NhC-T(U) | 208/230V~ 60Hz | 15                | 15                                  | 1                            |
| GMV-V60WL/NhC-T(U) | 208/230V~ 60Hz | 15                | 15                                  | 1                            |


## Engineering Wiring of Power Supply and Communication Cable:

- (1) Please refer to the following part for wiring. Connect the power cord and communication cord to the corresponding wiring board and grounding screws according to the circuit diagram.
- (2) The wiring shall not touch the pipeline, edge and device.
- (3) For the wiring of power and communication cord, the picture is for reference only. If there're discrepancies between it and the structure in the picture, the actual unit shall prevail.
- (4) Let the communication cables laid out through cabling through, conduit tube or cable channel.
- (5) Wiring is subject to the self-equipped diagram of the unit used at present.



# Appendix 5 Circuit Diagram

GMV-V36WL/NhC-T(U), GMV-V48WL/NhC-T(U) and GMV-V60WL/NhC-T(U)




**NOTE:** Refer to the mark on the unit for the actual circuit diagram.

## Appendix 6 Schematic Diagram

The working principle of Ultra Heat GMV6 Mini is as follows: when the indoor unit is running in the cooling mode, the outdoor unit starts the outdoor module according to the running load demand of the indoor unit. The outdoor heat exchanger is used as the condenser of the system, and the heat exchangers of indoor units are connected in parallel as the evaporator of system. It realizes the adjustment of the air temperature and humidity for indoor space through the return air circulation of the indoor unit; when the indoor unit is in the heating mode, all the four-way valves of the outdoor unit are switched to the energizing state, the outdoor heat exchanger is used as the evaporator of the system and the heat exchanger of indoor unit is used as the condenser of the system. The air temperature and humidity in the indoor space is realized by the return air circulation of the indoor unit.

Working principle diagrams:

System principle diagram of GMV-V36WL/NhC-T(U)、GMV-V48WL/NhC-T(U) and GMV-V60WL/NhC-T(U)



The arrows in the illustration indicate the mounting direction of the components.

# Appendix 7 Names and Functions of Components

| No. | Name  | Main Functions   |
|-----|---|--|
| 1   | Compressor  | The compressor changes its speed according to the actual system need for capacity adjustment.  |
| 2   | Crankcase heater  | In the standby state, the oil temperature of the compressor is guaranteed to prevent backflow.   |
| 3   | Discharge temperature sensor of the inverter compressor | The exhaust temperature of the compressor is detected to achieve the purpose of controlling and protecting the compressor.   |
| 4   | High pressure switch                                    | When the exhaust pressure of the compressor exceeds the action value of the high-pressure switch, the feedback signal immediately stops the operation of the whole unit to achieve the purpose of protecting the compressor. |
| 5   | Oil separator   | It separates the system's gas and oil to ensure the reliability of the compressor.   |
| 6   | Enthalpy-adding electronic expansion valve              | It is used to control the EVI capacity of the compressor.  |
| 7   | High pressure sensor                                    | It detects real-time high voltage values of the system, protects the compressor and realizes other control purposes.   |
| 8   | 4-way valve   | It is used for cooling and heating switching of the IDU.   |
| 9   | Heat exchanger  | It is used for outdoor heat exchange.  |
| 10  | Fan   | It improves the heat exchange efficiency.  |
| 11  | Defrosting temperature sensor                           | It is used to detect defrosting.   |
| 12  | Heating electronic expansion valve                      | It adjusts the refrigerant in heating mode   |
| 13  | Electronic expansion valve of the sub-cooler            | It is used to control the liquid pipe refrigerant subcooling degree during the cooling operation of the system and reduce the loss of the pipeline capacity.   |
| 14  | Sub-cooler  | It is used to control the liquid pipe subcooling degree.   |
| 15  | Liquid outlet temperature sensor of the sub-cooler      | It is used to detect the liquid pipe temperature.  |
| 16  | Inlet temperature sensor of the gas-liquid separator    | It is used to check the inlet temperature of the gas-liquid separator to prevent liquid refrigerant from entering the system.  |
| 17  | Gas inlet temperature sensor of the sub-cooler          | It is used to detect the gas pipe temperature.   |
| 18  | Low pressure sensor                                     | It is used to detect the low pressure of the system and prevent the operation pressure from being too low.   |
| 19  | Gas-liquid separator                                    | It separates the gas and liquid and prevents liquid refrigerant from entering the compressor.  |
| 20  | Outlet temperature sensor of the gas-liquid separator   | It is used to detect the internal state of the gas-liquid separator and further control the suction state of the compressor.   |
| 21  | Liquid valve  | It is closed after the unit is delivered from the factory.   |
| 22  | Gas valve   | It is closed after the unit is delivered from the factory.   |
| 23  | Unloading valve   | It prevents a dead zone in the pipeline, which may cause over high pressure.   |
| 24  | Low-temperature oil-return solenoid valve               | It is used to control the connection of the compressor return oil pipeline.  |
| 25  | Gas shut-off valve                                      | It is used to cut off the refrigerant in the gas pipe in case of refrigerant leakage.  |
| 26  | Liquid shut-off valve                                   | It is used to cut off the refrigerant in the liquid pipe in case of refrigerant leakage.   |



GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI 519070

---

Add: West Jinji Rd, Qianshan Zhuhai, Guangdong, China

Tel: (+86-756)8522218

Fax: (+86-756)8669426

E-mail: [global@cn.gree.com](mailto:global@cn.gree.com) [www.gree.com](http://www.gree.com)

**JF00305791**