




GMV-ND18A/B-T(U)

NO.	Part Name	Part Number	Quantity in unit
1	Top Cover Sub-assy	51060162	1
2	Electric Box Assy	100002072139	1
3	Main Board	300002062240	1
4	Transformer	43110286	1
5	Terminal Board	42200006005404	1
6	Terminal Board	42011147	1
7	Terminal Board	42011103	1
8	Terminal Board	42000100000102	1
9	Left Side Plate Sub-Assy	17037060269	1
10	Motor Housing	1570220101	1
11	Brushless DC Motor	15010400001401	1
12	Electric Expansion Valve Coil	4304413271	1
13	Evaporator Assy	01100106180902	1
14	Electronic Expansion Valve	072009060046	1
15	Strainer	721304401	2
16	Front Cover	012148060403P	1
17	Bottom Cover Plate 1	012147060206P	1
18	Bottom Cover Plate 2	012147060207P	1
19	Filter Sub-Assy	111001060269	1
20	Right Side Plate	012010062113P	1
21	Rear Side Plate	01312200010P	1
22	Sensor Sub-Assy	39008000103G	1
23	Wired Controller	XE70-33/H	1